

FORCE SERVICE LITERATURE CATALOG

1984 THRU 1995

This catalog has been prepared as an aid to expedite service literature orders for your dealership and customers. This catalog is arranged in numerical order by horsepower and model year, listing the most commonly required publications: Operators Manuals, Parts Books, and Service Manuals.

Order literature by part number on the standard "Outboard Motor Parts Order Form" or the "On Line Parts Ordering System". Refer to your "Parts Price List" for pricing information.

**KEEP THIS LIST AVAILABLE FOR REFERENCE, IT IS ESSENTIAL IN OBTAINING
CORRECT NUMBERS FOR ORDERING LITERATURE**

FORCE[®]
Outboards

A **BRUNSWICK MARINE** Company

FORCE SERVICE MAILING

5-25-95

- 1. 90-823264 - Service Manual - 9.9/15 H.P.**
- 2. 90-830565 - Service Manual - 90/120 H.P.**
- 3. 90-823871960 - Technician's Handbook -
1996**
- 4. 90-826290 - Force Service Literature
Catalog - 1984-1995**

5-1955

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
4 HORSEPOWER					
1984	42F4A	1001	FOB4066	FQB3926	FOB3867
	42FC4A	1001			
	42X4A	1001			
	42XC4A	1001			
1985	42F5A	1001	FOB4064	FOB4049	FOB3867
	42FC5A	1001	FOB4066	FOB4081	FOB3867
	43F5A	1001			
	43FC5A	1001			
1986	42F6A	1001	FOB4066	FOB4081	FOB3867
	42FC6A	1001			
	43F6A	1001			
	43FC6A	1001			
1987	42F7A	1001	FOB4066	FOB4096	FOB4126
	C42F7A	1001			
	43F7A	1001			
5 HORSEPOWER					
1988	52F8A	1001	FOB4205	90-822877	90-823263
	53F8A	1001			
	C52F8A	1001			
	C53F8A	1001			
	52F8B	1001	FOB4225-1	90-822877	90-823263
	53F8B				
	C52F8B				
	C53F8B				
1989	52F9A	1001	FOB4225-1	90-822877	90-823263
	B52F9A	1001			
	C52F9A	1001			
	53F9A	1001			
	B53F9A	1001	FOB4225-1	90-822877	90-823263
	52F9B	1001			
	53F9B	1001			
	52X9B	1001			
	53X9B	1001			
1990	52F90A	1001	FOB4225-1	90-822877	90-823263
	53F90A	1001			
	52F90B	1001	FOB4225-1	90-822877	90-823263

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
5 HORSEPOWER (CONT.)					
1990 (Cont.)	53F90B	1001	FOB4225-1	90-822877	90-823263
1991	52F91A	1001	FOB4472	90-822877	90-823263
	53F91A	1001			
	52E91A	1001			
	53E91A	1001			
	52L91A	1001			
	53L91A	1001			
	52F91D	1001	FOB4472	90-822877	90-823263
	53F91D	1001			
	52E91D	1001			
	53E91D	1001			
	52L91D	1001			
	53L91D	1001			
1992	52F92B	1001	FOB4472	90-822877	90-823263
	52E92B	1001			
	53F92B	1001			
	53E92B	1001			
	52L92B	1001			
	53L92B	1001			
	E000001-E009499		90-822171920	90-822877	90-823263
1993	E009500-E035059		90-822171941	90-822877	90-823263
1994	E035060 & Up		90-822171941	90-822877	90-823263
1995	E090400 & Up		90-822171941	90-822877	90-823263
7.5 HORSEPOWER					
1985	72F5A	1001	FOB3858	FOB3928	FOB3868
9.9 HORSEPOWER					
1984	92F4A	1001	FOB4067	90-823056	FOB3869
	92FC4A	1001			
	92F4B	1001			
1985	92F5B	1001	FOB4067	90-823056	FOB3869
	92FC5B	1001			
1986	92F6B	1001	FOB4067	90-823056	FOB3869
	92FC6B	1001			
1987	92F7A	1001	FOB4067	90-823056	FOB4127
	C92F7A	1001			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
9.9 HORSEPOWER (CONT.)					
1988	92F8A	1001	FOB4526-1	90-823056	90-823264
	93F8A	1001			
	C92F8A	1001			
	92F8B	1001	FOB4526-1	90-823056	90-823264
	93F8B	1001			
	C92F8B	1001			
1989	92F9A	1001	FOB4526-1	90-823056	90-823264
	B92F9A	1001			
	C92F9A	1001			
	93F9A	1001			
	B93F9A	1001			
	92F9B	1001	FOB4526-1	90-823056	90-823264
	92X9B	1001			
	93F9B	1001			
	93X9B	1001			
1990	92F90A	1001	FOB4526-1	90-823056	90-823264
	92X90A	1001			
	93F90A	1001			
	92F90C	1001	FOB4526-1	90-823056	90-823264
	92X90C	1001			
	93F90C	1001			
1991	92F91A	1001	FOB4526-1	90-823056	90-823264
	93F91A	1001			
	92E91A	1001			
	93E91A	1001			
	92F91B	1001	FOB4526-1	90-823056	90-823264
	93F91B	1001			
	92E91B	1001			
	92E91C	1001	FOB4526-1	90-823056	90-823264
	93E91C	1001			
	92L91C	1001			
	93L91C	1001			
	92F91D	1001	FOB4526-1	90-823056	90-823264
	93F91D	1001			
	92E91D	1001			
	93E91D	1001			
	92L91D	1001			
	93L91D	1001			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual	
9.9 HORSEPOWER (CONT.)						
1992	92E92A	1001	FOB4526-1	90-823056	90-823264	
	93E92A	1001				
	92L92A	1001				
	93L92A	1001				
	92F92B	1001	FOB4526-1	90-823056	90-823264	
	92E92B	1001				
	93F92B	1001				
	93E92B	1001				
	92L92B	1001				
	93L92B	1001				
	E000001-E009499					
	1993	E003125-E034999	90-822172941	90-823056	90-823264	
	1994	E035000 & Up	90-822172941	90-823056	90-823264	
	1995	E090400 & Up	90-826876950	90-823056	90-823264	
	15 HORSEPOWER					
	1984	152F4A	1001	FOB4067	90-823056	FOB3869
		152FC4A	1001			
1985	152F5A	1001	FOB4067	90-823056	FOB3869	
	152FC5A	1001				
1986	152F6A	1001	FOB4067	90-823056	FOB3869	
	152FC6A	1001				
1987	152F7A	1001	FOB4067	90-823056	FOB4127	
	C152F7A	1001				
1988	152F8A	1001	FOB4526-1	90-823056	90-823264	
	153F8A	1001				
	C152F8A	1001				
	152F8B	1001	FOB4526-1	90-823056	90-823264	
	153F8B	1001				
	C152F8B	1001				
1989	152F9A	1001	FOB4526-1	90-823056	90-823264	
	B152F9A	1001				
	C152F9A	1001				
	152Y9A	1001				
	153F9A	1001				
	B153F9A	1001				

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
------	------------------	------------------------	---------------------	---------------	-------------------

15 HORSEPOWER (CONT.)

1989 (Cont.)	152F9B	1001	FOB4526-1	90-823056	90-823264	
	153F9B	1001				
	152X9B	1001				
	153X9B	1001				
1990	152F90A	1001	FOB4526-1	90-823056	90-823264	
	152X90A	1001				
	153F90A	1001				
	152F90C	1001	FOB4526-1	90-823056	90-823264	
	152X90C	1001				
	153F90C	1001				
	152F90D	1001	FOB4526-1	90-823056	90-823264	
	152F91A	1001				
	153F91A	1001				
1991	152E91A	1001	FOB4526-1	90-823056	90-823264	
	153E91A	1001				
	152L91A	1001				
	152F91D	1001	FOB4526-1	90-823056	90-823264	
	153F91D	1001				
	152E91D	1001				
	153E91D	1001				
	1992	153E92A	1001	FOB4526-1	90-823056	90-823264
		152L92A	1001			
153L92A		1001				
152F92B		1001	FOB4526-1	90-823056	90-823264	
153F92B		1001				
152E92B		1001				
152L92B		1001				
153L92B		1001				
E000001-E009499						
1993	E009500-E035138		90-822172941	90-823056	90-823264	
1994	E035139 & Up		90-822172941	90-823056	90-823264	
1995	E090400 & UP		90-826876950	90-823056	90-823264	

25 HORSEPOWER

1989	256F9A 257F9A	1001 1001	FOB4367	FOB4400	FOB4645
------	------------------	--------------	---------	---------	---------

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
25 HORSEPOWER (CONT.)					
1989 (Cont.)	256F9B 257F9B	1001 1001	FOB4367	FOB4407	FOB4645
1995	E090400 & Up		90-826877950	90-820755	90-828625
35 HORSEPOWER					
1986	357F6A 35FC6A	1001 1001	FOB4074	FOB4083	FOB3870
1987	357F7A C357F7A 357Y7A	1001 1001 1001	FOB4136	FOB4098	FOB4128
	357F7B 357Y7B C357F7B	1001 1001 1001	FOB4136	FOB4160	FOB4645
1988	357Y8A	1001	FOB4525-1	FOB4190	FOB4645
	357F8B C357F8B 357Y8B 357D8B 357R8B	1001 1001 1001 1001 1001	FOB4525-1	FOB4191	FOB4645
1989	357F9A C357F9A 357Y9A B357F9A 357R9A 357I9A 355D9A 357D9A 357P9A 357H9A 357Q9A 357C9A	1001 1001 1001 1001 1001 1001 1001 1001 1001 1001 1001 1001	FOB4525-1	FOB4273	FOB4645
	357F9B 357X9B 357Y9B	1001 1001 1001	FOB4525-1	FOB4395	FOB4645
	357F9C 357Y9C	1001 1001	FOB4525-1	FOB4456	FOB4645
1990	357X90A 357F90A	1001 1001	FOB4525-1	FOB4488	FOB4645

- 7 -

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
40 HORSEPOWER (CONT.)					
1993	E0009500-E032000		90-819681930	90-823616	90-823265
1994	E032001 & Up		90-819681941	90-823616	90-823265
1995	E093700 & Up		90-826878950	90-820750	90-828821
50 HORSEPOWER					
1984	507F4A	1001	FOB4068	FOB4023	FOB3644
	507X4A	1001			
	507FC4A	1001			
	507XC4A	1001			
1985	507F5A	1001	FOB4068	FOB4051	FOB3644
	507X5A	1001			
	507FC5A	1001			
	507XC5A	1001			
1986	507F6A	1001	FOB4068	FOB4084	FOB3644
	507FC6A	1001			
	507X6A	1001			
	507XC6A	1001			
1987	507F7A	1001	FOB4068	FOB4099	FOB4129
	507X7A	1001			
	C507F7A	1001			
	507Y7A	1001			
	508M7A	1001			
	507F7B	1001	FOB4068	FOB4164	FOB4129
	C507F7B	1001			
	507X7B	1001			
	507Y7B	1001			
	508M7B	1001			
	507F7C	1001	FOB4137	FOB4161	FOB4129
	C507F7C	1001			
	507X7C	1001			
	507Y7C	1001			
	508M7C	1001			
1988	507Y8A	1001	FOB4525-1	FOB4192	FOB4645

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
50 HORSEPOWER (CONT.)					
1988 (Cont.)	507F8B	1001	FOB4525-1	FOB4193	FOB4645
	C507F8B	1001			
	507X8B	1001			
	507Y8B	1001			
	508M8B	1001			
	507T8B	1001			
	507N8B	1001			
	507L8B	1001			
	507F8C	1001	FOB4525-1	FOB4194	FOB4645
	C507F8C	1001			
	507X8C	1001			
	507Y8C	1001			
	507V8C	1001			
	508V8C	1001			
	508M8C	1001			
	507T8C	1001			
	507D8C	1001			
	507N8C	1001			
	507L8C	1001			
	507R8C	1001			
	507I8C	1001			
	507S8C	1001			
	504S8C	1001			
	507H8C	1001			
	504H8C	1001			
	507C8C	1001			
	C507F8D	1001	FOB4525-1	FOB4252	FOB4645
	507X8D	1001			
	507Y8D	1001			
	507V8D	1001			
	508V8D	1001			
	508M8D	1001			
	507T8D	1001			
	507D8D	1001			
	507N8D	1001			
	507L8D	1001			
	507R8D	1001			
	507I8D	1001			
	507S8D	1001			
	504S8D	1001			
	507H8D	1001			
	504H8D	1001			
	507J8D	1001			
1989	507Y9A	1001	FOB4525-1	FOB4274	FOB4645
	507X9A	1001			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
50 HORSEPOWER (CONT.)					
1989 (Cont.)	507F9B	1001	FOB4525-1	FOB4275	FOB4645
	C507F9B	1001			
	507X9B	1001			
	507A9B	1001			
	507Y9B	1001			
	B507F9B	1001			
	507L9B	1001			
	507R9B	1001			
	507K9B	1001			
	507I9B	1001			
	507D9B	1001			
	505D9B	1001			
	508M9B	1001			
	507P9B	1001			
	507H9B	1001			
	507Q9B	1001			
	507C9B	1001			
	507Z9B	1001			
	507U9B	1001			
	507C9B	1001			
	508J9B	1001			
	504P9B	1001			
	507F9C	1001	FOB4525-1	FOB4396	FOB4645
	507X9C	1001			
	507A9C	1001			
	508F9C	1001			
	507A9D	1001	FOB4525-1	FOB4457	FOB4645
	507F9D	1001			
	507X9D	1001			
	508F9D	1001			
1990	507A90A	1001	FOB4525-1	FOB4490-1	FOB4645
	507F90A	1001			
	507X90A	1001			
	507Y90A	1001			
	507A90B	1001	FOB4525-1	FOB4491-1	FOB4645
	507F90B	1001			
	507X90B	1001			
	507Y90B	1001			
	507F90B	1001			
	507A90C	1001	FOB4525-1	FOB4492-1	FOB4645
	507F90C	1001			
	507X90C	1001			
	507Y90C	1001			
	508F90C	1001			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
50 HORSEPOWER (CONT.)					
1990 (Cont.)	507A90D	1001	FOB4525-1	FOB4531	FOB4645
	507F90D	1001			
	507X90D	1001			
	507Y90D	1001			
	508F90D	1001			
1991	507F91A	1001	FOB4525-1	FOB4576-1	FOB4645
	507E91A	1001			
	507X91A	20665			
	507A91A	27040			
	507P91A	1001			
	508F91A	23635			
	508E91A	1001			
	508P91A	28606			
	507F91B	29009	FOB4525-1	FOB4577-1	FOB4645
	507E91B	29107			
	507X91B	29008			
	507P91B	29192			
	508F91B	29383			
	508E91B	1001			
	507F91C	29501	FOB4525-1	FOB4741	FOB4645
	507E91C	9435			
	507X91C	29433			
	507A91C	30942			
	507P91C	31452			
	508F91C	29733			
	508P91C	30216			
	507A91Z	28402			
1992	507A92A	30940	90-819681	FOB4780	90-823265
	507E92A	1001			
	507F92A	1001			
	507P92A	1001			
	507X92A	29944			
	508F92A	1001			
	508P92A	1001			
	507F92C	31796	90-819681	90-823616	90-823265
	507E92C	31807			
	507X92C	31852			
	507A92C	31911			
	E000001-E009499				
1993	E0009500-E032024		90-819681930	90-823616	90-823265
1994	E032025 & Up		90-819681941	90-823616	90-823265

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
50 HORSEPOWER (CONT.)					
1995	E093700 & Up		90-826878950	90-820750	90-828821
60 HORSEPOWER					
1985	608F5A	1001	FOB4010	FOB3936	FOB3788
70 HORSEPOWER					
1991	706F91B	15064	FOB4590	90-823089	90-823266
	706X91B	15056			
	706A91B	15193			
	706P91B	15454			
	708F91B	15076			
	708A91B	15077			
	708P91B	15993			
	706F91C	18201	FOB4590	90-823089	90-823266
	706X91C	17666			
	708F91C	17768			
	708A91C	17777			
	708P91C	17775			
1992	706X92A	17687	90-819682	90-823089	90-823266
	708A92A	18883			
	706F92C	21432	90-819682	90-823089	90-823266
	706E92C	21412			
	706X92C	18733			
	708F92C	21212			
	708E92C	20284			
	708A92C	21222			
	E000001-E009499				
1993	E009500-E032002		90-819681930	90-823089	90-823266
1994	E032003 & Up		90-819681941	90-823089	90-823266
1995	E093700 & Up		90-826878950	90-823089	90-823266
85 HORSEPOWER					
1983	856X3L	1001	FOB4069	FOB3856	FOB3873-1
	856XC3L	1001			
1984	856F4A	1001	FOB4069	FOB4024	FOB4130
	856FC4A	1001			
	856X4L	1001			
	856XC4L	1001			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
0	85 HORSEPOWER (CONT.)				
1985	856F5A	1001	FOB4069	FOB4052	FOB4130
	856FC5A	1001			
	856X5L	1001			
	856XC5L	1001			
1986	856F6A	1001	FOB4069	FOB4085	FOB4130
	856F6B	1001			
	856F6C	1001			
	856FC6A	1001			
	856FC6B	1001			
	856FC6C	1001			
	856X6L	1001			
	856X6M	1001			
	856X6N	1001			
	858F6A	1001			
	858F6B	1001			
	858F6C	1001			
	858V6A	1001			
	858V6B	1001			
	858V6C	1001			
1987	856F7A	1001	FOB4138	FOB4100	FOB4130
	C856F7A	1001			
	858F7A	1001			
	856Y7A	1001			
	858V7A	1001			
	856X7A	1001			
	856F7B	1001	FOB4138	FOB4162	FOB4130
	C856F7B	1001			
	858F7B	1001			
	856Y7B	1001			
	858V7B	1001			
	856X7B	1001			
1988	856X8A	1001	FOB4204-2	FOB4195	FOB4642
	O856X8A	1001			
	856A8A	1001			
	856Y8A	1001			
	C858F8A	1001			
	853F8A	1001			
	853X8A	1001			
	858V8A	1001			
	858M8A	1001			
	856T8A	1001			
	856D8A	1001			
	856N8A	1001			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
85 HORSEPOWER (CONT.)					
1988 (Cont.)	856L8A	1001	FOB4204-2	FOB4195	FOB4642
	858D8A	1001			
	858N8A	1001			
	858R8A	1001			
	858I8A	1001			
	858S8A	1001			
	854S8A	1001			
	856S8B	1001	FOB4204-2	FOB4196	FOB4642
	856A8B	1001			
	856V8B	1001			
	856F8B	1001			
	C858F8B	1001			
	858V8B	1001			
	853F8B	1001			
	C853F8B	1001			
	853X8B	1001			
	856T8B	1001			
	856D8B	1001			
	856N8B	1001			
	856L8B	1001			
	856I8B	1001			
	858M8B	1001			
	858D8B	1001			
	858N8B	1001			
	858R8B	1001			
	858I8B	1001			
	856H8B	1001			
	854H8B	1001			
	856C8B	1001			
	854C8B	1001			
	858S8B	1001			
	854S8B	1001			
	858J8B	1001			
1989	856A9A	1001	FOB4204-2	FOB4276	FOB4642
	858F9B	1001	FOB4204-2	FOB4277	FOB4642
	C858F9B	1001			
	856X9B	1001			
	856Y9B	1001			
	856W9B	1001			
	856L9B	1001			
	856K9B	1001			
	858P9B	1001			
	853F9B	1001			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
85 HORSEPOWER (CONT.)					
1989 (Cont.)	853X9B	1001	FOB4204-2	FOB4277	FOB4642
	858R9B	1001			
	858V9B	1001			
	858I9B	1001			
	858M9B	1001			
	853K9B	1001			
	856X9C	1001	FOB4204-2	FOB4278	FOB4642
	856A9C	1001			
	856Y9C	1001			
	C858F9C	1001			
	B858F9C	1001			
	853F9C	1001			
	856W9C	1001			
	856L9C	1001			
	856K9C	1001			
	856D9C	1001			
	854D9C	1001			
	858R9C	1001			
	858V9C	1001			
	858I9C	1001			
	858M9C	1001			
	853K9C	1001			
	858P9C	1001			
	856F9D	1001	FOB4204-2	FOB4279-1	FOB4642
	856F9E	1001	FOB4204-2	FOB4397	FOB4642
	856X9E	1001			
	856A9E	1001			
	858F9E	1001			
	858X9E	1001			
	853F9E	1001			
	853X9F	1001	FOB4204-2	FOB4398-1	FOB4642
	856F9F	1001			
	856X9F	1001			
	856A9F	1001			
	858F9F	1001			
	858X9F	1001			
	853F9F	1001			
	853X9F	1001			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
------	------------------	------------------------	---------------------	---------------	-------------------

85 HORSEPOWER (CONT.)

1989 (Cont.)	853F9G	1001	FOB4204-2	FOB4458-1	FOB4642
	853X9G	1001			
	856A9G	1001			
	856F9G	1001			
	856X9G	1001			
	858F9G	1001			
	858X9G	1001			
	853F9H	1001	FOB4204-2	FOB4459	FOB4642
	853X9H	1001			
	856A9H	1001			
	856F9H	1001			
	856X9H	1001			
	858F9H	1001			
858X9H	1001				

85 HORSEPOWER L-DRIVE

1989	85LD9A	1001	FOB4306-1	FOB4284-1	FOB4644 & 90-826660--1
	85LD9B	1001	FOB4306-1	FOB4461-1	FOB4644 & 90-826660--1
	85LD9C	1001	FOB4306-1	FOB4462	FOB4644 & 90-826660--1

90 HORSEPOWER SPORTJET

1993	E023150-E033710	90-823376933	90-820612	90-824724
1994	E033711-E066623	90-823376933	90-820612	90-824724
1994 1/2	E066620 & Up	90-823376941	90-820612	90-824724
1995	E080400 & Up	90-823376952	90-809468	90-828455

90 HORSEPOWER L-DRIVE

1990	90LD90A	1001	FOB4508	FOB4501	FOB4644 & 90-826660--1
	90LD90C	1001	FOB4511	FOB4539	FOB4644 & 90-826660--1
1991	90LD91B	1001	FOB4615	FOB4600	FOB4644 & 90-826660--1
	90LD91D	1001	FOB4615	FOB4701	FOB4644 & 90-826660--1

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
90 HORSEPOWER					
1990	903X90A	1001	FOB4507	FOB4493	FOB4642
	903F90A	1001			
	906A90A	1001			
	906X90A	1001			
	906F90A	1001			
	908F90A	1001			
	908X90A	1001			
	903F90B	1001	90-819683	FOB4494-1	FOB4642
	903X90B	1001			
	906A90B	1001			
	906F90B	1001			
	906X90B	1001			
	908F90B	1001			
	908X90B	1001			
	903F90C	1001	90-819683	FOB4495	FOB4642
	903X90C	1001			
	906A90C	1001			
	906F90C	1001			
	906X90C	1001			
	908F90C	1001			
	908X90C	1001			
1991	906F91A	22304	90-819683	FOB4580	FOB4642
	906X91A	1001			
	908E91A	1001			
	908F91A	20883			
	908A91A	24080			
	906F91C	26167	90-819683	FOB4696	FOB4642
	906X91C	26160			
	906P91C	26305			
	908F91C	25861			
	908A91C	25860			
	908P91C	25940			
	903P91C	1001			
	903F91C	26330			
	903E91D	25518	90-819683	FOB4698	FOB4642
	903F91D	1001			
	903P91D	1001			
	906F91D	1001			
	906P91D	1001			
	906X91D	1001			
	908A91D	1001			
	908F91D	1001			
	908P91D	1001			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
------	------------------	------------------------	---------------------	---------------	-------------------

90 HORSEPOWER (CONT.)

1991 (Cont.)	906F91E	27640	90-819683	90-823424	FOB4642
	906X91E	27198			
	908F91E	27300			
	908A91E	27298			
	903F91E	27300			
	906F91H	27967	90-819683	90-823424	FOB4642
	906E91H	27296			
	906X91H	27283			
	908F91H	27965			
	908E91H	27398			
	908A91H	28019			
	903E91H	28176			
1992	906A92A	28718	90-819683	90-823424	90-823267
	908A92A	28706			
	908F92A	28716			
	906F92C	29050	90-819683	90-823424	90-823267
	906E92C	29744			
	906X92C	28943			
	908F92C	29189			
	908E92C	29209			
	908A92C	28998			
	E000001-E009499				
1993	E009500-E031999		90-819683930	90-823424	90-823267
1994	E032000 & Up		90-819683941	90-823424	90-823267
1995	E093700 & Up		90-826880950	90-820754	90-830565

120 HORSEPOWER

1990	1201A90A	1001	FOB4507	90-823644	FOB4642
	1201X90A	1001			
	1208A90A	1001			
	1201A90B	1001	FOB4473-1	90-823644	FOB4642
	1201F90B	1001			
	1201X90B	1001			
	1208A90B	1001			
	1208F90B	1001			
	1208X90B	1001			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
120 HORSEPOWER (CONT.)					
1990 (Cont.)	1201A90C	1001	FOB4473-1	90-823644	FOB4642
	1201F90C	1001			
	1201X90C	1001			
	1208A90C	1001			
	1208X90C	1001			
1991	1208F91A	21261	FOB4473-1	90-823644	FOB4642
	1208X91A	21287			
	1208A91A	21401			
	1208C91A	1001			
	1201F91A	21526			
	1201X91A	18499			
	1201A91A	21604			
	1208F91C	22141	FOB4473-1	90-823644	FOB4642
	1208X91C	22608			
	1208A91C	22552			
	1208C91C	22706			
	1208P91C	22607			
	1201F91C	22808			
	1201X91C	22797			
	1201A91C	22998			
	1208E91D	22130	FOB4473-1	90-823644	FOB4642
	1201E91D	22128			
	1208F91E	23531	FOB4473-1	90-823644	FOB4642
	1208X91E	23530			
	1208F91H	23644	FOB4473-1	90-823644	FOB4642
	1208E91H	23159			
	1208X91H	23175			
	1208A91H	23177			
	1208C91H	23595			
	1208P91H	23582			
	1201F91H	23225			
	1201E91H	23224			
	1201X91H	23225			
	1201A91H	23476			
1992	1201E92A	24243	FOB4473-1	90-823644	90-823267
	1201A92A	24200			
	1201X92A	24170			
	1208A92A	24137			
	1208C92A	24400			
	1208E92A	24432			
	1208F92A	24136			
	1208X92A	23195			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
120 HORSEPOWER (CONT.)					
1992 (Cont.)	1201A92C 1201E92C 1201F92C 1201X92C 1201A92C 1208C92C 1208E92C 1208F92C 1208X92C E000001-E009499	24617 24842 24634 24614 24617 24691 24798 24687 24689	FOB4473-1	90-823644	90-823267
1993	E009630-E031999		90-819683930	90-823644	90-823267
1994	E032000 & Up		90-819683941	90-823644	90-823267
1995	E093700 & Up		90-826880950	90-820756	90-830565
120 HORSEPOWER L-DRIVE					
1990	120LD90A 120LD90B 120LD90C	1001 1001 1001	FOB4508 FOB4511 FOB4511	FOB4503 FOB4504 FOB4540	FOB4644 & 90-826660--1 FOB4644 & 90-826660--1 FOB4644 & 90-826660--1
1991	120LD91B 120LD91D	1001 1001	FOB4615 FOB4615	FOB4604 FOB4702	FOB4644 & 90-826660--1 FOB4644 & 90-826660--1
1992	120LD92B	1001	90-819684	FOB4779	FOB4644 & 90-826660--1
120 HORSEPOWER SPORT JET					
1995	E080400 & Up		90-823376952	90-820757	90-828455
125 HORSEPOWER					
1983	1251X3A 1251XC3A 1258X3A 1258XC3A	1001 1001 1001 1001	FOB4069	FOB3945	FOB3874

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
------	------------------	------------------------	---------------------	---------------	-------------------

125 HORSEPOWER (CONT.)

1984	1251F4A	1001	FOB4069	FOB4945	FOB4130		
	1251FC4A	1001					
	1251X4A	1001					
	1258F4A	1001					
	1251FC4A	1001					
	1258X4A	1001					
	1258XC4A	1001					
1985	1251F5A	1001	FOB4069	FOB4053	FOB4130		
	1251FC5A	1001					
	1251X5A	1001					
	1251XC5A	1001	FOB4069	FOB4053	FOB4130		
	1258F5A	1001					
	1258FC5A	1001					
	1258V5A	1001					
	1258X5A	1001					
	1258XC5A	1001					
	1986	1251F6A	1001	FOB4069	FOB4086	FOB4130	
		1251FC5A	1001				
		1251X6A	1001				
1251XC6A		1001					
1254X6A		1001					
1258F6A		1001					
1258FC6A		1001					
1258X6A		1001					
1258XC6A		1001					
1251F6B		1001	FOB4069	FOB4086	FOB4130		
1251FC6B		1001					
1251X6B		1001					
1251XC6B		1001					
1253X6B		1001					
1254X6B		1001					
1258F6B		1001					
1258FC6B		1001					
1258X6B		1001					
1258XC6B		1001					
1258V6B		1001					

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
------	------------------	------------------------	---------------------	---------------	-------------------

125 HORSEPOWER (CONT.)

1987	1251F7A	1001	FOB4138	FOB4101	FOB4130
	C1251F7A	1001			
	1251X7A	1001			
	1253X7A	1001			
	1254X7A	1001			
	1258F7A	1001			
	C1258F7A	1001			
	1258V7A	1001			
	1258X7A	1001			
	1251F7B	1001	FOB4138	FOB4163	FOB4130
	C1251F7B	1001			
	1251X7B	1001			
	1253X7B	1001			
	1254X7B	1001			
	1258F7B	1001			
	C1258F7B	1001			
	1258V7B	1001			
	1258X7B	1001			

1988	1258F8A	1001	FOB4204-2	FOB4198	FOB4642
	1258X8A	1001			
	1258V8A	1001			
	1254X8A	1001			
	1251X8A	1001			
	1251A8A	1001			
	1253X8A	1001			
	1258M8A	1001			
	1258T8A	1001			
	1258L8A	1001			
	1258F8C	1001	FOB4204-2	FOB4200	FOB4642
	1258AF8C	1001			
	1258X8C	1001			
	1254X8C	1001			
	1254A8C	1001			
	1258V8C	1001			
	1251F8C	1001			
	C1251F8C	1001			
	1251X8C	1001			
	1253X8C	1001			
	1251A8C	1001			
	1251V8C	1001			
	1258M8C	1001			
	1258T8C	1001			
	1258D8C	1001			
	1258L8C	1001			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
125 HORSEPOWER (CONT.)					
1988 (Cont.)	1258I8C	1001	FOB4204-2	FOB4200	FOB4642
	1258J8C	1001			
	1258C8C	1001			
	1251S8C	1001			
	1251H8C	1001			
1989	1251A9A	1001	FOB4204-2	FOB4280	FOB4642
	1258F9B	1001	FOB4204-2	FOB4281	FOB4642
	C1258F9B	1001			
	1258X9B	1001			
	1254X9B	1001			
	B1258F9B	1001			
	1251F9B	1001			
	1251X9B	1001			
	1253X9B	1001			
	B1251F9B	1001			
	1251E9B	1001			
	1258W9B	1001			
	1258L9B	1001			
	1258V9B	1001			
	1258I9B	1001			
	1258D9B	1001			
	1258M9B	1001			
	1251K9B	1001			
	1258P9B	1001			
	1251F9C	1001	FOB4204-2	FOB4282	FOB4642
	1251X9C	1001			
	1251A9C	1001			
	1251E9C	1001			
	1253X9C	1001			
	1254A9C	1001			
	1254X9C	1001			
	1258F9C	1001			
	C1258F9C	1001			
	1258D9C	1001			
	1258H9C	1001			
	1258L9C	1001			
	1258M9C	1001			
	1258P9C	1001			
	1258V9C	1001			
	1258W9C	1001			
	1258X9C	1001			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
125 HORSEPOWER (CONT.)					
1989 (Cont.)	1251F9D	1001	FOB4204-1	FOB4399	FOB4642
	1251X9D	1001			
	1251A9D	1001			
	1253X9D	1001			
	1254A9D	1001			
	1254X9D	1001			
	1258D9D	1001			
	C1258F9D	1001			
	1258F9D	1001			
	1258X9D	1001			
	1258A9D	1001			
	1258L9D	1001			
	1258M9D	1001			
	1258P9D	1001			
	1258V9D	1001			
	1258W9D	1001			
	1251A9E	1001	FOB4204-1	FOB4460	FOB4642
	1251F9E	1001			
	1251X9E	1001			
	1253X9E	1001			
	1254A9E	1001			
	1254X9E	1001			
	1258F9E	1001			
	C1258F9E	1001			
	1258X9E	1001			
125 HORSEPOWER L-DRIVE					
1989	125LD9A	1001	FOB4306-1	FOB4285	FOB4644 & 90-826660--1
	125LD9B	1001	FOB4306-1	FOB4464	FOB4644 & 90-826660--1
150 HORSEPOWER					
1989	1508F9A	1001	FOB4305	90-823715	FOB4643
	1508X9A	1001			
	1508A9A	1001			
	C1508F9A	1001			
	1508E9A	1001			
	1508FB9A	1001			
	1508V9A	1001			
	1508M9A	1001			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual
150 HORSEPOWER (CONT.)					
1989 (Cont.)	1508D9A	1001	FOB4305	90-823715	FOB4643
	1501F9A	1001			
	1501X9A	1001			
	C1501F9A	1001			
	1501FB9A	1001			
1990	1501X90A	1001	FOB4305	90-823715	FOB4643
	1508A90A	1001			
	1508X90A	1001			
	1501F90B	1001	FOB4305	90-823715	FOB4643
	1501X90B	1001			
	1508A90B	1001			
	1508F90B	1001			
	1508X90B	1001			
	1501F90C	1001	FOB4305	90-823715	FOB4643
	1501X90C	1001			
	1508A90C	1001			
	1508F90C	1001			
	1508X90C	1001			
	1501F90D	1001	FOB4305	90-823715	FOB4643
	1501X90D	1001			
	1508A90D	1001			
	1508F90D	1001			
	1508X90D	1001			
1991	1508F91A	22644	FOB4474	90-823715	90-823268
	1508X91A	1001			
	1501X91A	1001			
	1508F91B	23317	FOB4474	90-823715	90-823268
	1508X91B	22656			
	1508A91B	21587			
	1508C91B	21456			
	1501F91B	23317			
	1501A91B	21332			
	1508F91D	24164	FOB4474	90-823715	90-823268
	1508E91D	23627			
	1508X91D	24159			
	1508C91D	24160			
	1508P91D	24162			
	1501F91D	24064			

Year	Model Numbers	Starting Serial No.	Operators Manual	Parts Book	Service Manual			
150 HORSEPOWER (CONT.)								
1991 (Cont.)	1501E91D	23637	FOB4474	90-823715	90-823268			
	1501X91D	24061						
	1501A91D	24086						
	1508E91J	24613	FOB4474	90-823715	90-823268			
	1508X91J	24614						
	1508A91J	25087						
	1508C91J	24649						
	1508P91J	24643						
	1501F91J	24994						
	1501E91J	24519						
	1501X91J	24513						
	1501A91J	24591						
	1992	1508X92A	25790	FOB4474	90-823715	90-823268		
		1508A92A	26301					
		1508C92A	26307					
1501X92A		26185	FOB4474	90-823715	90-823268			
1501A92A		26200						
1051E92A		26520						
1501F92A		60019						
1508E92A		26606						
1508F92A		26970						
1508X92C		27500						
1508A92C		27795						
1508C92C		27576						
1501X92C		27400						
E000001-E009499								
1993		E009990-E032056				90-819683930	90-823715	90-823268
1994	E032057 & Up		90-819683941	90-823715	90-823268			

SEARS

Year	Sears Model No.	Operators/Parts Manual
------	--------------------	---------------------------

5 HORSEPOWER

1988	225.58749 225.58750	FOB4220-2
1989	225.5875012 225.587491	FOB4422 FOB4423
1990	225.587503 225.587493	FOB4545 FOB4546
1991	225.587504	FOB4689
1992	225.587504 225.587494	90-823212930 90-823650930
1993	225.587504 225.587494	90-823650930 90-823650930
1994	225.587505 225.587495	90-823212940 90-823212940
1995	225.587505 225.587495	90-823212940 90-823212940

7.5 HORSEPOWER

1988	225.58175 225.58174	FOB4214-1
1989	225.581751 225.581741	FOB4386 FOB4387

9.9 HORSEPOWER

1987	225.58799	FOB4120
1988	225.58199 225.58198	FOB4215-1
1989	225.581991 225.581981	FOB4388 FOB4389

NOTE: For Service Manual on all models listed contact SEARS for price and availability.

SEARS

Year	Sears Model No.	Operators/Parts Manual
------	--------------------	---------------------------

9.9 HORSEPOWER (CONT.)

1990	225.581993 225.581983	FOB4543 FOB4544
1991	225.581994 225.581984	FOB4691 FOB4692
1992	225.581995 225.581985	90-823145930 90-823651930
1993	225.581995 225.581985	90-823215930 90-823651930
1994	225.581996 225.581986	90-823215931 90-823215931
1995	225.581997 225.581987	90-827591950 90-827591950

15 HORSEPOWER

1987	225.58715	FOB4106-1
1988	225.58150 225.58149	FOB4216-1
1989	225.581501 225.581491	FOB4390 FOB4391
1990	225.581503 225.581493	FOB4541 FOB4542
1991	225.581504 225.581494	FOB4693 FOB4694
1992	225.581505 225.581495	90-823144930 90-823652930
1993	225.581505 225.581495	90-823218930 90-823652930
1994	225.581506 225.581496	90-823218931 90-823218931
1995	225.581507 225.581497	90-827592950 90-827592950

DEALER SERVICE LITERATURE

Part No.	Description
FOB4230-6	Complete Collection of Parts Books, Service Manuals & misc. literature
FOB4070-3	Service Manual/Parts Book Binder
FOB4167	Service Manual Collection: 1984-1987
FOB4404-3	Service Manual Collection: 1988-1991
90-822549	Microfiche Parts Book Collection: 1984-1994
90-823798	Service Bulletin Collection: 1983-1989
90-825408	Service Bulletin Collection: 1990-1992
90-74990-95	OEM Parts Price List
90-826589	Special Tool Catalog
90-821217	Warranty Claim Form
FOB3467	Parts Catalog Power Trim and Power Tilt thru 1986
FOB4685	Parts Catalog Power Trim and Power Tilt: 1986-1991
FOB4062-3	Data Chart: 1983-1990
FOB4800-1	Data Chart: 1991-1992
FOB2130	Engine Analysis and Service Sheet
FOB2179	Pre-Delivery Inspection Sheet
90-42000 95	Accessory Catalog
90-823871	Technicians Handbook: 1993
90-823871940	Technicians Handbook: 1994
90-823871950	Technicians Handbook 1995
90-816212-1	Pre-Delivery Inspection Form
90-823804	Wiring Diagram Collection 1984-1993

WATERCRAFTMANUALS.COM