

Martin Motors SERVICE BULLETIN

EAU CLAIRE, WISCONSIN, U. S. A.

DATE _____ 1956

NO. _____

NEW PRICES ON CERTAIN MARTIN MOTOR PARTS. EFFECTIVE APRIL 1, 1956

Increases in the cost of material and labor have made it necessary to adjust list prices on the parts listed below. Please correct your price list to show these changes.

<u>PART NO.</u>	<u>DESCRIPTION.</u>	<u>NEW LIST PRICE</u>
15038	Stern Bracket Clamping-Left	\$ 5.75
15039	Stern Bracket Clamping-Right	5.75
15040	Stern Bracket-Left	3.75
15041	Stern Bracket-Right	3.75
15231	Motor Support Tube	20.00
25005	Pump plate	.60
25010	Propeller Shaft	4.50
25012	Eccentric	2.50
25020	Motor Support Tube	16.00
25052	Stern Bracket-Left	4.00
25053	Stern Bracket-Right	4.00
25054	Pinion Gear	5.00
25146	Stern Bracket & Clamping Screw Ass'y.-R	6.25
25147	Stern Bracket & Clamping Screw Ass'y.-L	6.25
25354	Connecting Rod	10.00
25415	Gearcase Assembly	33.50
25417	Prop. Shaft and Gear	15.00
25418	Gear Set (Ring and Pinion)	10.00
55080	Drive Shaft Bearing	2.75
55260	Propeller	5.50
55605	Gearcase Assembly	36.75
55607	Gearcase Housing	12.75
65391	Starter Handle	.75
65779	Gear-Speed Control Handle Bracket	1.75
30A-52	Idle Adjustment Screw	.75
30A-53	Idle Adjustment Screw	.75
25270	Carburetor Control Ass'y	(No Longer Available)
25605	Spark Plug Nipple	(No Longer Available)

MARTIN MOTORS DIVISION OF NATIONAL PRESTO INDUSTRIES, INC.

EAU CLAIRE, WISCONSIN, U. S. A.

Martin Motors
NUMERICAL PARTS LIST

SHOWING PART NUMBER - DESCRIPTION AND PRICE

EFFECTIVE JANUARY 1, 1956

ALL PRICES AND SPECIFICATIONS HEREIN LISTED SUBJECT TO CHANGE WITHOUT NOTICE

Part No.	Description	Price	Part No.	Description	Price
5002	Magneto Assembly (Refer to 5088)		5403	Cylinder Block and Crankcase Assembly	29.00
5003	Cylinder Head	3.60	5404	Lower Unit Assembly (Refer to 15145)	
5004	Gasket—Cylinder Head Compression	.10	5405	Powerhead Assembly MARTIN 20	113.15
5005	Cylinder head water gasket	.16	5406	Powerhead—Less Carburetor and Magneto MARTIN 20	77.65
5008	Bearing—Lower Main (Refer to 5075)		5831	Washer—Shut Off Cock	.03
5009	Gasket—Intake Manifold	.05	5832	Metal Spacer	.03
5011	Cover—Intake Manifold	.25	15000	Tank Mounting Bracket—Rear	1.20
5013	Shroud—Rear	3.60	15001	Cover—Cylinder Head	.75
5014	Propeller (Refer to 5072)		15002	Gasket—Cylinder Head Cover	.10
5015	Stud—Carburetor	.10	15003	Cylinder Head (Refer to 15330)	
5016	Carburetor (MD 9A Tillotson)	12.10	15004	Gasket—Cylinder Head Compression	.15
5019	Control Linkage Rod	.30	15005	Gasket—Cylinder Head Water	.20
5020	Gasket—Exhaust Port Cover	.10	15011	Piston Ring	.40
5021	Exhaust Port Cover	.30	15012	Lockspring Wristpin	.05
5024	Gas Tank Assembly (Refer to 5070)		15014	Connecting Rod and Cap Assembly	6.00
5032	Gas Line Fitting	.94	15018	Crankshaft	21.00
5033	Decal—MARTIN "20"	.15	15019	Magneto (Wico FW-1741B)	40.25
5034	Decal—Operating Instructions	.15	15020	Bearing—Upper Main (Refer to 15182)	
5035	Retainer—Water Seal (Refer to 25904)		15021	Bearing—Lower Main (Refer to 15181)	
5036	Oil Seal—Crankshaft Lower	.44	15024	Gasket—Intake Manifold	.05
5037	Shroud Assembly—Front	4.00	15026	Carburetor Assembly (MD 8A Tillotson)	12.65
5038	Decal—Carburetor Control	.15	15027	Speed Control Lever	.25
5041	Gas Line Assembly	1.00	15028	Valve Assembly (Refer to 15223)	
5044	Crankshaft	13.50	15031	Tank Mounting Bracket—Side	.25
5050	Carburetor (MD 9B Tillotson)	12.10	15032	Gasket—Exhaust Port Cover Plate	.20
5055A	Decal Set (Prior to '49 Model) MARTIN 20	.75	15033	Plate—Exhaust Port Cover	.60
5055B	Decal Set ('49 or Later) MARTIN 20	.75	15034	Gasket—Exhaust Port Cover	.20
5056A	Gasket Set MARTIN 20	.99	15035	Cover—Exhaust Port	1.35
5056B	Powerhead Gasket Set MARTIN 20	.81	15036	Gasket—Intake Port Cover	.05
5057	Rod Control Linkage (Refer to 5083)		15037	Cover—Intake Port	.15
5058	Spark Plug and Washer (Refer to 100-s-4)		15038	Stern Bracket Clamping—Left	5.7
5061	Connecting Rod (Refer to 15014)		15039	Stern Bracket Clamping—Right	5.7
5062	Decal—MARTIN "20" (Refer to 5033)		15040	Stern Bracket—Left	3.40
5065	Rear Shroud and Flap Assembly	4.90	15041	Stern Bracket—Right	3.40
5066	Rear Shroud Spray Shield (Refer to 5093)		15045	Swivel Bracket	1.80
5067	Decal—Operating Instructions (Refer to 5034)		15046	Swivel Bearing	.15
5069	Carburetor and Choke Assembly (MD 9A Tillotson)	13.00	15047	Motor Support Tube Casing—Front (Available Only as Assembly—Refer to 15247)	
5070	Gas Tank & Decal Assembly MARTIN 20	17.00	15048	Motor Support Tube Casing—Rear (Available Only as Assembly—Refer to 15247)	
5072	Propeller	3.10	15049	Stern Adjusting Screw and Handle	1.65
5074	Decal—Carburetor	.15	15051	Pin—Stern Adjusting Anchor	.50
5075	Bearing—Lower Main (For Motor Series A1-2-3)	1.42	15052	Clevis Pin—Stern Bracket	.50
5076	Shroud Assembly—Front	4.00	15053	Pin—Tilting Lever	.15
5082	Control Linkage Pivot	.15	15054	Spacer—Tilting Lever	.15
5083	Rod Control Linkage	.10	15055	Tilt Adjusting Lever	.20
5084	Kit—Choke and Prime Assembly	4.25	15056	Thrust Socket	1.25
5088	Magneto Assembly (Wico Model 1883)	29.90	15058	Motor Support Tube Assembly (Refer to 15231)	
5090	Bearing—Lower Main (For Motor Series A-4)	1.42	15066	Propeller Shaft	2.00
5092	Rivet (Refer to 25483)		15067	Pin—Gear and Shaft	.05
5093	Spray Shield	.90	15068	Snap Ring—Bevel Gear	.05
5099	Shut Off Cock	1.65	15069	Bevel Gear (13-20 Ratio)	4.75
5100	Choke Stem Control	.40	15070	Gasket—Propeller Shaft Bearing Housing	.10
5101	Choke Control Assembly	1.10	15072	Pump Plate	.20
5102	Choke Stem and Pin (Refer to 5100)		15073	Pump Rotor	.70
5104	Spark Plug and Washer (Refer to 100-s-4)		15074	Pump Eccentric	1.20
5105	Magneto Assembly (Wico FW-2142) (Refer to 5088)		15075	Water Pump Housing Assembly	2.20
5401	Powerhead (Refer to 5405)		15077	Propeller (Refer to 15206)	
5402	Powerhead—Less Carburetor and Magneto (Refer to 5406)		15078	Friction Clutch	.40

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER—DESCRIPTION—PRICE

Part No.	Description	Price	Part No.	Description	Price
15084	Gas Tank Assembly (Refer to 15198)		15240	Set Screw—Cam Follower (Refer to 9-s-6)	
15086	Shroud—Rear (Refer to 15195)		15247	Motor Support Tube Casing—Front and Rear	8.00
15091	Oil Seal—Crankshaft—Upper	.85	15252	Tank Mounting Bracket—Side	.35
15092	Shut Off Cock	1.75	15254	Water Pump Seal	.05
15093	Cam Follower Pin	.15	15256	“Carter” Carburetor (Refer to 15334)	
15095	Gasket—Motor Support Tube	.20	15258	Exhaust Baffle Plate	.75
15096	Gasket—Grease Vent	.02	15260	Cover—Exhaust Port	1.40
15098	Bracket—Steering Handle (Refer to 15208)		15261	Gasket—Exhaust Port Cover	.16
15099	Compression Block—Handle Bracket	.05	15262	O’Ring—Valve	.25
15100	Grommet—Handle Bracket	.05	15266	O’Ring Valve Assembly	1.20
15101	Stud—Handle Bracket	.10	15267	Gear Set (13-19 Ratio)	7.50
15102	Stabilizer Friction Ring	.20	15268	Bevel Gear (13-19 Ratio—Sold in Sets Only) (Refer to 15267)	
15103	Piston and Wristpin Assembly	4.90	15269	Pinion Gear (13-19 Ratio—Sold in Sets Only) (Refer to 15267)	
15103A	Piston and Wristpin Assembly—.0015 oversize	4.60	15274	Gas Tank & Decal Assembly MARTIN 45	17.00
15105	Bolt—Tilting Pivot	.15	15275	Decal—Operating Instructions	.15
15106	Washer—Tilting Friction	.03	15276	Decal—Side	.15
15109	Cam—Carburetor Control	.20	15277	Gas Line Assembly	1.05
15111	Decal—MARTIN “40”	.15	15279	Shroud Assembly—Front	4.00
15114	Linkage Lever	.45	15284	Tank Mounting Bracket—Left	.40
15118	Rod—Linkage Control	.08	15285	Tank Mounting Bracket—Right	.40
15119	Gear Case and Seal Assembly	9.60	15288	Gasket—Carburetor (Used on “45” motors prior to Serial No. BB 58532)	.08
15120	Intake Manifold	1.40	15291	Handle and Cable Assembly (Tyco)	6.00
15121	Shroud Assembly—Front	4.00	15292	Cylinder Block and Crankcase Assembly	30.00
15127	Gear Set (13-19 Ratio) (Refer to 15267)		15296	(Carter - N752S) Carburetor with Linkage Control (Refer to 15334)	
15128	Gear Set (13-20 Ratio)	8.00	15302	Orifice Plate (For Motors after Serial No. BB 58532) Used with Manifold 15303	.15
15134A	Gasket Set MARTIN 40	1.49	15303	Intake Manifold (For Motors after Serial No. BB 58532) (Used with Orifice Plate 15302)	1.40
15134B	Powerhead Gasket Set MARTIN 40	1.31	15310	Stud Carburetor	.08
15135A	Decal Set (Prior to '49 Model) MARTIN 40	.75	15317	Tank Mounting Bracket Screw	.03
15135B	Decal Set ('49 Model or Later) MARTIN 40	.75	15318	Tank Mounting Locating Screw	.06
15136	Friction Clutch (Refer to 15078)		15322	Shut Off Cock	1.88
15137	Cylinder Block and Crankcase Assembly (Refer to 15191)		15323	Stem—Choke Control	.25
15138	Piston and Wristpin Assembly (Refer to 15103)		15324	Choke Control Assembly	1.00
15142	Powerhead Assembly (Refer to 15400)		15325	Choke Stem and Pin Assembly	.40
15142A	Powerhead—Less Carburetor and Magneto (Refer to 15401)		15326	Cup Washer	.06
15143	Gas Line Assembly	.96	15328	Water Pump Housing	2.20
15145	Lower Unit Assembly (Refer to 15511)		15329	Magneto (FW 2132)	40.25
15146	Gear Case Assembly	24.75	15330	Cylinder Head	4.80
15147	Stern Bracket Assembly	21.50	15331	Propeller Shaft	2.00
15148	Propeller Shaft Bearing Housing and Seal	2.90	15334	(Carter - N2021S) Carburetor with Linkage Control	12.80
15150	Gas Tank Gasket—Lower	1.30	15400	Powerhead Assembly	138.35
15151	Gas Tank Gasket—Upper	.70	15401	Powerhead—Less Carburetor and Magneto	91.85
15152	Clip—Magneto Wire	.02	15402	Piston and Wristpin—.020 Oversize	4.60
15154	Washer—Gear Case Mounting Screw	.05	15403	Piston Ring—.020 Oversize	.50
15155	Water Pump Housing—Flushing Kit	2.20	15409	Decal Set	.75
15156	Flushing Kit Assembly	2.90	15411	Powerhead with Carburetor and Magneto MARTIN 45	138.35
15159	Connecting Rod Screw	.25	15412	Powerhead—Less Carburetor and Magneto MARTIN 45	91.85
15160	Decal—Operating Instructions	.15	15413A	Gasket Set MARTIN 45	1.56
15161	Set Screw—Stern Bracket	.10	15413B	Powerhead Gasket Set MARTIN 45	1.18
15164	Swivel Retaining Screw	.10	15414	Water Pump Housing for flushing kit	2.20
15173	Lower Bearing Seat Casting (Refer to 25904)		15415	Flushing Kit “MARTIN 45” (Serial No. BB 59971 or later)	2.90
15176	Carburetor (MD 8B Tillotson)	12.65	15502	Stern Bracket (Refer to 15147)	
15181	Lower Main Bearing	1.45	15511	Lower Unit Assembly	46.50
15182	Upper Main Bearing	1.48	25000	Gearcase Housing (Refer to 25416)	
15185	Stabilizer Friction Washer (No Longer Used)		25003	Propeller Shaft Bearing Housing Assembly (Refer to 25419)	
15186	Carburetor and Choke Assembly (MD 8B Tillotson)	13.75	25004	Intermediate Housing	9.00
15188	Decal—Rear	.15	25005	Pump Plate	.35
15189	Decal—Speed Control (Refer to 25255)		25009	Water Pump Housing Assembly (Refer to 25155)	
15190	Decal—Operating Instructions (Refer to 15160)		25010	Propeller Shaft	2.65
15191	Cylinder Block and Crankcase Assembly	30.00	25011	Propeller Shaft and Gear Assembly	7.15
15195	Rear Shroud and Spray Shield Assembly	4.90	25012	Pump Eccentric	1.10
15198	Gas Tank & Decal Assembly MARTIN 40	17.00	25013	Driveshaft (Refer to 25290)	
15206	Propeller	3.25	25017	Stud Gearcase and Intermediate Housing Retainer (Rear)	.50
15208	Bracket—Steering Handle	1.96	25018	Stud Gearcase and Intermediate Housing Retainer (Front)	.50
15211	Water Outlet Deflector	.10			
15212	Decal—Carburetor	.15			
15213	Shroud Assembly—Front	4.00			
15214	Gasket—Idle Adjusting Screw Opening	.03			
15223	Valve Assembly	.80			
15224	Kit—Choke and Prime Assembly	4.25			
15226	Tapered Dowel Pin Screw	.10			
15227	Gasket—Grease Vent Screw	.03			
15231	Motor Support Tube Assembly	20.00			
15234	Splash Shield	.88			
15237	Lower Unit Stud	.54			

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER — DESCRIPTION — PRICE

Part No.	Description	Price	Part No.	Description	Price
25020	Motor Support Tube Assembly	12.00	25157	Friction Clutch Assembly	1.15
25023	Pin Stern Adjusting Arm Clevis	.55	25158	Stud—Thrust Socket Fastener (Refer to 25334)	
25027	Bearing—Swivel	.15	25159	Propeller (Refer to 25614)	
25029	Thrust Socket (Refer to 25860)		25166	Spring—Valve	.10
25030	Motor Support Tube Casing—(Available Only as Complete Assembly 25682)		25170	Cam Follower Spacer Washer	.02
25031	Cylinder Head Cover	.75	25173	Pivot Bolt Cover	.20
25032	Lever Stern Adjusting Tilting	.32	25176	Starter Housing	6.00
25033	Key Reverse Stop	.03	25177	Lid—Filler Cap (Refer to 25407)	
25036	Swivel Bracket	1.80	25178	Steering Handle Bracket (Refer to 25613)	
25039	Tube—Drive Shaft Seal Extension	1.50	25179	Steering Handle (Refer to 25612)	
25040	Cylinder Head	4.60	25180	Mounting Bracket—Gas Tank—Rear	1.00
25043	Motor Support Tube Casing Assembly—Rear (Available only as Complete Assembly—Refer to 25682)		25181	Speed Control Knob (Refer to 25611)	
25045	Spacer—Stern Adjusting Arm Thrust Socket	.18	25182	Bearing—Lower Main	1.45
25046	Thrust Washer—Motor Support Tube	.05	25183	Bearing—Upper Main (Refer to 25185)	
25047	Gasket—Exhaust Port Cover Plate	.25	25184	Bearing—Lower Main (Refer to 25182)	
25048	Exhaust Port Cover	1.45	25185	Bearing—Upper Main	1.50
25049	Plate Exhaust Port Cover	.60	25187	Gasket—Cylinder Compression	.20
25051	Cam Follower	.85	25188	Tank Seal (Refer to 25909)	
25052	Stern Bracket—Left	4.00 3.00	25189	Water Seal Gasket	.25
25053	Stern Bracket—Right	4.00 3.00	25191	Gasket—Spark Plug	.02
25054	Pinion Gear (13-20 Ratio)	5.00 3.00	25195	Pin—Cam Follower	.15
25055	Bevel Gear	4.50	25197	Stud—Carburetor	.05
25061	Pressure Pad—Clamp Screw	.10	25198	Gasket—Intake Manifold	.05
25064	Lockspring—Wristpin	.05	25199	Gasket—Carburetor	.05
25065	Gasket—Intake Port	.05	25200	Gasket—Exhaust Port Plate	.25
25070	Stud—Tilting	.30	25202	Mounting Bracket—Gas Tank—Side (Refer to 25672)	
25071	Water Seal (C1-and-C2)	.06	25203	Carburetor Assembly (Tillotson MD 5A)	12.65
25073	Water Inlet Tube Assembly (C1 and C2)	.75	25205	Speed Control Lever	.20
25074	Motor Support Tube Gasket	.25	25206	Starter Handle Plug Assembly	.60
25076	Intake Port Cover	.15	25207	Shear Pin Support Bracket	.10
25077	Connecting Rod Assembly—(Used on C1 "60" Motors) (Refer to 25354)	4.30	25208	Filler Cap Latch (Grey)	.50
25082	Gasket—Seal Retainer	.10	25209	Air Vent Bushing	.15
25084	Pin—Pump Eccentric	.01	25210	Air Vent Screw	.15
25085	Propeller Nut	.50	25213	Small Set Screw—Carburetor Control Knob	.02
25087	Gasket—Propeller Shaft Bearing Housing	.10	25215	Carburetor Link Control Assembly (MD 15B Tillotson)	13.75
25088	Crankshaft—(Used on C1 "60" Only) (Refer to 25353)		25217	Decal—MARTIN "60" (Refer to 25258)	
25089	Pump Rotor	.84	25218	Screw—Shroud Mounting	.05
25090	Snap Ring—Water Pump	.05	25219	Spray Shield Assembly	1.10
25093	Water Seal—Pump Housing and Gearcase	.05	25220	Stabilizer Compression Block	.05
25095	Gasket—Cylinder Head Cover	.10	25221	Stabilizer Compression Plate	.05
25096	Bolt—Starter Pivot	1.10	25222	Seal—Water Outlet Deflector (Refer to 25905)	
25098	Pawl Retainer Spacer	.03	25223	Piston Ring	.40
25103	Spring—Starter Rewind	1.10	25224	Dowel Pin	.03
25104	Hook—Starter Rope	.10	25225	Bolt—Steering Handle Bracket	.05
25107	Spring—Starter Compression	.08	25226	Grommet—Steering Handle	.10
25109	Anchor—Starter Spring	.40	25227	Pressure Pad—Steering Handle Bracket	.10
25113	Ratchet Ring—Starter	.90	25228	Washer—Steering Handle Bracket	.02
25114	Cylinder Block and Crankcase Assembly (Refer to 25908)		25233	Control Linkage Rod	.15
25121	Pawl Retainer Assembly	1.75	25235	Control Linkage Spring	.03
25124	Plug—Starter Handle (Refer to 25206)		25236	Pivot—Control Linkage	.05
25125	Starter Handle	.30	25239	Grip—Steering Handle (Refer to 25342)	
25126	Starter Cord Assembly (Refer to 25251)		25240	Screw—Cam Follower Pin (Refer to 9-s-6)	
25127	Starter Pulley Assembly	2.65	25243	Stabilizer Friction Washer	.20
25129	Washer—Fixed Contact Clamp Screw (Refer to 2965F)		25244	Bias Spring—Starter	.20
25130	Screw—Fixed Contact Clamp (Refer to 5431F)		25245	Grease Plug	.05
25131	Shoe Mounting Screw (Refer to 5431F)		25248	Valve Assembly (Refer to 25642)	
25139	Seal Assembly (Refer to 25905)		25249	Shut Off Cock (Used on "60" Model Prior to Serial No. C-64817)	1.50
25140	Stern Adjusting Screw and Handle Assembly	1.55	25251	Starter Cord and Handle Assembly	2.20
25141	Pin—Stern Adjusting Anchor	.55	25254	Gas Line Fitting Screen	.75
25142	Spacer—Stern Bracket	.15	25255	Decal—Speed Control	.15
25143	Stud—Tilt Adjusting Lever (Refer to 25333)		25256	Decal—Operating Instructions (Refer to 25370)	
25145	Clamp Screw and Handle Assembly	.65	25257	Decal—Carburetor	.15
25146	Stern Bracket and Clamp Screw Assembly—Right	6.25 4.00	25258	Decal—Side	.15
25147	Stern Bracket and Clamp Screw Assembly—Left	6.25 4.00	25259	Decal—Rear	.15
25150	Stabilizer Friction Ring	.20	25262	Gas Line Assembly	1.10
25154	Pins—Journal Bearing Location	.01	25266	Oil Seal—Crankshaft—Upper	.80
25155	Water Pump Housing Assembly	2.20	25267	Gasket—Grease Vent	.02
25156	Shear Pin	.02	25268	Gasket—Grease Plug	.02
			25269	Washer—Starter Pivot Bolt	.02
			25270	Carburetor Control Cable Assembly NOT AVAILABLE	.80
			25271	Retainer—Filler Cap	.10
			25273	Spring Washer	.10
			25275	Shut Off Cock	1.65

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER—DESCRIPTION—PRICE

Part No.	Description	Price	Part No.	Description	Price
25276	Filler Cap Assembly (Grey)	2.75	25411	Knob Assembly—Carburetor Shut Off with Screw	.30
25278	Tension Spring—Filler Cap (Refer to 25609)		25413	Stern Bracket Assembly	24.00
25281	Swivel Locking Pin Assembly	.25	25414	Lower Unit Assembly (Refer to 25518)	
25284	Swivel Retainer Screw	.08	25415	Gearcase Assembly	33.50 30.00
25286	Washer—Tilting Friction	.05	25416	Gearcase Housing	11.50
25287	Friction Washer—Steering Handle	.02	25417	Propeller Shaft and Gear	15.00 10.00
25290	Driveshaft	3.50	25418	Gear Set (Ring and Pinion)	10.00 8.00
25292	Piston and Wristpin Assembly	4.75	25419	Propeller Shaft Bearing Housing	2.85
25292A	Piston and Wristpin Assembly—.0015 Oversize	4.50	25422	Seal—Lower Main Bearing (Refer to 25904)	
25292B	Piston and Wristpin Assembly—.003 Oversize	4.50	25423	Ring—Lower Main Seal	.24
25292C	Piston and Wristpin Assembly—.030 Oversize	4.50	25428	Tube—Driveshaft Seal	1.35
25293	Gasket—Lower Seal	.10	25429	Tube Seal Spacer	.05
25294	Magneto—(Wico - FW-1740B)	40.25	25449	Air Vent Screw Pad	.05
25295	Seal—Lower Main Bearing (Refer to 25904)		25453	Arm—Choke Control	.05
25296	Water Inlet Tube	.90	25454	Choke Control Linkage	.05
25297	Washer—Water Tube	.02	25455	Bracket—Choke Control	.16
25298	Cam Spacer—(Wico Magneto)	.03	25459	Seal—Gearcase Grease	.05
25300	Carburetor (MD 15A Tillotson)	12.65	25461	Spacer—Driveshaft Seal	.05
25301	Extension Drive Shaft	4.70	25465A	Driveshaft Seal Assembly	3.95
25302	Stud—Lower Unit Extension—Short	.55	25465B	Driveshaft Seal Assembly—Extension	3.95
25303	Stud—Lower Unit Extension—Long	.55	25468	Set Screw—Carburetor Control Knob (Refer to 25359)	
25304	Water Inlet Tube Extension (C-1)	1.10	25483	Rivet	.05
25307	Lower Unit Extension Kit (C-1 and C-2)	11.65	25486	Carburetor (MD 15B Tillotson)	12.65
25308	Shim Extension—Intermediate Housing	4.75	25487	Carburetor Control Knob	.60
25310	Magneto—(Scintilla)	25.00	25501	Starter and Cover Assembly (Grey) (Prior to '49 Model)	19.80
25311	Flywheel and Cam Assembly (Scintilla)	10.00	25502	Powerhead (Refer to 25618)	
25314	Adaptor—(Scintilla)	1.50	25503	Stern Bracket Assembly (Refer to 25413)	
25315	Cam Spring Washer (Refer to 3081F)		25518	Lower Unit Assembly	45.50
25316	Lower Unit Extension Kit (C-3 and C-4)	11.65	25550	Steering Handle and Bracket Assembly	24.00
25317	Water Inlet Tube—(C-3 Extension)	1.10	25600	Gas Tank & Decal Assembly MARTIN 60	21.00
25321	Idle Adjusting Screw (Refer to 08427)		25601	Starter Housing (Black) (Refer to 25650)	
25324A	Gasket Set (C-1 and C-2)	1.78	25603	Filler Cap Latch (Black) (Refer to 25652)	
25324B	Powerhead Gasket Set (C-1 and C-2)	1.64	25604	Filler Cap Assembly (Refer to 25910)	
25325A	Gasket Set (C-3 and C-4)	1.80	25605	Spark Plug Nipple	.30 *
25325B	Powerhead Gasket Set (C-3 and C-4)	1.64	25609	Tension Spring Filler Cap	.05
25326A	Decal Set (Prior to '49 Model) MARTIN 60	.75	25611	Speed Control Knob	.75
25326B	Decal Set (After '49 Model) MARTIN 60	.75	25612	Steering Handle	1.75
25327	Friction Clutch Assembly (Refer to 25157)		25613	Steering Handle Bracket	2.00
25333	Stud—Tilt Adjusting Lever	.30	25614	Propeller	3.00 2.00
25334	Stud—Thrust Socket	.15	25616	Shroud—Rear	3.85
25337	Grease Fitting	.12	25617	Swivel Retaining Screw	.18
25338	Recoil Starter Spring Spacer	.10	25618	Powerhead Complete MARTIN 60-66	147.15
25339	Compression Nut	.10	25619	Starter and Cover Assembly (Refer to 26012)	
25340	Compression Sleeve	.03	25620	Powerhead—Less Carburetor and Magneto MARTIN 60 - 66	100.65
25341	Choke Control Assembly	1.00	25623	Shroud Assembly—Front	4.40
25342	Grip—Steering Handle	.35	25624	Filler Cap (Black) ('49 Model and Later)	1.25
25344	Connecting Rod Screw	.24	25637	Motor Support Tube Casing—Front (Refer to 25682)	
25353	Crankshaft	22.00	25640	Cam Follower Pin Screw	.15
25354	Connecting Rod Assembly	14.00 10.00	25641	Cam Follower	.75
25359	Set Screw—Carburetor Control Knob	.02	25642	Valve Assembly	.90
25364	Choke Stem and Pin Assembly (Refer to 25341)		25644	Choke Shaft and Primer	.77
25366	Flushing Kit Plug	.12	25650	Starter Housing (Black) ('49 Model and Later)	5.50
25367	Nozzle—Flushing Kit (Refer to 25686)		25652	Filler Cap Latch ('49 Model and Later)	.50
25368	Water Pump Housing—Flushing Kit	2.20	25672	Mounting Bracket—Side	.50
25369	Flushing Kit Assembly	3.00	25682	Motor Support Tube Casing—Front and Rear	10.20
25370	Decal—Operating Instructions	.15	25683	Screw Plug—Flusing Kit	.50
25378	Grease Plug—Large	.12	25684	Fiber Washer—Flushing Kit	.02
25379	Gasket—Grease Plug	.02	25685	Coupling—Flushing Kit	.35
25400	Cylinder Block and Crankcase Assembly (Refer to 25908)		25686	Flushing Plug Kit	.94
25401	Piston and Wristpin Assembly (Refer to 25292)		25688	Piston Ring—.030 Oversize	.40
25401A	Piston and Wristpin Assembly (Refer to 25292A)		25691A	Stainless Steel Water Inlet Tube (C-3 and C-4)	1.50
25401B	Piston and Wristpin Assembly (Refer to 25292B)		25691B	Stainless Steel Water Inlet Tube—Extension	2.00
25402	Key—Magneto	.10	25695	Gearcase Seal	.15
25403	Intake Manifold Assembly	1.30	25698	Carburetor—Carter N-753S	10.80
25404	Collar Assembly—Control Linkage	.25	25699	Tank Seal (Refer to 25909)	
25405	Powerhead Assembly (Refer to 25618)		25700	Propeller Nut—Brass	1.00
25406	Starter Cord and Anchor Assembly	1.40	25741A	Stainless Steel Water Tube (C-1 and C-2)	1.50
25407	Filler Cap (Grey) (Prior to '49 Model)	1.25	25741B	Stainless Steel Water Tube—Extension (C-1 and C-2)	2.00
25408	Gas Tank Assembly (Refer to 25600)		25742	Carburetor with Linkage and Choke Control (Carter N753S)	12.80
25409	Shroud Assembly—Front	3.85			
25410	Knob Assembly—Carburetor Control with Screw	.35			

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER—DESCRIPTION—PRICE

Part No.	Description	Price	Part No.	Description	Price
25743	Elbow Fitting60	25910	Filler Cap Assembly	2.75
25744	Shut Off Cock	1.70	25919	Intake Manifold Assembly	1.40
25745	Choke Control Assembly90	25920	Cam—Carburetor Control20
25746	Bracket—Choke Control20	25921	Cam—Carburetor Control20
25747	Choke Pin and Stem Assembly30	25924	Sleeve—Starting Housing04
25749	Decal—Operating Instructions15	25925	Spring Washer10
25750	Shroud Assembly—Front	4.40	25926	Adjusting Screw—Clutch Lever (Refer to 25878)10
25751	Decal—Carburetor Control15	25927	Motor Support Tube Casing Assembly	10.60
25752	Gas Line Assembly85	25930	Locknut—Cable Adjusting Screw03
25755	O'Ring Valve ('49 Model and Later)	1.25	25931	Spacer—Tank Seal05
25759	Bevel Gear (13-19 Ratio)	3.85	25936	Water Pump Gasket (Refer to 55714 and 55715)03
25760	Pinion Gear (13-19 Ratio)	2.75	25945	Snap Ring03
25762	Cam Follower Pin Insert Bushing35	25946	Screw—Rear Tank Bracket Locating05
25765	Propeller Shaft and Gear Assembly	6.60	25948	Swivel Retaining Screw14
25767	Gas Tank & Decal Assembly MARTIN 66	21.00	25949	Water Inlet Tube	1.10
25768	Decal—MARTIN "66"15	25952	Magneto (Wico FW-2141)	40.25
25771	Handle and Cable Assembly (Tyco)	6.00	25955	Carburetor (Carter N-2022S)	10.80
25778	Tank Mounting Bracket—Intake Side70	25956	Carburetor with Linkage and Choke Control Assembly (Carter N-2022S)	12.80
25787	Decal Set MARTIN 6675	26000	Decal Set—75 Syncro Twist75
25790	Gear Set (13-19 Ratio)	6.60	26002	Lower Unit Assembly	98.00
25794	Gas Tank & Decal Assembly MARTIN 75 S.T.	21.00	26003	Gearcase Assembly	42.00
25796	Decal—MARTIN "75"15	26004	Gearcase Housing Assembly	14.20
25797	Cam—Carburetor Control20	26006	Intermediate Housing—Lower	12.50
25799	Decal—Rear15	26007	Bearing Plate (Refer to 26033)12.60
25807	Lever—Throttle Control10	26008	Motor Support Tube Assembly	18.00
25810	Guide Screw—Steering Handle04	26009	Steering Handle Assembly	18.00
25814	Bracket—Steering Handle	4.95	26010	"75" Twist Shift Powerhead Assembly Complete	147.15
25815	Handle—Steering	4.60	26011	"75" Twist Shift Powerhead—Less Carburetor and Magneto	100.65
25827	Decal—Rear15	26012	Starter and Cover Assembly	19.80
25828	Shroud Assembly—Front	4.30	26013	Filler Cap Assembly	2.75
25836	Bracket—Cable Support20	26014	Stern Bracket Assembly	24.00
25838	Spring—Clutch Lever10	26016	Powerhead Assembly, Complete "75" Syncro Twist	147.15
25840	Plug—Steering Handle45	26017	Powerhead—Less Carburetor and Magneto "75" Syncro Twist	100.65
25841	Locknut—Cable Adjusting Screw02	26018A	Gasket Set MARTIN 75 Twist Shift	2.41
25842	Tube Assembly—Clutch Control	5.30	26018B	Powerhead Gasket Set MARTIN 75 Twist Shift, Syncro Twist	1.76
25843	Cover Plate—Steering Handle60	26019	Decal Set MARTIN 75 Twist Shift75
25845	Button and Rod Assembly	1.35	26020	Cylinder Block and Crankcase	33.00
25846	Collar Assembly35	26021	Steering Handle Sub Assembly	9.90
25848	Spring—Throttle Control02	26032	Motor Support Tube Assembly (Refer to 26008)6.50
25849	Eccentric Assembly55	26033	Driveshaft Bearing Plate6.50
25852	Orifice Plate—Carburetor06	55000	Cylinder Block and Crankcase Assembly (Refer to 55608)70
25854	Spacer Tank Seal (Refer to 25931)4.90	55001	Cam Follower—Lower70
25856	Upper Driveshaft	1.20	55002	Cam Follower—Upper	8.60
25857	Tube—Driveshaft Enclosure	1.20	55003	Cylinder Head40
25859	Reversing Lock10	55011	Piston Ring	4.90
25860	Thrust Socket	1.20	55013	Piston and Wristpin Assembly	10.20
25861	Tube Neutral Cable (Refer to 25878)55	55015	Connecting Rod and Cap Assembly (Includes Needles)	30.00
25862	Bracket—Tube Support2.38	55016	Spring—Magneto Cam (Refer to 55185)	43.15
25863	Water Inlet Tube (Refer to 25949)25	55018	Crankshaft	7.40
25867	Motor Support Tube Assembly (Refer to 26008)8.40	55019	Magneto (Wico FW-1927)	2.75
25869	Neutral Clutch Lever25	55020	Upper Main Bearing—Orange08
25870	Seal Assembly—Lower Main Bearing24	55021	Lower Main Bearing—Torrington06
25871	Upper Cable Assembly (Refer to 25907)20	55022	Pin—Bearing Locating	1.75
25874	Gasket—Motor Support Tube30	55024	Gasket—Intake Manifold01
25875	Propeller	3.85	55025	Intake Manifold75
25876	Decal—Speed Control15	55026	Spacer—Cam Follower03
25877	Gas Tank & Decal Assembly MARTIN 75 T.S.	21.00	55027	Spark Plug Insulator70
25878	Control Cable, Boot and Tube	3.85	55028	Spark Plug and Washer (Refer to 100-s-4)25
25880	Filler Cap (Refer to 26013)8.40	55029	Main Bearing Seal20
25885	Torque Tube Assembly25	55030	Reed Seal35
25886	Gear and Shaft Pin24	55031	Cam Follower Pin10
25887	O'Ring—Enclosure Tube20	55032	Gasket—Exhaust Port Cover10
25888	Bracket—Throttle Control33.00	55033	Exhaust Port Cover Plate10
25889	Cable Clamp—No Longer Used06	55034	Taper Dowel Screw	1.40
25890	Clamp—Cable Nut—No Longer Used	1.90	55035	Exhaust Port Cover03
25893	Cylinder Block and Crankcase Assembly15			
25896	Cap—Grommet Retainer10			
25897	Throttle Control Cable	1.75			
25898	Spring—Neutral Lever Return2.75			
25903	Gasket—Lower Main Bearing Seal05			
25904	Seal—Lower Main Bearing	2.75			
25905	Seal Assembly—Lower Main Bearing05			
25906	Grommet—Water Tube	2.75			
25907	Upper Cable Assembly	33.00 [†]			
25908	Cylinder Block and Crankcase Assembly40			
25909	Tank Seal40			

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER—DESCRIPTION—PRICE

Part No.	Description	Price	Part No.	Description	Price
55036	Gasket—Intake Port Cover	.06	55147	Grommet Cap	.04
55037	Intake Port Cover	1.10	55148	Clamp—Flexible Vent Tube	.05
55038	Gasket—Lower Main Cap	.10	55149	Grommet—Throttle Control	.10
55039	Cap—Lower Main	.20	55151	Tab—Pawl Friction	.12
55040	Stern Bracket—Right	4.40	55152	Spring—Starter Pawl	.04
55041	Stern Bracket—Left	4.40	55153	Pawl Starter	.45
55043	Upper Seal—Water Tube	.10	55154	Starter Pulley	5.50
55045	Gasket—Motor Support Tube	.25	55156	Spring—Starter Rewind	1.75
55046	Stabilizer Friction Ring (Refer to 55296)		55157	Starter Pulley Liner—No Longer Used	.35
55047	Motor Support Tube Casing (Refer to 55295)		55158	Starter Rope Assembly	1.80
55049	Stern Adjusting Screw and Handle	1.50	55161	Plate—Pawl Friction	.88
55050	Carburetor (Carter N754SA)	10.80	55162	Bearing—Starter Pivot	1.30
55051	Pin—Stern Adjusting Anchor	.80	55163	Plate—Rewind Spring Anchor	.50
55052	Adapter—Safety Chain	.06	55164	Spring—Access Cover	.10
55053	Bolt—Stern Bracket	.45	55165	Spring—Anchor Plate	.16
55054	Bolt—Thrust Socket	.30	55166	Pivot Pin—Access Cover	.05
55055	Tilt Adjusting Lever	.45	55167	Retaining Ring	.06
55056	Thrust Socket	1.65	55174	Pulley—Emergency Starter	.60
55057	Intermediate Housing	11.40	55175	Ratchet—Starter	2.50
55058	Motor Support Tube Assembly (Refer to 55639)		55176	Starter Housing (Refer to 55461)	
55060	Reversing Lock	.12	55179	Decal—Maintenance Instructions	.15
55061	Ball Bearing—Propeller Shaft	3.30	55180	Access Cover Sub Assembly	3.00
55062	Water Inlet Tube	.80	55181	Carburetor Control Knob	.75
55063	Pin—Gear and Propeller Shaft	.06	55182	Ring—Steering Handle Retainer	.10
55064	Water Pump Housing Assembly	2.00	55183	Grommet—Shut Off Cock	.08
55067	Lower Unit—Long Stud	.45	55185	Spring—Magneto Cam	.06
55068	Lower Unit—Short Stud	.24	55186	Water Pump Seal	.05
55069	Pump Rotor (Refer to 55476)		55187	Oil Seal—Propeller Shaft	1.00
55071	Pin—Pump Rotor	.05	55188	Pump Plate	.26
55072	Propeller Shaft	6.70	55189	Gasket—Propeller Shaft Bearing Housing	.10
55073	Zerol Bevel Gear	4.80	55190	Washer—Driveshaft Enclosure Tube Seal	.06
55074	Zerol Bevel Pinion	4.40	55193	Bolt—Pinion to Driveshaft	.20
55076	Tube—Driveshaft Enclosure	1.10	55195	Stud—Crankcase to Block	.10
55078	Driveshaft	3.50	55196	Stud—Cylinder Head (Refer to 10-s-12)	
55080	Bearing—Driveshaft	2.75 2.75	55197	Stud—Manifold to Case	.10
55081	Lower Seal—Water Tube	.02	55198	Stud—Carburetor	.10
55082	Needle Bearing—Driveshaft	.80	55199	Gasket—Carburetor	.06
55089	Instruction Plate	.50	55200	Valve and O'Ring Assembly	1.90
55090	Bolt—Bracket Mounting	.18	55204	O'Ring—Valve	.25
55091	Bolt—Rear Tank Mounting (Refer to 55090)		55205	Valve Spring	.15
55105	Gas Line Fitting	.98	55206	Pad—Reed Mounting	.45
55106	Gas Line and Fitting Assembly	2.30	55207	Reed—Bleed System	.08
55108	Cable—Vent Seal Control	1.30	55208	Stop—Bleed System—Reed	.06
55109	Collar—Flexible Vent Cable	.20	55209	Gasket—Reed Mounting Pad	.05
55110	Speed Control Lever	.50	55210	Nut—Bleed System	.05
55111	Link—Speed Control	.15	55211	Tube—Upper Cylinder Bleed	.24
55112	Stator Lever	.20	55212	Tube—Lower Cylinder Bleed	.15
55113	Pivot—Speed Control Lever	.15	55213	Compression Sleeve	.01
55114	Hinge Pin—Speed Control Lever	.10	55214	Cam—Carburetor	.20
55115	Wave Washer—Speed Control Lever	.01	55215	Key—Magneto	.10
55116	Speed Control Knob	2.50	55216	Marker—Lead Wire (Refer to 5925F)	
55118	Vent Tube—Upper—No Longer Used		55217	Flap—Rear Shroud	.40
55121	Sleeve—Speed Control Lever (Refer to 25924)		55218	Main Spring—Shroud Fastener	.10
55122	Spring—Choke Control	.04	55219	Choke Control Rod Assembly	.40
55123	Spring Air Vent—No Longer Used		55221	Hair Pin Cotter—Choke Control Rod	.01
55125	Bracket—Steering Handle (Refer to 55361)		55222	Lever—Choke Rod	.05
55126	Handle—Steering	4.60	55223	Choke Bracket Assembly	.10
55127	Bushing—Steering Handle	.18	55224	Carburetor Bracket	.15
55128	Grip—Steering Handle	.35	55225	Intermediate Lever	.03
55129	Button Throttle Control	.42	55227	Carburetor Link	.03
55130	Rod—Throttle Control	.35	55228	Link—Control Rod	.10
55131	Spring—Throttle Control	.06	55230	Vent Tube Spring	.25
55132	Throttle Control Lever Assembly	.34	55231	Seal—Vent Tube—No Longer Used	
55134	Ring—Steering Handle Retaining (Refer to 55182)		55232	Adapter Fitting—Shut Off Cock	.30
55135	Inner Washer—Steering Handle	.10	55233	Gasket—Cap Seal Clutch Shaft	.05
55136	Outer Washer—Steering Handle	.20	55234	Gas Tank & Decal Assy. MARTIN 100 Stand.	26.00
55137	Screw—Throttle Control Lever	.06	55235	Decal—Rear	.15
55138	Cable—Throttle Control	2.00	55236	Fuel Gauge (Refer to 55290)	
55139	Clip—Throttle Control	.05	55237	Screw—Fuel Gauge	.15
55141	Shoe Spring—Throttle Control	.05	55238	Gasket—Fuel Gauge—Rear	.05
55142	Pin—Throttle Control Bracket	.15	55239	Gasket—Fuel Gauge—Rear (Refer to 55238)	
55143	Disc—Throttle Control Grommet	.05	55241	Clip—Wrench	.10
55144	Ring—Throttle Control Button	.22	55242	Fuel Cap Assembly	2.00
55145	Screw—Friction Shoe	.03	55246	Gasket—Fuel Cap (Part of Assembly 55242)	.05
55146	Cover Plate—Steering Handle	.30	55248	Chain—Fuel Cap (Refer to 55359)	
			55249	Stop—Fuel Cap	.10
			55250	Front Shroud Sub-Assembly	4.90

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER—DESCRIPTION—PRICE

Part No.	Description	Price	Part No.	Description	Price
55251	Stud—Shroud Fastener	.20	55390	Spring—Clutch	.08
55252	Cross Pin—Shroud Fastener	.05	55391	Decal—Start and Shift	.15
55253	Rear Shroud Sub Assembly	7.50	55392	Clutch Plate	.06
55254	Centering Disc	2.40	55393	Pin—Clutch Plate Driver	.08
55255	Clutch Plate	.12	55394	Clutch Plate and Disc Assembly	2.20
55256	Clutch Disc	.12	55395	Clutch Disc	.08
55257	Clutch Spring	.15	55399	Driver—Clutch Plate	2.75
55258	Propeller Spring Shield <i>not available</i>	.25	55400	Snap Ring—Clutch Driver	.03
55259	Propeller Nut	.65	55401	Seal Neutral Cable Tube	.02
55260	Propeller	5.50	55405	Zerol Bevel Gear Assembly	6.00
55261	Shut Off Cock	1.80	55408	Bushing	.15
55262	Clutch Plate and Disc Assembly	3.50	55411	Cylinder Block and Case Assembly (Refer to 55678)	.05
55263	Pinion Thrust Washer	.30	55412	Gasket—Clutch Lever Bracket	1.00
55264	Wrench	.25	55414	Carburetor Cam Assembly	.01
55265	Shim—Gear Bearing	.05	55415	Washer—Pivot Screw	.10
55266	Seal—Upper Driveshaft Enclosure Tube	.72	55418	Neutral Lever Return Spring	4.95
55267	Lower Seal—Driveshaft Enclosure Tube	.10	55419	Propeller Shaft	.05
55272	Seal Ring—Fuel Cap	.15	55420	Air Vent Screw (Refer to 55487)	.05
55273	Fuel Cap	2.30	55421	Washer—Air Vent Seal	.05
55275	Pin—Fuel Cap Chain	.04	55422	Chain Retainer—Fuel Cap	.03
55276	Fuel Cap Assembly (Refer to 55431)	.25	55423	Friction Spring—Air Vent	.05
55287	Washer and O'Ring—Fuel Gauge	3.30	55424	Drive Pin	3.40
55290	Gas Gauge—Metal	.75	55431	Access Cover Sub Assembly (Refer to 55180)	13.50
55292	Fuel Gauge—Tube	.10	55435	Bracket Assembly	26.00
55293	Fuel Gauge—Tube Seal	1.00	55440	Gas Tank & Decal Assembly MARTIN 100 T.S.	-.02
55294	Bleed Valve Assembly	7.80	55441	Washer—Bearing	.30
55295	Motor Support Tube Casing	1.30	55442	Stud—Lower Unit (Short)	2.40
55296	Stabilizer Friction Ring	10.20	55443	Bearing Plate and Bracket (Refer to 26033)	.10
55300	Upper Intermediate Housing	2.70	55445	Upper Cable Assembly	.10
55301	Water Pump Housing (Refer to 55712)	.15	55446	Dowel—Block and Case	.05
55306	Bracket—Clutch Lever	.25	55447	Cap—Sealing Nut	.25
55307	Pin—Clutch Lever	2.00	55448	Sealing Nut Assembly	.04
55308	Clutching Lever	1.35	55450	Washer Clutch Spring	.15
55309	Clutch Spring	2.35	55453	Decal—Neutral	.75
55310	Rotor—Water Pump	.03	55456	Cap—Lower Main Bearing	11.10
55312	Clutch Bushing	3.50	55461	Starter Housing	.02
55313	Pin—Pump Rotor	.01	55474	Spring—Clutch Control Detent	2.00
55314	Driveshaft—Lower	4.50	55475	Gasket—Exhaust Port Cover (Refer to 55032)	.10
55316	Key—Driveshaft	.18	55476	Rotor—Water Pump	.03
55319	Upper Driveshaft	.12	55479	Grommet—Clutch Cable (Refer to 55445)	.10
55320	O'Ring—Water Tube	.50	55482	Plate—Clutch Driver	.03
55321	Fitting—Clutch Shaft	.34	55483	Water Pump Seal	.50
55322	Shaft—Clutch Lever Actuating	.05	55487	Air Vent Screw	.04
55323	Cover Plate—Water Pump (Refer to 55713)	.16	55489	Clip—Drive Pin	.05
55324	Stud—Lower Unit	.96	55493	Rivet—Speed Control Lever	114.00
55325	Snap Ring	.10	55503	Lower Unit Assembly	24.00
55327	Access Cover	.10	55504	Stern Bracket Assembly	Powerhead—Less Carburetor and Magneto (Refer to 55611)
55328	Driveshaft Enclosure Tube	.15	55505	Powerhead—Less Carburetor and Magneto (Refer to 55611)	23.00
55329	Boot for Clutch Mechanism	.10	55506	Starter and Cover Assembly	13.20
55330	Gasket—Gearcase	.10	55507	Throttle Control Assembly	12.80
55332	Gasket—Bearing Plate	.15	55509	Carter Carburetor and Linkage Control	23.75
55333	Gasket—Propeller Shaft Bearing Housing Assembly	.10	55510	Steering Handle and Bracket Assembly	24.00
55339	Cap Seal—Clutch Shaft	.20	55512	Stern Bracket Assembly	24.00
55341	O'Ring	.15	55517	Powerhead (Refer to 55636)	24.00
55344	Neutral Clutch Lever Assembly	.85	55521	Starter and Cover Assembly (Refer to 55506)	.30
55347	Bracket—Cable Support	.35	55600	Decal Set (MARTIN 100 Std.)	1.50
55348	Bracket—Tube Support	.30	55602A	Gasket Set (MARTIN 100 Std.)	1.34
55352	Water Inlet Tube (Refer to 55729)	.04	55602B	Powerhead Gasket Set (MARTIN 100 Std.—T.S.)	3.30
55354	Spring—Declutching	1.40	55603	Flushing Kit (MARTIN 100 Std.)	2.40
55358	Upper Cable Assembly—Clutch Control	.08	55604	Flushing Kit—Pump Housing	13.50
55359	Chain—Fuel Cap	4.10	55605	Gearcase Assembly	12.75
55361	Steering Handle Bracket	4.60	55606	Tank Bracket	10.00
55362	Propeller (Standard)	.15	55607	Gearcase Housing	40.00
55366	Rear Decal	4.30	55608	Cylinder Block and Crankcase Assembly	3.60
55367	Propeller Shaft Bearing Housing and Seal Assembly	4.60	55609	Starter Cord and Handle Assembly (Refer to 55640)	145.75
55368	Water Pump Housing Assembly (Refer to 55712)	4.60	55610	Propeller Shaft Bearing Housing	19.80
55369	Control Cable, Boot and Tube Assembly	6.60	55611	Powerhead—Less Carburetor and Magneto (MARTIN 100 Std.)	15.40
55371	Clutch Spring and Bushing Assembly	.60	55612	Starter Housing and Access Cover (Refer to 55461)	19.80
55379	Spark Plug and Washer (Refer to 100-s-4)	.05	55613	Propeller Shaft Bearing and Gear	15.40
55380	Thrust Collar	.02	55614	Propeller Shaft Assembly	.24
55381	Pin—Thrust Collar	.06			
55382	Snap Ring—Thrust Collar Pin	.06			
55388	Gasket—Access Cover	.24			
55389	Thrust Washer—Clutch Bushing	.24			

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER — DESCRIPTION — PRICE

Part No.	Description	Price	Part No.	Description	Price
55615	Rod and Button Assembly	1.25	65058	Gasket—Intake Manifold	.10
55616	Stern Bracket—Right	5.50	65060	Gasket—Carburetor	.05
55617	Stern Bracket—Left	5.50	65062	Tube—Oiling System	.30
55632	Gear Set (Ring and Pinion)	10.80	65066	Ring—Resilient Co-Pilot	.30
55635A	Gasket Set (MARTIN 100 Std.)	1.94	65067	Adjusting Plate—Co-Pilot	.05
55635B	Powerhead Gasket Set (Refer to 55602B)		65069	Connecting Rod	13.10
55636	Powerhead Assembly—Complete (MARTIN 100 T.S.)	199.65	65071	Control Panel Assembly	4.50
55637	Powerhead—Less Carburetor and Magneto (MARTIN 100 T.S.)	145.75	65072	Stud—Lower Unit	.55
55638	Steering Handle Assembly	18.00	65073	Friction Quadrant	1.50
55639	Motor Support Tube Assembly	13.70	65077	Needle Bearing Driveshaft	.90
55640	Starter Cord and Handle Assembly	2.75	65079	Bolt—Pinion to Driveshaft	.35
55641	Lower Unit Assembly (Refer to 55503)		65106	Spacer—Tilt Adjusting Lever	.35
55642	Adapter	1.10	65108	O'Ring Water Pump Cover Plate	.30
55643	Flushing Kit (MARTIN 75 T.S. and 100 T.S.)	1.52	65111	Lower Rubber Bushing	.44
55656	Upper Driveshaft—(5" Extension)	5.00	65112	Lower Rubber Bushing Liner	.44
55657	Enclosure Tube	1.85	65113	Upper Rubber Bushing	.55
55659	Control Cable—Boot and Tube	5.00	65114	Upper Rubber Bushing Liner	.55
55661	Test Spring	.15	65115	Friction Spring Lever	.90
55662	Washer—Test Spring	.03	65121	Stud—Carburetor	.07
55663	Washer	.05	65123	Tilt Adjusting Lever Assembly	7.30
55664	Water Inlet Tube	2.60	65125	Deflector Cone—Driveshaft Spline	.15
55665	Decal Set (MARTIN 100 T.S.)	.45	65127	Pin—Tilt Adjusting	1.40
55666	Intake Port Cover—Lower	1.85	65128	Tilt Adjusting Screw and Handle Assembly	2.50
55667	Fitting—3/Way Valve to Carburetor	.25	65137	O'Ring—Water Tube Seal	.15
55668	Fuel Line—Pump to Selector	1.25	65138	Pin—Pump Rotor	.05
55669	Fuel Pump Assembly	9.00	65139	Intermediate Housing (Refer to 65815)	
55670	Fuel Pump Kit (MARTIN 100)	12.50	65140	Washer—Tilt Friction	.05
55672	Fuel Line and Fitting Assembly	1.75	65141	Gasket—Intermediate Housing to Water Pump Housing	.15
55673	Fitting and Selector	7.50	65143	Propeller Shaft	7.10
55674	Decal	.15	65144	Bevel Gear	6.75
55675	Motor Support Tube Assembly (Refer to 55639)		65147	Gasket—Gearcase to Intermediate Housing	.15
55676	Moulding	.25	65148	Gearcase Nosecap	2.50
55678	Cylinder Block and Crankcase Assembly	40.00	65149	Shear Pin	.05
55709	Bearing Plate and Bracket Assembly	11.25	65150	Bevel Pinion	4.70
55710	Driveshaft Bearing Plate (Refer to 26033)		65151	Driveshaft	9.00
55711	Water Pump Housing (Refer to 55712)		65152	Propeller Shaft and Gear	19.80
55712	Water Pump Housing Assembly	5.60	65153	Propeller Thrust Retainer	3.50
55713	Cover Plate—Water Pump	.30	65159	Bolt—Stern Bracket	.55
55714	Gasket—Water Pump Bearing Plate	.10	65161	Gasket—Cylinder Head Cover	.25
55715	Gasket—Water Pump	.10	65162	Cover—Cylinder Head	2.75
55729	Water Inlet Tube Assembly <i>no longer available</i>	1.25	65166	Linkage—Carburetor	.04
55731	Propeller (Heavy Load) <i>no longer available</i>	4.20	65170	Lever—Cam Control	.20
55738	Fuel Tank Assembly (Refer to 55440)		65171	Lever and Pin Assembly—Carb Linkage	.45
55739	Magneto (Refer to 55019)		65173	Spring—Carburetor Linkage	.10
65004	Bearing—Propeller Shaft	8.25	65174	Clamp Screw—Handle Assembly	1.05
65005	Washer—Fuel Selector	.02	65200	Body Assembly—Diaphragm Fuel Pump	2.50
65006	Water Pump Housing	5.65	65206	Gasket—Fuel Pump Cover	.05
65009	Propeller Nut	1.05	65208	Diaphragm—Fuel Pump	.10
65010	Pin—Gear to Propeller Shaft	.05	65211	Fuel Pump and Lower Intake Assembly	7.90
65011	Gearcase Seal—O'Ring	.35	65215	Cover Assembly—Diaphragm—Fuel Pump	2.20
65012	Washer	.40	65216	Valve Spring—Diaphragm	.02
65016	Housing Coupling Adapter Fuel Line	1.06	65224	Intake Valve	1.40
65022	Crankshaft	45.00	65225	Intake Pipe	.85
65023	Cylinder Head	7.70	65226	Filter—Auxiliary Fuel Tank	.25
65024	Gasket—Cylinder Head Compression	.85	65227	Fuel Cap and Air Vent Assembly	3.10
65029	Lockspring—Wristpin	.05	65228	Fuel Line—Two Feet	.60
65036	Gasket—Exhaust Housing	.20	65229	Fuel Line—Thirteen Feet	3.10
65037	Stud—Crankcase to Block	.10	65230	Fuel Line Connector	.30
65038	Upper Main Bearing Cap	6.70	65231	Transparent Tube	.25
65039	Lower Main Bearing Cap	5.75	65232	Seal Fuel Cap	.05
65040	Bearing—Upper and Lower Main	4.40	65233	Gasket—Fuel Tank Handle	.15
65041	Piston Ring	.45	65235	Fuel Cap—Auxiliary Fuel Tank	1.00
65042	Gasket—Exhaust Port Cover	.25	65252	Plunger Assembly	1.30
65043	O'Ring—Upper and Lower Main Cap	.35	65253	Access Cover—Rear Shroud	.65
65044	Upper Main Bearing Cap	15.20	65254	Coupling Adapter—Assembly for Fuel Line	2.20
65045	Lower Main Bearing Cap	10.20	65271	Fuel Gauge and Ring Assembly—Fuel Tank	1.95
65047	Pin—Cam Follower	.15	65283	Cover Plate Assembly—Water Pump	5.50
65048	Gasket—Intake Port Cover	.10	65285	Pump Diaphragm Spring	.20
65049	Cover—Upper Intake Port	.98	65286	Button—Pump Diaphragm	.15
65050	Cover—Lower Intake Port	1.70	65288	Carburetor	10.80
65051	Gasket—Exhaust Port Cover	.35	65289	Magneto	45.00
65052	Plate—Exhaust Port Cover	.65	65290	Choke Bracket Assembly	.35
65053	Exhaust Port Cover	1.50	65296	Choke Rod	.35
65056	Stud—Lower Main Bearing Cap	.10	65301	Fuel Selector	4.90
			65305	Pin—Access Cover Shroud	.15
			65326	Fuel Line Connector	.50

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER — DESCRIPTION — PRICE

Part No.	Description	Price	Part No.	Description	Price
65327	Fuel Line Assembly	6.00	65647	Cable Assembly—15 foot	16.50
65328	Fuel Tank Handle Assembly	8.75	65649	Friction Shoe Assembly	.70
65336	Stern Bracket Assembly (Right)	14.60	65657	Aft Housing	3.50
65337	Stern Bracket Assembly (Left)	14.60	65658	Aft Cover	1.10
65338	Stern Bracket (Right)	11.75	65664	Remote Control Clips	.10
65339	Stern Bracket (Left)	11.75	65689	Carburetor Linkage Pivot	1.00
65349	Bracket Assembly—Tank Mounting	15.40	65700	Access Cover—Sub Assembly	3.25
65351	Fuel Selector—Locating Pin	.05	65701	Decal—Operating Instructions	.15
65352	Nut—Fuel Selector—Mounting	.03	65704	Bushing and Tube Assembly (Refer to 65826)	
65353	Support—Friction Quadrant	.35	65705	Main Bearing Seal	.88
65359	Rod—Shifting Link—Actuating	1.10	65709	Choke Bracket and Rod Assembly	.94
65362	Stud—Steering Handle Bracket	.15	65712	Fuel Gauge Shroud	.10
65368	Pinion—Speed Control Stator Drive	.75	65713	Cover—Lower Intake Port	1.40
65372	Washer—Lower Rubber Bushing	.05	65714	Fuel Line and Fitting—Tank to Selector	1.65
65373	Bushing—Steering Handle	.15	65715	Fuel Line and Fitting—Pump to Selector	1.65
65376	Gear—Speed Control Drive	1.70	65716	Fuel Line and Fitting—Selector to Carburetor	1.65
65379	Friction Washer—Speed Control	.15	65719	Air Vent Screw Assembly	1.10
65380	Ring Gear—Mounting	.55	65720	Fuel Gauge and Tube Assembly	5.40
65384	Gear Steering Handle Elbow—Speed Control	1.70	65721	Metecal Nameplate	.15
65385	Piston and Wristpin Assembly	6.00	65723	Propeller	4.00
65386	Clip—Magneto Wire	.05	65728	Fuel Tank Handle	5.20
65387	Stator Retaining Ring	.10	65729	Fuel Gauge Dial	.60
65389	Spring—Access Cover Rear Shroud	.05	65730	Locking Block	.06
65391	Starter Handle	.50 .75	65731	Seal Propeller Shaft	1.25
65414	Ring—Stator Gear Spacer	.20	65734	Fuel Selector Plug	.15
65415	Primer Bulb Assembly	3.00	65738	Decal—Auxiliary Gas Tank	.15
65427	Nut—Speed Control Friction	1.20	65739	Bearing—Drive Shaft	.90
65428	Wave Washer—Speed Control Friction	.05	65755	Bracket—Steering Handle	7.20
65429	Pin—Steering Handle Elbow Stop	.10	65757	Starter Housing (Refer to 65820)	
65431	Intake Manifold Assembly	2.75	65762	Rear Shroud and Decal	8.00
65432	Flushing Plug	.28	65779	Gear—Speed Control Handle Bracket	1.25 1.75
65433	Valve Spring	.20	65784	Spark Plug and Washer (100-s-10)	.87
65436	Ring—Stator Pinion Spacer	.10	65787	Orifice Plate	.96
65442	Speed Control Ring	1.50	65789	Bowed Washer	.02
65443	Cover Ring and Set Screw	1.50	65795	Rubber Washer—3/way Valve	.05
65444	Cap—Speed Control Grip	1.70	65797	Ratchet—Starter	2.50
65448	Front Trim	2.50	65799	Starter Plug Assembly	.90
65461	Cam and Gear Assembly—Carburetor Control	2.70	65800	Gasket Set Complete—(MARTIN 200)	2.64
65462	Front Shroud—Sub Assembly	6.60	65801	Gasket Set Powerhead—(MARTIN 200)	2.30
65467	Casing—Flexible Shaft	3.00	65802	Powerhead—with Carburetor and Magneto—(MARTIN 200)	263.80
65468	Flexible Shaft—Speed Control	2.10	65803	Powerhead—Less Carburetor and Magneto—(MARTIN 200)	206.80
65469	Access Cover—Sub Assembly (Refer to 65700)		65805	Upper Main Cap and Ball	7.60
65471	Grip Assembly	3.50	65806	Choke Actuating Arm and Screw Assembly	.50
65473	Tube Assembly—Speed Control	3.10	65807	Choke Knob and Set Screw Assembly	.60
65476	Shroud and O'Ring Assembly—Steering Handle	4.50	65808	Idle Adjustent Tab and Set Screw Assembly	.90
65478	Ring—Steering Handle—Shroud	1.25	65809	High Speed Tab and Set Screw Assembly	1.10
65479	Elbow Assembly	10.40	65810	Motor Support Tube and Screw Assembly	8.85
65482	Check Valve	.98	65811	Motor Support Tube Housing Assembly	14.35
65484	Pin—Speed Control Grip to Tube	.35	65812	Stern Bracket and Motor Support Tube Housing Assembly	60.00
65486	Rubbing Pad—Steering Handle Bracket	.08	65813	Gear Case Assembly	60.00
65489	Gas Tank & Decal Assembly MARTIN 200	26.00	65814	Gear Case	18.60
65491	Decal—Operating Instructions (Refer to 65701)		65815	Intermediate Housing Assembly	15.20
65492	Speed Control Handle Bracket Gear	.75	65816	Auxiliary Tank—Sub Assembly	21.00
65495	Cover—Steering Handle Elbow	.25	65817	Fuel Selector Knob and Set Screw Assembly	.70
65497	Friction Shoe Assembly	.45	65818	Starter Cord and Handle Assembly	3.00
65498	Indicator—High and Low Speed	.05	65819	Carburetor Knob Assembly	.50
65509	Auxiliary Gas Tank Assembly	32.50	65820	Starter Housing	13.70
65510	Starter Assembly	23.00	65821	Exhaust Housing	35.00
65514	Steering Handle Bracket Assembly	13.50	65822	Cylinder Block and Case	60.00
65516	Steering Handle Assembly	35.60	65823	Bearing—Driveshaft	.90
65601	Lever—Stator	.20	65826	Steering Handle—Sub Assembly	10.40
65607	Bowdin Wire Casing Clamp	.15	65828	Flushing Kit	1.55
65617	Aft—Speed Control Lever Assembly	.25	65900	Racing Driveshaft	5.00
65635	Aft—Control Washer	.02	65901	Racing Intermediate Housing	22.50
65644	Cable Assembly—6 foot	9.40	65903	Racing Gearcase Nosecap	4.50
65645	Cable Assembly—9 foot	13.50			
65646	Cable Assembly—12 foot (Not Available)				

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER — DESCRIPTION — PRICE

SCREWS:

First and second dimensions indicate diameter and number of threads per inch.
Third dimension indicates length of screw.

WASHERS:

First dimension indicates the inside diameter.
Second dimension indicates the outside diameter.
Third dimension indicates thickness of washer.

NUTS:

Dimensions indicate the size of the screw or bolt on which the nut can be used.

Part No.	Description	Price
1-s-1	Screw (Refer to 17-s-1)
1-s-3	Screw, 6-32x $\frac{1}{8}$ " Rd. Hd. St.	.02
1-s-4	Screw, 10-24x $\frac{1}{4}$ " Rd. Hd. St.	.02
1-s-7	Vent Screw, 10-24x $\frac{3}{8}$ " Rd. Hd. Br.	.02
1-s-14	Screw, 10-24x $\frac{1}{4}$ " Rd. Hd. St.	.02
1-s-15	Screw, 8-32x $\frac{1}{8}$ " Rd. Hd. St.	.02
1-s-16	Screw, 6-32x $\frac{3}{8}$ " Rd. Hd. St.	.02
1-s-17	Screw, 3-48x $\frac{1}{4}$ " Rd. Hd. St.	.02
2-s-1	Screw, $\frac{1}{4}$ -20x $\frac{7}{8}$ " Fil. Hd. St.	.04
2-s-2	Screw, $\frac{1}{4}$ -20x1 $\frac{3}{4}$ " Fil. Hd. St.	.04
2-s-3	Screw, $\frac{1}{4}$ -20x2 $\frac{1}{2}$ " Fil. Hd. St.	.05
2-s-4	Screw, 10-24x $\frac{1}{2}$ " Fil. Hd. St. (Refer to 2-s-5)
2-s-5	Screw, 10-24x $\frac{7}{8}$ " Fil. Hd. St.	.02
2-s-6	Screw, 10-24x $\frac{1}{2}$ " Fil. Hd. St.	.02
2-s-7	Screw, $\frac{1}{4}$ -20x $\frac{3}{4}$ " Fil. Hd. St.	.02
2-s-8	Screw, $\frac{1}{4}$ -20x1" Fil. Hd. St.	.04
2-s-9	Screw, $\frac{1}{4}$ -20x $\frac{5}{8}$ " Fil. Hd. St.	.02
2-s-10	Screw, 12-24x $\frac{3}{8}$ " Fil. Hd. St.	.02
2-s-11	Screw, 10-24x $\frac{3}{4}$ " Fil. Hd. St.	.02
2-s-12	Screw, $\frac{1}{4}$ -20x2 $\frac{1}{2}$ " Fil. Hd. St.	.05
2-s-15	Screw, $\frac{1}{4}$ -20x $\frac{1}{2}$ " Fil. Hd. St.	.02
2-s-16	Screw (Refer to 2-s-3)
2-s-17	Screw, $\frac{1}{4}$ -20x2 $\frac{1}{4}$ " Fil. Hd. St.	.05
2-s-18	Screw, 10-20x $\frac{3}{8}$ " Fil. Hd. St.	.02
2-s-19	Screw, 12-24x $\frac{5}{8}$ " Fil. Hd. St.	.02
2-s-20	Screw, $\frac{1}{4}$ -20x1 $\frac{7}{8}$ " Fil. Hd. St.	.05
2-s-21	Screw, $\frac{1}{4}$ -20x2" Fil. Hd. St.	.05
2-s-22	Screw, 10-24x1" Fil. Hd. St.	.03
2-s-25	Screw, $\frac{1}{4}$ -20x1 $\frac{5}{8}$ " Fil. Hd. St.	.10
2-s-26	Screw, $\frac{1}{4}$ -20x1 $\frac{1}{4}$ " Fil. Hd. St.	.03
2-s-27	Screw, $\frac{1}{4}$ -20x1 $\frac{1}{8}$ " Fil. Hd. St.	.03
2-s-31	Screw, 10-24x $\frac{5}{8}$ " Fil. Hd. St.	.05
2-s-33	Screw, 10-24x $\frac{3}{8}$ " Fil. Hd. St.	.02
2-s-37	Screw, 8-32x $\frac{1}{2}$ " Fil. Hd. St.	.02
2-s-38	Screw, 10-32x $\frac{1}{4}$ " Fil. Hd. St.	.02
2-s-39	Screw, 10-24x $\frac{1}{8}$ " Fil. Hd. St.	.02
2-s-40	Screw, $\frac{1}{4}$ -20x $\frac{3}{4}$ " Fil. Hd. Br.	.05
2-s-41	Screw, 10-24x $\frac{1}{2}$ " Fil. Hd. St.	.03
2-s-42	Screw, 12-24x $\frac{1}{2}$ " Fil. Hd. St.	.02
2-s-43	Screw, 10-24x $\frac{3}{4}$ " Fil. Hd. St.	.02
2-s-44	Screw, 5-40x1 $\frac{1}{2}$ " Fil. Hd. St.	.02
2-s-47	Screw, $\frac{1}{4}$ -20x $\frac{5}{8}$ " Fil. Hd. St.	.03
2-s-48	Screw, 5-40x $\frac{1}{4}$ " Fil. Hd. St.	.06
2-s-49	Screw, 10-24x $\frac{3}{8}$ " Fil. Hd. St.	.03
2-s-50	Screw, 10-24x $\frac{3}{4}$ " Fil. Hd. St.	.05
2-s-51	Screw, 8-32x $\frac{5}{8}$ " Fil. Hd. St.	.02
2-s-52	Screw, $\frac{1}{4}$ -20x1" Fil. Hd. St.	.10
2-s-54	Screw, 10-24x1 $\frac{1}{2}$ " Fil. Hd. St.	.03
2-s-55	Screw, $\frac{1}{4}$ -20x $\frac{1}{2}$ " Fil. Hd.	.02
2-s-56	Screw, $\frac{1}{4}$ -28x.781 Fil. Hd. St.	.03
2-s-57	Screw, $\frac{1}{4}$ -20x1" Fil. Hd. St.	.03
3-s-1	Screw, 8-32x $\frac{1}{4}$ " Ov. Bnd. Hd. St.	.02
3-s-2	Screw, 4-40x $\frac{1}{8}$ " Ov. Bnd. Hd. St.	.02
3-s-3	Screw, $\frac{1}{4}$ -20x1 $\frac{5}{8}$ " Ov. Bnd. Hd. St.	.03
3-s-4	Screw, 10-24x $\frac{1}{2}$ " Ov. Bnd. Hd. St.	.02
3-s-7	Screw, 10-24x $\frac{1}{2}$ " Ov. Bnd. Hd. St.	.05
4-s-1	Screw (Refer to 4-s-6)
4-s-2	Screw, 10-24x $\frac{5}{8}$ " Ov. Hd. St.	.02
4-s-5	Screw, 10-24x $\frac{3}{8}$ " Ov. Hd. St.	.02
4-s-6	Screw, $\frac{1}{4}$ -20x1 $\frac{1}{2}$ " Ov. Hd. St.	.10

Part No.	Description	Price
4-s-8	Screw (Refer to 4-s-6)
4-s-9	Screw, 10-24x $\frac{1}{2}$ " Ov. Hd. St.	.02
4-s-10	Screw, $\frac{1}{4}$ -28x $\frac{7}{8}$ " Ov. Hd. St.	.03
5-s-1	Screw, 4x $\frac{1}{4}$ " Dr. St.	.01
5-s-2	Screw, 00X $\frac{1}{8}$ " Dr. St.	.01
5-s-3	Screw, 0(.073)x $\frac{1}{8}$ " Dr. St.	.02
5-s-4	Drive Screw, 00X $\frac{1}{8}$ " Dr. St.	.01
6-s-1	Screw (Refer to 13-s-1)
6-s-2	Screw, 10-24x $\frac{3}{8}$ " Slt. Hd. St.	.03
6-s-3	Set Screw, $\frac{1}{4}$ -20x $\frac{1}{2}$ " Slt. Hd. St.	.03
6-s-4	Set Screw, 10-32x $\frac{1}{8}$ " Slt. Hd. St.	.03
6-s-5	Set Screw, 10-24x $\frac{1}{4}$ " Slt. Hd. St.	.02
6-s-6	Set Screw (Refer to 55344)
6-s-7	Set Screw, 8-32x $\frac{1}{8}$ " Slt. Hd. St.	.03
7-s-1	Screw (Refer to 15159)
7-s-2	Screw (Refer to 25344)
7-s-5	Screw, Allen Head, $\frac{1}{4}$ -20x2" Hex. Hd. St.	.30
7-s-6	Screw, 10-32x $\frac{5}{8}$ " Hex. Hd. St.	.15
7-s-7	Screw, 12-28x $\frac{5}{8}$ " Hex. Hd. St.	.12
7-s-8	Screw, $\frac{5}{16}$ -18x1 $\frac{3}{4}$ " Hex. Hd. St.	.25
7-s-9	Screw, $\frac{1}{4}$ -20x1" Hex. Hd. St.	.40
7-s-10	Screw, $\frac{5}{16}$ -18x1 $\frac{1}{4}$ " Hex. Hd. St.	.45
8-s-2	Screw, 10-24x $\frac{3}{4}$ " Fl. Hd. St.	.02
8-s-3	Screw (Refer to 8-s-15)
8-s-4	Screw, $\frac{1}{4}$ -20x1 $\frac{1}{4}$ " Fl. Hd. St.	.03
8-s-5	Screw, 4-40x $\frac{1}{4}$ " Fl. Hd. St.	.02
8-s-6	Screw, $\frac{1}{4}$ -20x $\frac{3}{8}$ " Fl. Hd. St.	.02
8-s-8	Screw (Refer to 8-s-19)
8-s-11	Screw, 10-24x $\frac{1}{2}$ " Fl. Hd. St.	.06
8-s-13	Screw, 5-40x $\frac{1}{8}$ " Fl. Hd. St.	.02
8-s-14	Screw, $\frac{5}{16}$ -18x $\frac{3}{4}$ " Fl. Hd. St.	.03
8-s-15	Screw, 6-32x $\frac{5}{8}$ " Fl. Hd. St.	.02
8-s-16	Screw, 6-32x $\frac{1}{4}$ " Fl. Hd. St.	.02
8-s-17	Screw, $\frac{1}{4}$ -2x1 $\frac{1}{8}$ " Fl. Hd. St.	.06
8-s-18	Screw, 10-24x $\frac{1}{8}$ " Fl. Hd. St.	.02
8-s-19	Screw, 10-24x $\frac{7}{8}$ " Fl. Hd. St.	.02
8-s-21	Screw, $\frac{1}{4}$ -20x $\frac{3}{4}$ " Fl. Hd. St.	.06
8-s-22	Screw, $\frac{1}{2}$ -20x1 $\frac{1}{4}$ " Fl. Hd. St.	.10
8-s-24	Screw, 10-24x $\frac{1}{8}$ " Fl. Hd. St.	.03
8-s-25	Screw, $\frac{1}{4}$ -20x $\frac{3}{4}$ " Fl. Hd. St.	.03
9-s-1	Set Screw, 10-24x $\frac{5}{8}$ " Al. Hd. St.	.10
9-s-2	Set Screw (Refer to 15161)
9-s-5	Set Screw, 8-32x $\frac{1}{4}$ " Al. Hd. St.	.06
9-s-6	Set Screw, 10-32x $\frac{1}{4}$ " Al. Hd. St.	.06
9-s-7	Set Screw, 10-24x $\frac{1}{4}$ " Al. Hd. St.	.10
9-s-9	Screw, 5-40x $\frac{1}{8}$ " Al. Hd. St.	.10
10-s-8	Screw, $\frac{5}{16}$ -18x2" Hex. Hd. St.	.06
10-s-11	Screw, $\frac{1}{8}$ -24x1 $\frac{3}{8}$ " Hex. Hd. St.	.26
10-s-12	Screw, $\frac{1}{4}$ -20x1 $\frac{1}{4}$ " Hex. Hd. St.	.05
10-s-13	Screw, $\frac{1}{4}$ -20x $\frac{7}{8}$ " Hex. Hd. St.	.15
10-s-15	Screw, $\frac{1}{4}$ -20x1 $\frac{1}{8}$ " Hex. Hd. St.	.04
10-s-16	Screw, $\frac{5}{16}$ -18x $\frac{5}{8}$ " Hex. Hd. St.	.05
10-s-17	Screw, $\frac{1}{8}$ -24x1 $\frac{1}{8}$ " Hex. Hd. St.	.05
10-s-18	Screw, $\frac{1}{4}$ -20x1 $\frac{1}{8}$ " Hex. Hd. St.	.06
11-s-1	Screw, $\frac{1}{4}$ -20x3 $\frac{1}{2}$ " Fil. Hd. St.	.10
11-s-2	Screw, $\frac{1}{4}$ -20x1 $\frac{7}{8}$ " Fil. Hd. St.	.08
12-s-1	Set Screw, 10-24x $\frac{1}{4}$ " Al. Hd.	.10
13-s-1	Screw, $\frac{1}{8}$ -24x $\frac{1}{2}$ " Slt. Hd. St.	.06
13-s-2	Set Screw, $\frac{1}{8}$ -24x $\frac{3}{4}$ " Slt. Hd. St.	.06
14-s-3	Screw, 6-40x $\frac{3}{8}$ " Al. Hd. St.	.10
17-s-1	Screw, 4-40x $\frac{1}{4}$ " Rd. Hd. St.	.02
18-s-1	Screw, 5-40x $\frac{1}{4}$ " Sem. Fast. St.	.02
18-s-2	Screw, 10-24x $\frac{5}{8}$ " Sem. Fast. St.	.03
18-s-3	Screw, 10-24x $\frac{3}{4}$ " Sem. Fast. St.	.06
19-s-1	Screw, 10-24x $\frac{5}{8}$ " Fil. Hd. St.	.03
20-s-1	Nut, $\frac{1}{8}$ -20"	.05
20-s-3	Nut, (Refer to 21-s-2)
20-s-4	Nut, $\frac{1}{4}$ -28"	.03
20-s-5	Nut, $\frac{5}{16}$ -24"	.10
20-s-7	Nut, $\frac{1}{8}$ -24"	.03
20-s-8	Nut, $\frac{1}{4}$ -28"	.03
21-s-2	Nut, $\frac{3}{8}$ -24"	.03
22-s-3	Nut, $\frac{1}{4}$ -28"	.03
23-s-1	Nut, $\frac{3}{8}$ -24"	.10
23-s-2	Nut, $\frac{1}{4}$ -28"	.06
23-s-3	Nut, $\frac{1}{8}$ -18"	.10
23-s-4	Nut, $\frac{5}{16}$ -24"	.10

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER — DESCRIPTION — PRICE

Part No.	Description	Price	Part No.	Description	Price
24-s-1	Nut, $\frac{1}{8}$ -20"	.04	40-s-1	Oil Seal Drive Shaft (Refer to 40-s-6)
25-s-1	Nut, 10-24"	.02	40-s-5	Oil Seal (Refer to 40-s-7)
25-s-4	Nut, $\frac{1}{4}$ -28"	.08	40-s-6	Oil Seal—Driveshaft	.90
25-s-5	Nut, $\frac{5}{16}$ -18"	.10	40-s-7	Oil Seal—Propeller Shaft	.90
25-s-6	Nut, 8-32"	.02	40-s-8	Seal—Driveshaft	.95
26-s-1	Nut, $\frac{1}{4}$ -20"	.03	41-s-1	Washer, $\frac{21}{64}$ - $\frac{11}{16}$ x $\frac{1}{8}$ "	.03
26-s-3	Nut, 10-24x $\frac{3}{8}$ "	.03	41-s-2	Washer, $\frac{21}{64}$ - $\frac{11}{16}$ x $\frac{1}{8}$ "	.02
29-s-1	Nut, (Refer to 23-s-2)	41-s-3	Washer, $\frac{21}{64}$ - $\frac{11}{16}$ x $\frac{1}{8}$ "	.03
29-s-2	Nut, $\frac{5}{16}$ -24"	.12	42-s-1	Set Screw, $\frac{5}{16}$ -18x $\frac{1}{2}$ Al. Hd. St.	.03
33-s-1	Screw, #10-1 $\frac{3}{4}$ " Slit Hd. Br.	.10	45-s-1	Connector—Compression—Male— $\frac{1}{4}$ "	.10
34-s-1	Screw, #10- $\frac{3}{8}$ " Slit Hd. St.	.02	48-s-1	Elbow—Compression—Male, $\frac{1}{4}$ "	.50
35-s-3	Washer, $\frac{3}{8}$ - $\frac{3}{4}$ x $\frac{1}{16}$ "	.05	48-s-2	Elbow—Compression—Male, $\frac{1}{4}$ "	.40
35-s-4	Washer, $\frac{1}{8}$ - $\frac{1}{8}$ x $\frac{1}{32}$ "	.02	49-s-1	Elbow—Street, $\frac{1}{4}$ "	.70
35-s-6	Washer (Refer to 35-s-37)	50-s-1	Plug—Expansion	.02
35-s-11	Washer, $\frac{3}{32}$ - $\frac{1}{2}$ x $\frac{3}{32}$ "	.02	50-s-2	Plug—Expansion	.02
35-s-12	Washer, $\frac{1}{16}$ - $\frac{1}{8}$ x $\frac{1}{4}$ "	.02	50-s-3	Plug—Expansion	.06
35-s-14	Spacer, $\frac{21}{64}$ - $\frac{3}{4}$ x.032" (Refer to 25931)	50-s-8	Expansion Plug	.03
35-s-15	Washer, $\frac{21}{64}$ - $\frac{1}{8}$ x $\frac{1}{16}$ "	.06	50-s-9	Stainless Steel Plug	.04
35-s-16	Washer, $\frac{1}{16}$ - $\frac{1}{8}$ x $\frac{1}{16}$ "	.04	50-s-10	Stainless Steel Plug	.04
35-s-17	Washer, $\frac{1}{4}$ - $\frac{1}{2}$ x $\frac{3}{16}$ "	.02	50-s-11	Stainless Steel Plug	.03
35-s-18	Washer, $\frac{1}{4}$ - $\frac{1}{8}$ x $\frac{1}{16}$ "	.02	55-s-3	Eyelet	.02
35-s-21	Washer (Refer to 15154)	60-s-1	Cotter Pin, $\frac{3}{32}$ x $\frac{1}{16}$ "	.03
35-s-22	Washer, 158-14x $\frac{1}{32}$ "	.02	60-s-2	Cotter Pin, $\frac{3}{32}$ x $\frac{3}{4}$ "	.03
35-s-23	Washer, $\frac{1}{16}$ - $\frac{3}{8}$ x $\frac{3}{16}$ "	.02	60-s-3	Cotter Pin, $\frac{1}{8}$ x $\frac{1}{8}$ "	.02
35-s-24	Washer, $\frac{17}{64}$ - $\frac{1}{16}$ x $\frac{3}{16}$ "	.02	60-s-6	Cotter Pin, $\frac{1}{8}$ x $\frac{1}{8}$ "	.02
35-s-25	Washer, $\frac{17}{64}$ - $\frac{3}{32}$ x $\frac{1}{16}$ "	.02	60-s-7	Cotter Pin (Refer to 60-s-8)
35-s-28	Washer, $\frac{17}{64}$ - $\frac{3}{8}$ x $\frac{3}{16}$ "	.02	60-s-8	Cotter Pin, $\frac{3}{32}$ x $\frac{7}{8}$ "	.02
35-s-29	Washer, $\frac{17}{64}$ - $\frac{1}{8}$ x $\frac{1}{16}$ "	.03	61-s-1	Cotter Hairpin	.02
35-s-33	Spacer (Refer to 25854)	61-s-2	Cotter Hairpin	.02
35-s-35	Washer, $\frac{1}{32}$ - $\frac{1}{8}$ x $\frac{3}{16}$ "	.02	65-s-1	Drive Pin, .066x $\frac{3}{32}$ "	.02
35-s-36	Washer (Refer to 35-s-16)	65-s-2	Drive Pin, .131x $\frac{1}{16}$ "	.02
35-s-37	Washer, $\frac{21}{64}$ - $\frac{3}{4}$ x.032"	.04	65-s-3	Drive Pin, .115x $\frac{1}{4}$ "	.02
35-s-38	Washer, 158- $\frac{1}{4}$ x $\frac{1}{32}$ "	.04	65-s-5	Drive Pin, .114x $\frac{1}{32}$ "	.02
35-s-39	Washer, $\frac{1}{32}$ - $\frac{1}{8}$ x $\frac{1}{16}$ "	.03	65-s-7	Drive Pin, .099x $\frac{1}{4}$ "	.02
35-s-40	Washer, $\frac{1}{32}$ - $\frac{3}{32}$ x $\frac{1}{32}$ "	.05	65-s-9	Drive Pin, .062x $\frac{3}{8}$ "	.02
35-s-41	Washer, $\frac{1}{4}$ -355x.031"	.03	65-s-10	Drive Pin, .098x $\frac{3}{16}$ "	.02
35-s-42	Washer, $\frac{1}{32}$ - $\frac{1}{8}$ x.031"	.03	65-s-12	Drive Pin (Refer to 65-s-13)
35-s-43	Washer, $\frac{1}{16}$ - $\frac{1}{4}$ x.010"	.10	65-s-13	Drive Pin, .066x $\frac{3}{32}$ "	.02
36-s-1	Lockwasher for $\frac{1}{8}$ -20" Bolt	.03	65-s-14	Drive Pin, .065x $\frac{1}{16}$ "	.02
36-s-2	Lockwasher for 10-24" Bolt	.02	65-s-15	Drive Pin, .132x $\frac{1}{16}$ "	.02
36-s-3	Washer for $\frac{1}{4}$ -20" Bolt	.02	65-s-16	Drive Pin, .066x $\frac{1}{8}$ "	.02
36-s-4	Washer for 12-24" Bolt	.02	65-s-17	Drive Pin, .125x $\frac{1}{2}$ "	.02
36-s-5	Washer for 10-24" Bolt	.02	65-s-18	Drive Pin, .093x $\frac{1}{2}$ "	.02
36-s-6	Lockwasher for $\frac{5}{16}$ -18" Bolt	.03	65-s-19	Drive Pin, .125x $\frac{3}{16}$ "	.02
36-s-8	Lockwasher, $\frac{1}{8}$ -18x.125x.046"	.02	70-s-3	Rivet, 187x $\frac{1}{16}$ " Rd. Hd. St.	.02
36-s-10	Lockwasher for 10-24" Bolt	.02	71-s-2	Rivet—Ctr. Sunk Hd., $\frac{1}{8}$ x $\frac{1}{8}$ "	.02
36-s-11	Lockwasher for $\frac{1}{4}$ -20" Bolt	.02	71-s-3	Rivet—Ctr. Sunk Hd., .289x.066x $\frac{3}{8}$ "	.02
36-s-12	Lockwasher for $\frac{5}{16}$ -18" Bolt	.04	72-s-1	Rivet, 140x $\frac{1}{2}$ " Semi. Tub. Br.	.03
36-s-13	Lockwasher for 8-32" Bolt	.02	75-s-1	Screw—Phil. Hd. 10-24x $\frac{1}{8}$ "	.03
36-s-14	Lockwasher (Refer to 37-s-6)	76-s-1	Screw—Ov. Phil. Hd. 10-24x1	.03
36-s-15	Lockwasher for $\frac{1}{4}$ -20" Bolt	.02	80-s-1	Ball—Vent Seal	.02
36-s-16	Lockwasher for 5-40" Bolt	.03	80-s-2	Ball	.02
36-s-17	Washer for 10-24" Bolt	.02	80-s-5	Ball—Detent	.02
36-s-19	Lockwasher for 12-24" Bolt	.02	80-s-8	Ball—120x#5 Shot	.05
37-s-2	Washer—Shakeproof, $\frac{1}{4}$ - $\frac{1}{2}$ x.025" (Refer to 37-s-4)	80-s-10	Steel Ball, $\frac{3}{32}$ "	.05
37-s-3	Washer—Shakeproof, 10- $\frac{3}{8}$ x.022"	.02	81-s-2A	Roller Crankpin (Needle Bearing 26 MARTIN 100)	.75
37-s-4	Washer—Shakeproof, $\frac{1}{4}$ - $\frac{1}{2}$ x.025"	.02	81-s-2B	Roller Crankpin (Needle Bearing 28 MARTIN 200)	.81
37-s-6	Washer—Shakeproof, 12- $\frac{1}{2}$ x.022"	.02	82-s-4	Retaining Ring Follower	.05
37-s-7	Washer—Shakeproof (Refer to 37-s-3)	82-s-5	Retaining Ring	.05
38-s-1	Washer—Ctr. Sunk, 6- $\frac{1}{16}$ x.018"	.02	82-s-6	Snap Ring (Refer to 60-s-6)
38-s-2	Washer—Ctr. Sunk, 10- $\frac{3}{8}$ x.022"	.02	84-s-4	Retaining Ring, .312x.270x.025x.276x.028x.390	.05
38-s-3	Washer—Ctr. Sunk, $\frac{1}{4}$ - $\frac{1}{2}$ x.022"	.02	90-s-3	Spring Swivel Lock	.05
38-s-4	Washer—Ctr. Sunk, $\frac{1}{4}$ - $\frac{1}{2}$ x.022"	.04	90-s-4	Spring—Vent Seal	.05
39-s-1	Washer—Shakeproof, $\frac{3}{8}$ - $\frac{1}{4}$ x.035"	.02	100-s-1	Spark Plug and Washer (Champion J-8-J)	.87
39-s-2	Washer (Refer to 39-s-6)	100-s-4	Spark Plug and Washer (Champion J-6-J)	.87
39-s-4	Washer—Shakeproof, $\frac{1}{4}$ - $\frac{3}{8}$ x.022"	.04	100-s-5	Spark Plug and Washer (Champion J-11-J)	.87
39-s-5	Washer—Shakeproof, $\frac{5}{16}$ - $\frac{1}{2}$ x.030"	.04			
39-s-6	Washer—Shakeproof, $\frac{1}{4}$ - $\frac{3}{8}$ x.030"	.03			

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER — DESCRIPTION — PRICE

TILLOTSON CARBURETOR

PARTS FOR MODELS

MD 5A, MD 5B, MD 8A, MD 8B, MD 9A, MD 9B, MD 15A and MD 15B

Part No.	Description	Price	Part No.	Description	Price
0676	Main Adjustment Screw Gland Gasket02	08015	Body—Upper half	3.80
0702	Main Adjustment Screw Gland30	08018	Inlet Needle Seat and Gasket90
0703	Main Adjustment Screw Packing Nut19	08025	Gasket and Packing Set30
0705	Main Adjustment Screw Packing07	08026	Repair Parts Kit	3.30
0992	Lockwasher, Body Retaining Screw02	08179	Main Nozzle39
01675	Lockwasher—Choke Shutter Screw02	08180	Main Adjustment Screw (Long Shank)45
02395	Main Nozzle Channel Plug Screw07	08181	Body—Upper Half	3.80
02510	Inlet Seat Gasket02	08185	Throttle Shaft and Lever (Refer to 08421)	
02531	Body Channel Welch Plug06	08189	Throttle Shutter13
02658	Idle Tube Gasket02	08252	Idle Adjustment Screw30
03311	Fuel Bowl Drain Screw (Small)07	08256	Body—Upper Half	3.80
03804	Primer Pin Washer06	08267	Body—Upper Half	3.80
05204	Choke Shutter Screw (Refer to 05430)		08314	Repair Parts Kit	3.30
05430	Throttle Shutter Screw02	08316	Repair Parts Kit	3.30
05591	Flange Gasket07	08332	Fuel Bowl	1.93
05725	Idle Adjustment Screw Spring07	08403	Idle Adjustment Screw33
06062	Body Retaining Screw and Lockwasher07	08404	Main Adjustment Screw50
07804	Float94	08405	Main Adjustment Screw50
07895	Inlet Needle Seat and Gasket90	08406	Choke Shutter19
07896	Fuel Bowl Plug Screw (Large)13	08421	Throttle Shaft and Lever (With Screw)44
07900	Idle Tube Gasket02	08423	Main Nozzle33
07901	Float Lever Pinion Screw19	08426	Idle Tube50
07903	Body Gasket13	08427	Idle Adjustment Screw33
07910	Throttle Return Spring13	08429	Body—Upper Half	3.80
07912	Choke Friction Pin Screw07	08472	Repair Parts Kit	3.03
07921	Idle Tube33	08499	Choke Shaft and Collar28
07922	Main Nozzle39	08531	Choke Shaft and Primer Lever Complete (Refer to 25644)	
07923	Choke Friction Pin07	08532	Body—Upper Half	3.85
07925	Choke Friction Pin Spring07	08554	Gasket and Packing Set28
07929	Fuel Bowl (Refer to 08332)		08555	Repair Parts Kit	3.25
07938	Idle Tube33	08597	Throttle Return Spring Cotter Pin01
07944	Throttle Return Spring13	08605	Body—Upper Half	3.80
07993	Primer Pin25	08607	Body—Upper Half	3.80
07994	Primer Pin Return Spring07	08609	Choke Shaft and Lever, Assembly70
07995	Primer Pin Link19	08716	Throttle Shutter19
07997	Primer Pin (Refer to 07993)		08717	Primer Pin Return Spring08
08002	Choke Shaft and Primer Lever Complete77	08722	Repair Parts Kit	3.30
08003	Idle Adjustment Screw33	08723	Repair Parts Kit	3.03
08006	Throttle Shaft, Lever and Swivel66	08724	Repair Parts Kit	3.25
08010	Choke Shutter13	08919	Primer Pin Return Spring (Refer to 08717) ..	
08011	Throttle Shutter19			
08013	Main Adjustment Screw (Long Shank) (Refer to 08404)				

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER — DESCRIPTION — PRICE

CARTER CARBURETOR PARTS

Part No.	Description	Price	Part No.	Description	Price
1A-73	Flange Gasket (Refer to 1A-83)		23A-19	Bowl Ring Gasket	.14
1A-83	Flange Gasket	.09	24-23	Float Lever Pin	.07
2-139	Throttle Valve	.14	25-171S	Needle and Seat Assembly	1.08
2-140	Throttle Valve	.14	25-223S	Needle and Seat Assembly (Refer to 25-246)	
2-141	Throttle Valve	.14	25-246	Needle and Seat	1.20
2-158	Throttle Valve	.15	30A-47	Idle Adjustment Screw (Refer to 30A-53)	
3-686S	Throttle Shaft and Lever Assembly	1.01	30A-49	Idle Adjustment Screw (Refer to 30A-54)	
3-701S	Throttle Shaft and Lever Assembly	1.01	30A-50	Idle Adjustment Screw (Refer to 30A-52)	
3-734S	Throttle Shaft and Lever Assembly	1.01	30A-52	Idle Adjustment Screw	.41
3-826	Throttle Shaft and Lever Assembly	1.01	30A-53	Idle Adjustment Screw	.41
7-164S	Choke Valve (Refer to 7-180S)		30A-54	Idle Adjustment Screw	.41
7-165S	Choke Valve Assembly (Refer to 7-180S)		30A-56	Idle Adjustment Screw	1.65
7-180S	Choke Valve Assembly	.41	37-57	High Speed Adjusting Screw	1.43
7-183	Choke Valve Assembly	.53	39-10	Valve Attaching Screw (Refer to 101-320)	
11-203S	Low Speed Jet Assembly	.68	47-11	Welsh Plug	.04
11-204S	Low Speed Jet Assembly	.68	47-31	Welsh Plug	.05
11-209S	Low Speed Jet Assembly	.68	61-302	Idle Adjustment Screw Spring (Refer to 61-475)	
12-337	Nozzle (Refer to 12-387) for "45" Motors		61-369	Choke Shaft Spring	.07
12-337	Nozzle (Refer to 12-379) for "75" and "100" Motors		61-405	Spring	.15
12-358	Nozzle (Refer to 12-379)		61-406	Needle Pull Clip	.06
12-379	Nozzle	.54	61-411	Throttle Valve Return Spring	.20
12-387	Nozzle	.54	61-475	Idle Adjustment Screw Spring	.14
12-399	Nozzle	.68	61-490	Return Spring—Throttle Valve	.23
14-408S	Choke Shaft and Lever Assembly	.68	101-320	Valve Attaching Screw	.03
14-458	Choke Shaft and Lever Assembly	.90	116-16	Choke Shaft Ball	.03
15A-12	Packing Nut	.15	136-175	Idle Adjusting Screw Washer	.08
15-50S	Bowl Nut Assembly	.23	150-171	Float Stop Pin	.02
20-22	Needle Seat Gasket	.07	159-135S	Adjustable Main Metering Screw (Refer to 159-156S)	
20-110	Bowl Nut Gasket	.07	159-138S	Adjustable Main Metering Screw Assembly	1.01
21-105S	Float and Lever Assembly	2.03	159-156S	Adjustable Main Metering Screw Assembly	1.01
21-139S	Float and Lever Assembly	2.03	163-53	High Speed Needle Packing	.07
23-37	Bowl	1.01	65-s-1	Float Stop Pin (Refer to 150-171)	
23-42	Bowl	1.01			
23-49	Bowl	1.13			

SYNCR0-TWIST PARTS FOR

"45", "66", and "75"

Part No.	Description	Price	Part No.	Description	Price
SA-1	R. H. Bracket	.65	O-22	Friction Shoe	.03
SA-2	Cable Assembly	3.00	O-23	Pin	.02
SA-4	Quadrant Assembly	.80	O-24	8/32" x 7/8" R. H. Machine Screw	.02
SA-6	Quadrant Assembly	.80	O-25	8/32" x 3/8" Machine Screw	.01
SA-7	Cable Assembly	3.00	O-26	Locknut—1/4-28 H. P. x 1/8	.03
SA-51-1	Rubber Grip Assembly	.65	O-27	Lockwasher—1/4 Med. Press	.02
SSA-3	Gear Housing Sub-Assembly	3.40	O-28	Cotter Pin, 1/8" x 1/2"	.02
O-1	Rotatable Tube	.66	O-29	Slotted Set Screw	.02
O-4	Gear and Drum	.70	O-30	Locking Screw	.01
O-5	Gear	.60	O-4M	Left Hand Bracket	.40
O-6	Driveshaft	.30	O-8M	Spacer	.06
O-7	Driving Lug	.03	O-9M	Cable Support	.25
O-9	Gear Housing Cap	1.16	O-13M	R. H. Bracket	.65
O-10	Bolt	.08	O-14M	L. H. Bracket	.40
O-13	Cable Clamp	.04	SA-3	Handle and Cable Assembly (Refer to 25771)	
O-18	Pivot Bolt	.10	SA-5	Sub Assembly (Refer to 15291)	
O-20	Collar—Includes 1/32" x 1/8" Set Screw	.56			

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER—DESCRIPTION—PRICE

MAGNETO PARTS LIST

Part No.	Description	Price	Part No.	Description	Price
X2215	Lead Wire Group	.42	X6337	Stator Plate Unit (Incl. Coils, Condensers, etc.)	14.55
2264A-B	Coil Wedge	.06	X6404	Rotor	24.45
2965	Fixed Contact Clamp Screw Washer	.05	7018	Breaker Cam	1.50
2972	Shaft Key (Refer to 25402)		7041	Breaker Slide	.10
3081	Cam Spring Washer	.05	X7046	Breaker Contact Set	1.80
3497A-B	Coil Wedge	.06	X7120	Coil Group (Refer to 5460)	
5431	Condenser Clamp Screw	.05	7167	Terminal Coupling (Sold with 7120, Coil, to make 5460)	
5431	Fixed Contact Clamp Screw	.05	7218	Breaker Cam	1.50
5431	Condenser Connection Screw	.05	X7224	Rotor	22.60
5443F	Fixed Contact (Refer to 5469F)		X7238	Stator Plate Unit (Incl. Coils, Condensers, etc.)	26.05
5445	Core Screw	.05	X7296	Stator Plate Unit (Refer to X6277)	
5446	Cam Wiper Felt	.05	X7310	Rotor (Refer to X5479)	
5449F	Breaker Shoe Group (Refer to 5469F)		X7345	Coil Group	5.40
X5460	Coil Group	5.40	X7379	Lead Wire Group	.45
5461F	Breaker Spring (Refer to 5469F)		X7381	Lead Wire Group	.45
X5463	Condenser Group	1.50	7428	Stator Unit Replacement	6.21
5465	Breaker Cam	1.50	7430	Lead Wire	.40
5469F	Breaker Contact Set	1.80	X7500	Coil Group	4.75
X5471	Stator Plate Assembly (Replacement)	4.60	7537	Core Screw	.05
X5479	Rotor	21.15	Y7558	Rotor	24.40
X5485	Stator Plate Assembly (Replacement)	4.60	Y7559	Rotor	21.15
5486	Lead Wire Bushing	.05	X7562	Stator Plate Unit (Incl. Coils, Condensers, etc.)	24.40
5488	Control Linkage Pivot (Refer to 25236)		8732	Primary Lead Wire Clip Screw	.05
5489	Control Linkage Pivot Washer (Refer to 35-s-12)		8824	Lead Wire Spring Ends	.10
5490	Control Linkage Pivot Cotter Pin (Refer to 60-s-3)		8825	Lead Wire Rubber Cap	.15
X5816	Friction Shoe Group	.25	X8835	Stator Plate	22.40
5925	Lead Wire Marker	.05	X8837	Lead Wire Group	.45
X6277	Stator Plate Unit (Incl. Coils, Condensers, etc.)	25.45	8915	Lead Wire	.55

TOOLS — ACCESSORIES

Part No.	Description	Price	Part No.	Description	Price
5289	Test Propeller "20" only	(NET) 1.75	25721	Kalaign Solvent—No. 1,000 Solution	(NET) .35
5801	Shear Pin Kit and Display Card	7.20	25736	Tyco Twist Grip "60", "66" and "75" T. G.	8.65
5808	Bushing for Tiller Bar	.10	25738	Michigan Propeller 8" x 9"—"60", "66" and "75" T. G.	5.50
5825	Tiller Bar for "100"	3.95	25740	Hammerloid Grey Paint No. 33 (1 Pint)	2.00
5827	Oil Seal Driver	(NET) 1.00	25763	Tiller Bar "60", "66", "75" T. G. and "75" T. S.	3.95
5828	Needle Bearing Driver	(NET) 1.50	26015	Test Propeller—"75" Twist Shift	(NET) 2.50
5829	Bronze Bearing Driver	(NET) 1.25	55271	Test Propeller—"100" Std.	(NET) 2.00
5835	Adapter—Bronze Bearing Driver	(NET) 1.00	55601	Ring Compressor "100" Std., "100" T. S.	(NET) 1.50
15113	Wristpin Punch "20", "40" and "45"	(NET) 1.00	55625	Propeller Adapter "100" Std.	2.90
15123	Ring Compressor "20", "40" and "45"	(NET) 1.50	55627	Remote Control Kit "100" Std.	1.60
15253	Center Main Facing Tool "40" and "45"	(NET) 6.00	55634	Test Propeller "100" T. S.	(NET) 2.50
15289	Test Propeller "40" and "45"	(NET) 1.75	55655	"100" 5" Extension Kit	29.95
15407	Ring Compressor .020 O.S.—"20", "40" and "45"	(NET) 1.50	55670	"100" Fuel Pump Kit with 3/way Valve Only	12.50
15408	Tyco Twist Grip "40" and "45"	8.65	55685	"100" Fuel Tank and Pump Kit with 3/way Valve	39.95
25263	Magneto Puller—Complete	(NET) 1.50	55688A	"100" Ace Remote Control Kit 7'	(NET) 14.95
25285	Screw for Magneto Puller	(NET) .25	55688B	"100" Ace Remote Control Kit 8'	(NET) 14.95
25289	Test Propeller "60", "66" and "75" T. G.	(NET) 1.75	55688C	"100" Ace Remote Control Kit 10'	(NET) 14.95
25306	Ring Compressor "60", "66", "75" T. G. and "75" T. S.	(NET) 1.50	65509	Fuel Tank and Hose "100" and "200"	32.50
25492	Wristpin Punch "60", "66", "75" T. G., "75" T. S., "100" Standard and "100" T. S.	(NET) 1.00	65600	"200" Speed Control Racing Kit	6.95
25628	Centering Ring	(NET) .25	65606	"200" Front Steering Bar Kit	5.50
25671	Abrasive Disc	(NET) .05	65621	Compressor, Piston Ring	(NET) 1.50
25678	Valve Gripping Tool	(NET) 1.50	65624	"200" Fuel Pump Kit Only	9.50
25690	Center Main Facing Tool "60", "66", "75" T. G., and "75" T. S.	(NET) 6.00	65634	Wristpin Punch	(NET) 1.00
25696	Valve Checking Tool Gauge Assembly—Not Available		65640	"200" Remote Control Kit 6'	37.95
25697	Ring Compressor .030 O. S.—"60", "66", "75" T. G. and "75" T. S.	(NET) 1.50	65641	"200" Remote Control Kit 9'	39.95
25719	Offset Screwdriver	(NET) 1.50	65643	"200" Remote Control Kit 15'	43.95
25720	3-M Sealer EC-776 (1 Pint)	(NET) 1.50	65663	Rear Steering Bar Kit	4.50
			65676	Test Propeller	2.50
			65699	"200" Fuel Tank and Pump Kit	39.95
			65828	"200" Flushing Kit	1.40

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTOR NUMERICAL PARTS LIST

SHOWING PART NUMBER — DESCRIPTION — PRICE

MARTIN MOTOR MANUALS

Part No.	Description	Price	Part No.	Description	Price
5079	"20" Owners Manual	1.00	25739	Technical Service Manual 20, 40 and 60	1.00
5106	"20" Owners Manual	1.00	25793	"75" Twist Grip Owners Manual	1.00
5833	Master Manual	(NET) 4.50	25922	"75" Twist Shift Owners Manual	1.00
15220	"40" Owners Manual	1.00	55269	"100" Standard Owners Manual	1.00
15298	"45" Owners Manual	1.00	55455	"100" Twist Shift Owners Manual	1.00
25632	"60" Owners Manual	1.00	65825	"200" Owners Manual (Includes 65743)	1.00

WATERCRAFTMANUALS.COM

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — AND MODEL

MARTIN MOTORS DIVISION OF NATIONAL PRESTO INDUSTRIES, INC.

EAU CLAIRE, WISCONSIN, U. S. A.

Martin Motors

NUMERICAL PARTS LIST

SHOWING PART NUMBER — DESCRIPTION — INTERCHANGEABILITY AND PRICE

EFFECTIVE APRIL 15, 1953

ALL PRICES AND SPECIFICATIONS HEREIN LISTED SUBJECT TO CHANGE WITHOUT NOTICE

x — DENOTES PARTS INTERCHANGEABLE ON MODELS INDICATED.

Part No.	DESCRIPTION	INTERCHANGEABILITY												Price
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL		
5002	Magneto Assembly (Refer to 5088)	x												
5003	Cylinder Head	x												3.20
5004	Gasket—Cylinder Head Compression	x												.06
5005	Cylinder Head Water Gasket	x												.10
5008	Bearing—Lower Main (Refer to 5075)	x												
5009	Gasket—Intake Manifold	x												.02
5011	Cover—Intake Manifold	x												.25
5013	Shroud—Rear	x												3.60
5014	Propeller (Refer to 5072)	x												
5015	Stud—Carburetor	x												.08
5016	Carburetor MD9A	x												12.10
5019	Control Linkage Rod	x												.30
5020	Gasket—Exhaust Port Cover	x												.05
5021	Exhaust Port Cover	x												.25
5024	Gas Tank Assembly (Black)	x												17.00
5032	Gas Line Fitting	x												.85
5033	Decal—Martin "20"	x												.10
5034	Decal—Operating Instructions	x												.10
5035	Retainer—Water Seal (Refer to 25904)	x	x	x	x	x	x							
5036	Oil Seal—Crankshaft Lower	x	x	x	x	x	x	x						.40
5037	Shroud Assembly—Front	x												4.00
5038	Decal—Carburetor Control	x												.10
5041	Gas Line Assembly	x												.90
5044	Crankshaft	x												13.50
5050	Carburetor MD9B	x												12.10
5055A	Decal Set (Prior to '49 Model)	x												.30
5055B	Decal Set ('49 or Later)	x												.30
5056A	Gasket Set	x												.43
5056B	Powerhead Gasket Set	x												.38
5057	Rod Control Linkage (Refer to 5083)	x												
5058	Spark Plug and Washer (Refer to 100-s-4)	x								x	x			
5061	Connecting Rod (Refer to 15014)	x	x	x										
5062	Decal—Martin "20" (Refer to 5033)	x												
5065	Rear Shroud and Flap Assembly	x												4.90
5066	Rear Shroud Spray Shield (Refer to 5093)	x												
5067	Decal—Operating Instructions (Refer to 5034)	x												
5069	Carburetor and Choke Assembly (MD-9A)	x												13.00
5070	Gas Tank (Grey) '49 and Later	x												17.00
5072	Propeller	x												2.85
5074	Decal—Carburetor	x												.10
5075	Bearing—Lower Main (For Motor Series A1-2-3)	x												1.30
5076	Shroud Assembly—Front	x												4.00
5082	Control Linkage Pivot	x												.15
5083	Rod Control Linkage	x												.10
5084	Kit—Choke and Prime Assembly	x												4.25

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL	
5088	Magneto Assembly (Wico Model 1883)	x											29.90
5090	Bearing—Lower Main (For Motor Series A-4)	x											1.30
5092	Rivet	x	x	x									.02
5093	Spray Shield (Includes 4-5092)	x											.90
5099	Shut Off Cock	x											1.65
5101	Choke Control Assembly	x											.92
5102	Choke Stem and Pin	x											.40
5104	Spark Plug and Washer (Refer to 100-s-4)	x							x	x			
5105	Magneto Assembly (FW-2142)	x											29.90
5401	Powerhead (Refer to 5405)	x											
5402	Powerhead—Less Carburetor and Magneto (Refer to 5406)	x											
5403	Cylinder Block and Crankcase Assembly	x											29.00
5404	Lower Unit Assembly (Refer to 15145)	x	x	x									
5405	Powerhead Assembly	x											107.00
5406	Powerhead—Less Carburetor and Magneto	x											71.50
5831	Washer—Shut Off Cock	x	x	x	x	x	x		x	x			.01
5832	Metal Spacer	x	x		x	x							.01
15000	Tank Mounting Bracket—Rear	x	x	x									1.00
15001	Cover—Cylinder Head		x	x									.70
15002	Gasket—Cylinder Head Cover		x	x									.05
15003	Cylinder Head		x	x									3.75
15004	Gasket—Cylinder Head Compression		x	x									.08
15005	Gasket—Cylinder Head Water		x	x									.14
15011	Piston Ring	x	x	x									.40
15012	Lockspring Wristpin	x	x	x									.02
15014	Connecting Rod and Cap Assembly	x	x	x									4.30
15018	Crankshaft		x	x									21.00
15019	Magneto "Wico" (FW-1741B)		x										40.25
15020	Bearing—Upper Main (Refer to 15182)	x	x	x									
15021	Bearing—Lower Main (Refer to 15181)		x	x									
15024	Gasket—Intake Manifold		x	x									.02
15026	Carburetor Assembly (MD 8A)		x										12.65
15027	Speed Control Lever	x	x	x									.25
15028	Valve Assembly (Refer to 15223)	x	x										
15031	Tank Mounting Bracket—Side	x	x										.15
15032	Gasket—Exhaust Port Cover Plate		x										.10
15033	Plate—Exhaust Port Cover		x	x									.55
15034	Gasket—Exhaust Port Cover		x										.10
15035	Cover—Exhaust Port		x										1.35
15036	Gasket—Intake Port Cover	x	x	x									.02
15037	Cover—Intake Port	x	x	x									.10
15038	Stern Bracket Clamping—Left	x	x	x									4.10
15039	Stern Bracket Clamping—Right	x	x	x									4.10
15040	Stern Bracket—Left	x	x	x									3.10
15041	Stern Bracket—Right	x	x	x									3.10
15045	Swivel Bracket	x	x	x									1.80
15046	Swivel Bearing	x	x	x									.10
15047	Motor Support Tube Casing—Front (Available Only as Assembly—Refer to 15247)	x	x										
15048	Motor Support Tube Casing—Rear (Available Only as Assembly—Refer to 15247)	x	x										
15049	Stern Adjusting Screw and Handle	x	x	x									1.50
15051	Pin—Stern Adjusting Anchor	x	x	x									.44
15052	Clevis Pin—Stern Bracket	x	x	x									.44
15053	Pin—Tilting Lever	x	x	x									.10
15054	Spacer—Tilting Lever	x	x	x									.10
15055	Tilt Adjusting Lever	x	x	x									.15
15056	Thrust Socket	x	x	x									1.15
15058	Motor Support Tube Assembly (Refer to 15231)	x	x	x									

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL	
15066	Propeller Shaft	x	x	x									1.80
15067	Pin—Gear and Shaft	x	x	x									.05
15068	Snap Ring—Bevel Gear	x	x	x									.01
15069	Bevel Gear (13-20 Ratio)	x	x	x									4.50
15070	Gasket—Propeller Shaft Bearing Housing	x	x	x									.03
15072	Pump Plate	x	x	x									.20
15073	Pump Rotor	x	x	x									.50
15074	Pump Eccentric	x	x	x									1.20
15075	Water Pump Housing Assembly	x	x	x									1.96
15077	Propeller (Refer to 15206)		x	x									
15078	Friction Clutch	x	x	x									1.20
15084	Gas Tank Assembly (Black) (Prior to '49 Model)		x										17.00
15086	Shroud—Rear		x										3.80
15091	Oil Seal—Crankshaft—Upper	x	x	x									.75
15092	Shut Off Cock	x	x										1.65
15093	Cam Follower Pin	x	x	x	x								.15
15095	Gasket—Motor Support Tube	x	x	x									.10
15096	Gasket—Grease Vent	x	x	x									.01
15098	Bracket—Steering Handle (Refer to 15208)	x	x										
15099	Compression Block—Handle Bracket	x	x	x									.05
15100	Grommet—Handle Bracket	x	x	x									.05
15101	Stud—Handle Bracket	x	x	x									.10
15102	Stabilizer Friction Ring	x	x	x									.20
15103	Piston and Wristpin Assembly	x	x	x									4.60
15103A	Piston and Wristpin Assembly—.0015 Oversize	x	x	x									4.60
15103B	Piston and Wristpin Assembly—.003 Oversize	x	x	x									4.60
15105	Bolt—Tilting Pivot	x	x	x									.15
15106	Washer—Tilting Friction	x	x	x									.03
15109	Cam—Carburetor Control		x		x								.20
15111	Decal—Martin "40"		x										.10
15114	Linkage Lever		x		x								.40
15118	Rod—Linkage Control		x		x								.05
15119	Gear Case and Seal Assembly	x	x	x									8.90
15120	Intake Manifold		x										1.40
15121	Shroud Assembly—Front		x										4.00
15127	Gear Set (13-19 Ratio) (Refer to 15267)	x	x										
15128	Gear Set (13-20 Ratio)	x	x	x									7.50
15134A	Gasket Set		x										.76
15134B	Powerhead Gasket Set		x										.61
15135A	Decal Set (Prior to '49 Model)		x										.30
15135B	Decal Set ('49 Model or Later)		x										.30
15136	Friction Clutch (Refer to 15078)	x	x	x									
15137	Cylinder Block and Crankcase Assembly (Refer to 15191)		x										
15138	Piston and Wristpin Assembly (Refer to 15103)	x	x	x									
15142	Powerhead Assembly (Refer to 15400)		x										
15142A	Powerhead—Less Carburetor and Magneto (Refer to 15401)		x										
15143	Gas Line Assembly		x										.96
15145	Lower Unit Assembly	x	x	x									46.50
15146	Gear Case Assembly	x	x	x									23.50
15147	Stern Bracket Assembly	x	x	x									21.50
15148	Propeller Shaft Bearing Housing and Seal	x	x	x									2.90
15150	Gas Tank Gasket—Lower	x	x										1.80
15151	Gas Tank Gasket—Upper	x	x										.70
15152	Clip—Magneto Wire	x	x	x	x	x	x	x	x				.02
15154	Washer—Gear Case Mounting Screw	x	x	x									.05
15155	Water Pump Housing—Flushing Kit	x	x	x									1.96
15156	Flushing Kit Assembly	x	x	x									2.50
15159	Connecting Rod Screw	x	x	x									.15

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL	
15160	Decal—Instructions Operation		x										.10
15161	Set Screw—Stern Bracket	x	x	x									.10
15164	Swivel Retaining Screw	x	x	x									.08
15173	Lower Bearing Seat Casting (Refer to 25904)	x	x	x	x	x	x						
15176	Carburetor (MD 8B)		x										12.65
15181	Lower Main Bearing		x	x									1.30
15182	Upper Main Bearing	x	x	x									1.35
15185	Stabilizer Friction Washer (No Longer Used)	x	x										
15186	Carburetor and Choke Assembly (MD 8B)		x										13.75
15188	Decal—Rear	x	x		x								.10
15189	Decal—Speed Control (Refer to 25255)	x	x	x	x	x	x						
15190	Decal—Operating Instructions (Refer to 15160)		x										
15191	Cylinder Block and Crankcase Assembly		x										30.00
15195	Rear Shroud and Spray Shield Assembly		x	x									4.90
15198	Gas Tank Assembly (Grey) ('49 Model and Later)		x										17.00
15206	Propeller		x	x									2.95
15208	Bracket—Steering Handle	x	x	x									1.80
15211	Water Outlet Deflector		x										.10
15212	Decal—Carburetor		x		x	x							.10
15213	Shroud Assembly—Front		x										4.00
15214	Gasket—Idle Adjusting Screw Opening	x	x										.01
15223	Valve Assembly	x	x										.80
15224	Kit—Choke and Prime Assembly		x		x								4.25
15226	Tapered Dowel Pin Screw	x	x	x	x	x	x	x					.10
15227	Gasket—Vent Screw	x	x	x									.01
15231	Motor Support Tube Assembly	x	x	x									14.20
15234	Splash Shield		x	x									.88
15237	Lower Unit Stud	x	x	x									.54
15240	Set Screw—Cam Follower (Refer to 9-s-6)	x	x		x								
15247	Motor Support Tube Casing—Front and Rear	x	x	x									8.00
15252	Tank Mounting Bracket—Side		x										.35
15254	Water Pump Seal	x	x	x									.05
15256	Carter Carburetor (N-752-SA)			x									10.80
15258	Exhaust Baffle Plate		x										.75
15260	Cover—Exhaust Port		x	x									1.40
15261	Gasket—Exhaust Port Cover		x	x									.12
15262	O'Ring Valve	x	x	x									.25
15266	O'Ring Valve Assembly	x	x	x									1.20
15267	Gear Set (13-19 Ratio)	x	x										7.50
15268	Bevel Gear (13-19 Ratio—Sold in Sets Only) (Refer to 15267)	x	x										
15269	Pinion Gear (13-19 Ratio—Sold in Sets Only) (Refer to 15267)	x	x										
15274	Gas Tank and Decal Assembly			x									17.00
15275	Decal—Operating Instructions			x									.10
15276	Decal—Side			x									.10
15277	Gas Line Assembly			x									.96
15279	Shroud Assembly—Front			x									4.00
15284	Tank Mounting Bracket—Left			x									.40
15285	Tank Mounting Bracket—Right			x									.40
15288	Gasket—Carburetor (Used on "45" Motors Prior to Serial No. BB-58532)			x									.04
15292	Cylinder Block and Crankcase Assembly			x									30.00
15296	Carter Carburetor with Linkage Control (N-752S)			x									12.80
15302	Orifice Plate (For Motors after Serial No. BB-58532—Used with Manifold 15303)			x									.15
15303	Intake Manifold (For Motors after Serial No. BB-58532—Used with Orifice Plate 15302)			x									1.40
15310	Stud Carburetor			x									.08
15317	Tank Mounting Bracket Screw	x	x	x									.03

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price		
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL			
15318	Tank Mounting Locating Screw	x	x	x											.06
15322	Shut Off Cock			x					x						1.88
15323	Stem—Choke Control			x					x						.25
15324	Choke Control Assembly			x					x						.94
15325	Choke Stem and Pin Assembly			x					x						.35
15326	Cup Washer	x	x	x	x	x	x	x							.06
15329	Magneto (FW-2132)		x	x											40.25
15334	Carter Carburetor with Linkage Control (N-2021S)			x											12.80
15400	Powerhead Assembly		x												130.00
15401	Powerhead—Less Carburetor and Magneto		x												83.50
15402	Piston and Wristpin—.020 Oversize	x	x	x											4.60
15403	Piston Ring—.020 Oversize	x	x	x											.50
15409	Decal Set			x											.30
15411	Powerhead with Carburetor and Magneto			x											130.00
15412	Powerhead—Less Carburetor and Magneto			x											83.50
15413A	Gasket Set			x											.77
15413B	Powerhead Gasket Set			x											.62
15502	Stern Bracket (Refer to 15147)	x	x	x											
25000	Gearcase Housing (Refer to 25416)				x	x	x								
25003	Propeller Shaft Bearing Housing Assembly (Refer to 25419)				x	x	x								
25004	Intermediate Housing				x	x	x								9.00
25005	Pump Plate				x	x	x								.30
25009	Water Pump Housing Assembly (Refer to 25155)				x	x	x								
25010	Propeller Shaft				x	x	x								2.40
25011	Propeller Shaft and Gear Assembly				x	x	x								6.60
25012	Pump Eccentric				x	x	x								1.00
25013	Driveshaft (Refer to 25290)	x	x	x	x	x	x								
25017	Stud Gearcase and Intermediate Housing Retainer (Rear)				x	x	x								.44
25018	Stud Gearcase and Intermediate Housing Retainer (Front)				x	x	x								.44
25020	Motor Support Tube Assembly				x	x	x								11.20
25023	Pin Stern Adjusting Arm Clevis				x	x	x	x	x	x					.55
25027	Bearing—Swivel				x	x	x	x							.15
25029	Thrust Socket				x	x	x								1.20
25030	Motor Support Tube Casing—Available Only as Assembly 25682				x	x	x								
25031	Cylinder Head Cover				x	x	x	x							.75
25032	Lever Stern Adjusting Tilting				x	x	x								.32
25033	Key Reverse Stop				x	x	x	x	x	x					.03
25036	Swivel Bracket				x	x	x	x							1.80
25039	Tube—Drive Shaft Seal Extension				x	x	x								1.50
25040	Cylinder Head				x	x	x	x							4.25
25043	Motor Support Tube Casing Assembly—Rear (Available Only as Complete Assembly—Refer to 25682)				x	x	x								
25045	Spacer—Stern Adjusting Arm Thrust Socket				x	x	x	x	x	x					.15
25046	Thrust Washer—Motor Support Tube	x	x	x	x	x	x	x	x	x					.05
25047	Gasket—Exhaust Port Cover Plate				x	x	x	x							.15
25048	Exhaust Port Cover				x	x	x	x							1.45
25049	Plate—Exhaust Port Cover				x	x	x	x							.60
25051	Cam Follower	x	x	x	x										.85
25052	Stern Bracket—Left				x	x	x	x							2.85
25053	Stern Bracket—Right				x	x	x	x							2.85
25054	Pinion Gear (13-20 Ratio)	x	x	x	x	x	x								3.00
25055	Bevel Gear				x	x	x								4.10
25061	Pressure Pad—Clamp Screw	x	x	x	x	x	x	x	x	x					.06
25064	Lockspring Wristpin				x	x	x	x	x	x					.02
25065	Gasket—Intake Port				x	x	x	x							.02

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price	
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL		
25070	Stud Tilting				x	x	x	x						.30
25071	Water Seal (C1 and C2)				x			x						.06
25073	Water Inlet Tube Assembly (C1 and C2)				x									.64
25074	Motor Support Tube Gasket				x	x	x							.15
25076	Intake Port Cover				x	x	x	x						.15
25077	Connecting Rod Assembly—Used on C1-“60” Motors				x									4.30
25082	Gasket—Seal Retainer				x									.05
25084	Pin—Pump Eccentric	x	x	x	x	x	x							.01
25085	Propeller Nut	x	x	x	x	x	x							.40
25087	Gasket—Propeller Shaft Bearing Housing				x	x	x							.03
25088	Crankshaft—Used on C1 “60” Only				x									22.00
25089	Pump Rotor				x	x	x							.75
25090	Snap Ring—Water Pump	x	x	x	x	x	x							.01
25093	Water Seal Pump Housing and Gearcase				x	x	x							.05
25095	Gasket—Cylinder Head Cover				x	x	x	x						.05
25096	Bolt—Starter Pivot	x	x	x	x	x	x	x						1.00
25098	Pawl Retainer Spacer	x	x		x									.03
25103	Spring—Starter Rewind	x	x	x	x	x	x	x						.95
25104	Hook—Starter Rope	x	x	x	x	x	x	x						.05
25107	Spring Starter Compression	x	x	x	x	x	x	x						.08
25109	Anchor Starter Spring	x	x	x	x	x	x	x						.34
25113	Ratchet Ring Starter	x	x	x	x	x	x	x						.80
25114	Cylinder Block and Crankcase Assembly (Refer to 25908)				x	x								
25121	Pawl Retainer Assembly	x	x	x	x	x	x	x						1.60
25124	Plug—Starter Handle (Refer to 25206)	x	x	x	x	x	x	x	x	x				
25125	Starter Handle	x	x	x	x	x	x	x	x	x				.25
25126	Starter Cord Assembly (Refer to 25251)	x	x	x	x	x	x	x						
25127	Starter Pulley Assembly	x	x	x	x	x	x	x						2.40
25129	Washer—Fixed Contact Clamp Screw (Refer to 2965F)	x	x	x	x	x	x	x	x	x				
25130	Screw—Fixed Contact Clamp (Refer to 5431F)	x	x	x	x	x	x	x	x	x				
25131	Shoe Mounting Screw (Refer to 5431F)	x	x	x	x	x	x	x	x	x				
25139	Seal Assembly (Refer to 25905)	x	x	x	x	x	x							
25140	Stern Adjusting Screw and Handle Assembly				x	x	x	x						1.55
25141	Pin Stern Adjusting Anchor				x	x	x	x						.55
25142	Spacer—Stern Bracket				x	x	x	x	x	x				.15
25143	Stud—Tilt Adjusting Lever (Refer to 25333)				x	x	x	x						
25145	Clamp Screw and Handle Assembly	x	x	x	x	x	x	x	x	x				.65
25146	Stern Bracket and Clamp Screw Assembly—Right				x	x	x	x						4.50
25147	Stern Bracket and Clamp Screw Assembly—Left				x	x	x	x						4.50
25150	Stabilizer Friction Ring				x	x	x	x						.15
25154	Pins—Journal Bearing Location	x	x	x	x	x	x	x						.01
25155	Water Pump Housing Assembly				x	x	x							1.80
25156	Shear Pin	x	x	x	x	x	x							.02
25157	Friction Clutch Assembly				x	x	x							1.00
25158	Stud—Thrust Socket Fastener (Refer to 25334)	x	x		x									
25159	Propeller (Refer to 25614)				x	x	x							
25166	Spring Valve	x	x	x	x	x	x	x						.10
25170	Cam Follower Spacer Washer	x	x	x	x									.01
25173	Pivot Bolt Cover	x	x	x	x	x	x	x						.20
25176	Starter Housing	x	x		x									6.00
25177	Lid—Filler Cap (Refer to 25407)	x	x	x	x	x	x	x						
25178	Steering Handle Bracket (Refer to 25613)				x	x	x							
25179	Steering Handle (Refer to 25612)	x	x		x									
25180	Mounting Bracket—Gas Tank—Rear				x	x	x	x						.95
25181	Speed Control Knob (Refer to 25611)	x	x	x	x	x	x	x						
25182	Bearing—Lower Main				x	x	x	x						1.80
25183	Bearing—Upper Main (Refer to 25185)				x	x	x	x						

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL	
25184	Bearing—Lower Main (Refer to 25182)				x	x	x	x					
25185	Bearing—Upper Main				x	x	x	x					1.35
25187	Gasket—Cylinder Compression				x	x	x	x					.10
25188	Tank Seal (Refer to 25909)	x	x	x	x	x	x	x					
25189	Water Seal Gasket				x	x	x	x					.20
25191	Gasket—Spark Plug		x	x	x	x	x	x					.01
25195	Pin—Cam Follower				x								.15
25197	Stud—Carburetor		x	x	x	x	x	x					.05
25198	Gasket—Intake Manifold				x	x	x	x					.02
25199	Gasket—Carburetor	x	x		x	x							.01
25200	Gasket—Exhaust Port Plate				x	x	x	x					.15
25202	Mounting Bracket—Gas Tank—Side (Refer to 25672)				x								
25203	Carburetor Assembly (MD 5A)				x								12.65
25205	Speed Control Lever				x	x	x	x					.20
25206	Starter Handle Plug Assembly	x	x	x	x	x	x	x	x				.50
25207	Shear Pin Support Bracket	x	x	x	x	x	x	x					.10
25208	Filler Cap Latch (Grey)	x	x		x								.50
25209	Air Vent Bushing	x	x	x	x	x	x	x					.12
25210	Air Vent Screw	x	x	x	x	x	x	x	x				.10
25213	Small Set Screw—Carburetor Control Knob	x	x		x								.01
25215	Carburetor Link Control Assembly (MD 15B)				x	x							13.75
25217	Decal—Martin "60" (Refer to 25258)				x								
25218	Screw—Shroud Mounting	x	x	x	x	x	x	x					.02
25219	Spray Shield Assembly				x	x	x	x					1.00
25220	Stabilizer Compression Block	x	x	x	x	x	x	x	x				.03
25221	Stabilizer Compression Plate	x	x	x	x	x	x	x	x				.03
25222	Seal—Water Outlet Deflector (Refer to 25905)				x								
25223	Piston Ring				x	x	x	x					.40
25224	Dowel Pin	x	x		x								.03
25225	Bolt—Steering Handle Bracket				x	x	x						.05
25226	Grommet—Steering Handle				x	x	x	x	x	x			.05
25227	Pressure Pad—Steering Handle Bracket				x	x	x	x					.05
25228	Washer—Steering Handle Bracket				x	x	x	x					.02
25233	Control Linkage Rod				x								.15
25235	Control Linkage Spring	x	x		x								.03
25236	Pivot Control Linkage	x	x		x								.05
25239	Grip—Steering Handle (Refer to 25342)	x	x		x								
25240	Screw—Cam Follower Pin (Refer to 9-s-6)	x	x	x	x	x	x	x					
25242	Clip—Magneto Wire (Refer to 15152)	x	x	x	x	x	x	x	x				
25243	Stabilizer Friction Washer				x	x	x	x	x	x			.20
25244	Starter Bias Spring	x	x	x	x	x	x	x					.15
25245	Grease Plug	x	x	x	x	x	x	x	x				.02
25248	Valve Assembly (Refer to 25642)				x	x							
25249	Shut Off Cock (Used on "60" Model Prior to Serial No. C-64817)				x								1.50
25251	Starter Cord and Handle Assembly	x	x	x	x	x	x	x					1.90
25254	Gas Line Fitting Screen		x	x	x	x	x	x					.65
25255	Decal—Speed Control	x	x	x	x	x	x						.10
25256	Decal—Operating Instructions (Refer to 25370)				x	x							
25257	Decal—Carburetor		x		x								.10
25258	Decal—Side				x								.10
25259	Decal—Rear	x	x		x								.10
25262	Gas Line Assembly				x	x	x						.96
25266	Oil Seal—Crankshaft—Upper				x	x	x	x					.72
25267	Gasket—Grease Vent	x	x	x	x	x	x						.01
25268	Gasket—Grease Plug	x	x	x	x	x	x						.01
25269	Washer—Starter Pivot Bolt	x	x	x	x	x	x	x					.01
25270	Carburetor Control Cable Assembly	x	x		x								.70
25271	Retainer—Filler Cap	x	x	x	x	x	x						.10

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY												Price
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL		
25273	Spring Washer	x	x	x	x	x	x	x					.05	
25275	Shut Off Cock	x	x	x	x	x	x						1.50	
25276	Filler Cap Assembly (Grey)	x	x		x								2.50	
25278	Tension Spring—Filler Cap (Refer to 25609)	x	x	x	x	x	x	x						
25281	Swivel Locking Pin Assembly	x	x	x	x	x	x	x					.25	
25284	Swivel Retainer Screw	x	x	x	x	x	x						.08	
25286	Washer—Tilting Friction				x	x	x	x	x	x			.05	
25287	Friction Washer—Steering Handle	x	x		x								.01	
25290	Driveshaft	x	x	x	x	x	x						3.15	
25292	Piston and Wristpin Assembly				x	x	x	x					4.50	
25292A	Piston and Wristpin Assembly—.0015 Oversize				x	x	x	x					4.50	
25292B	Piston and Wristpin Assembly—.003 Oversize				x	x	x	x					4.50	
25292C	Piston and Wristpin Assembly—.030 Oversize				x	x	x	x					4.50	
25293	Gasket—Lower Seal	x	x	x	x	x	x	x					.05	
25294	Magneto Wico (FW-1740B)				x								40.25	
25295	Seal—Lower Main Bearing (Refer to 25904)	x	x	x	x	x	x							
25296	Water Inlet Tube	x	x	x	x	x	x						.75	
25297	Washer—Water Tube	x	x	x	x	x	x						.02	
25298	Cam Spacer—Wico Magneto		x	x	x	x	x	x					.03	
25300	Carburetor (MD 15A)				x								12.65	
25301	Extension Drive Shaft				x	x	x						4.70	
25302	Stud—Lower Unit Extension—Short				x	x	x						.55	
25303	Stud—Lower Unit Extension—Long				x	x	x						.55	
25304	Water Inlet Tube Extension C-1				x								1.10	
25307	Lower Unit Extension Kit—C-1 and C-2				x								11.65	
25308	Shim Extension Intermediate Housing				x	x	x						4.75	
25310	Magneto Scintilla				x								25.00	
25311	Scintilla Flywheel and Cam Assembly				x								10.00	
25314	Scintilla Adapter				x								1.50	
25315	Cam Spring Washer (Refer to 3081F)	x	x	x	x	x	x	x						
25316	Lower Unit Extension Kit—C-3 and C-4				x	x	x						11.65	
25317	Water Inlet Tube—C-3				x	x	x						1.10	
25321	Idle Adjusting Screw (Refer to 08427)				x	x								
25324A	Gasket Set (C-1 and C-2)				x								.99	
25324B	Powerhead Gasket Set (C-1 and C-2)				x								.79	
25325A	Gasket Set (C-3 and C-4)				x	x							.99	
25325B	Powerhead Gasket Set (C-3 and C-4)				x	x							.79	
25325C	Gasket Set						x						1.00	
25326A	Decal Set (Prior to '49 Model)				x								.30	
25326B	Decal Set (After '49 Model)				x								.30	
25327	Friction Clutch Assembly (Refer to 25157)				x	x	x							
25333	Stud—Tilt Adjusting Lever				x	x	x	x					.30	
25334	Stud—Thrust Socket	x	x	x	x	x	x	x					.15	
25337	Grease Fitting				x	x	x	x	x	x			.12	
25338	Recoil Starter Spring Spacer	x	x	x	x	x	x	x					.04	
25339	Compression Nut	x	x	x	x	x	x	x	x	x			.10	
25340	Compression Sleeve	x	x	x	x	x	x	x	x	x			.03	
25341	Choke Control Assembly		x		x	x							.90	
25342	Grip—Steering Handle	x	x		x								.20	
25344	Connecting Rod Screw				x	x	x	x					.24	
25353	Crankshaft				x	x	x	x					22.00	
25354	Connecting Rod Assembly				x	x	x	x					4.30	
25359	Set Screw—Carburetor Control Knob	x	x	x	x	x	x	x	x	x			.01	
25364	Choke Stem and Pin Assembly (Refer to 25341)		x		x	x								
25366	Flushing Kit Plug	x	x	x	x	x	x	x	x	x			.10	
25367	Nozzle—Flushing Kit (Refer to 25686)	x	x	x	x	x	x	x	x	x				
25368	Water Pump Housing—Flushing Kit				x	x	x						2.00	
25369	Flushing Kit Assembly				x	x	x						2.80	
25370	Decal—Operating Instructions				x	x							.10	
25378	Grease Plug—Large	x	x	x	x	x	x	x	x	x			.10	

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price	
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL		
25379	Gasket—Grease Plug	x	x	x	x	x	x	x	x	x				.01
25400	Cylinder Block and Crankcase Assembly (Refer to 25908)				x	x								
25401	Piston and Wristpin Assembly (Refer to 25292)				x	x	x	x						
25401A	Piston and Wristpin Assembly (Refer to 25292A)				x	x	x	x						
25401B	Piston and Wristpin Assembly (Refer to 25292B)				x	x	x	x						
25402	Key—Magneto	x	x	x	x	x	x	x						.10
25403	Intake Manifold Assembly				x	x	x							1.30
25404	Collar Assembly—Control Linkage	x	x		x									.25
25405	Powerhead Assembly (Refer to 25618)				x	x								
25406	Cord and Anchor Assembly	x	x	x	x	x	x	x						1.25
25407	Filler Cap (Grey) (Prior to '49 Model)	x	x	x	x	x	x	x						1.10
25408	Gas Tank Assembly (Black) (Prior to '49 Model)				x									21.00
25409	Shroud Assembly—Front				x									3.85
25410	Knob Assembly—Carburetor Control with Screw	x	x		x									.35
25411	Knob Assembly—Carburetor Shut Off with Screw	x	x		x									.30
25413	Stern Bracket Assembly				x	x	x							24.00
25414	Lower Unit Assembly (Refer to 25518)				x	x	x							
25415	Gearcase Assembly				x	x	x							28.60
25416	Gearcase Housing				x	x	x							10.60
25417	Propeller Shaft and Gear				x	x	x							9.50
25418	Gears (Ring and Pinion)				x	x	x							7.10
25419	Propeller Shaft Bearing Housing				x	x	x							2.60
25422	Seal—Lower Main Bearing (Refer to 25904)	x	x	x	x	x	x							
25423	Ring—Lower Main Seal	x	x	x	x	x	x	x						.24
25428	Tube—Drive Shaft Seal	x	x	x	x	x	x							1.20
25429	Tube Seal Spacer	x	x	x	x	x	x							.03
25449	Air Vent Screw Pad	x	x	x	x	x	x	x						.05
25453	Arm—Choke Control		x		x	x								.05
25454	Choke Control Linkage	x	x	x	x	x	x	x						.03
25455	Bracket—Choke Control	x	x		x	x								.16
25459	Seal—Gearcase Grease	x	x	x	x	x	x							.05
25461	Spacer—Drive Shaft Seal	x	x	x	x	x	x							.02
25465A	Drive Shaft Seal Assembly	x	x	x	x	x	x							3.30
25465B	Drive Shaft Seal Assembly—Long				x	x	x							3.30
25468	Set Screw—Carburetor Control Knob (Refer to 25359)	x	x	x	x	x	x	x	x	x				
25486	Carburetor (MD 15B)				x	x								12.65
25487	Carburetor Control Knob	x	x	x	x	x	x	x						.50
25501	Starter and Cover Assembly (Grey) (Prior to '49 Model)	x	x		x									19.80
25502	Powerhead (Refer to 25618)				x	x								
25503	Stern Bracket Assembly (Refer to 25413)				x	x	x							
25518	Lower Unit Assembly				x	x	x							45.50
25550	Steering Handle and Bracket Assembly							x						24.00
25600	Fuel Tank (Grey) ('49 and Later)				x									21.00
25601	Starter Housing (Black) (Refer to 25650)	x	x	x	x	x	x	x						
25603	Filler Cap Latch (Black) (Refer to 25652)	x	x	x	x	x	x	x						
25604	Filler Cap Assembly (Refer to 25910)	x	x	x	x	x	x							
25605	Spark Plug Nipple	x	x	x	x	x	x	x	x	x				.25
25609	Tension Spring Filler Cap	x	x	x	x	x	x	x						.03
25611	Speed Control Knob	x	x	x	x	x	x	x						.65
25612	Steering Handle	x	x		x									1.55
25613	Steering Handle Bracket				x	x	x							1.80
25614	Propeller				x	x	x							3.00
25616	Shroud—Rear				x	x	x	x						3.85
25617	Swivel Retaining Screw	x	x	x	x	x	x	x						.14
25618	Powerhead Complete				x	x								138.00
25619	Starter and Cover Assembly	x	x	x	x	x	x							19.80
25620	Powerhead—Less Carburetor and Magneto				x	x								91.50

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL	
25623	Shroud Assembly—Front				x	x							4.40
25624	Filler Cap (Black) ('49 Model and Later)	x	x	x	x	x	x						1.10
25637	Motor Support Tube Casing—Front (Refer to 25682)				x	x	x						
25640	Cam Follower Pin Screw				x	x	x	x					.15
25641	Cam Follower				x	x	x	x					.75
25642	Valve Assembly				x	x							.75
25644	Choke Shaft and Primer (Refer to 08531)		x		x	x							
25650	Starter Housing (Black) ('49 Model and Later)	x	x	x	x	x	x	x					5.50
25652	Filler Cap Latch ('49 Model and Later)	x	x	x	x	x	x	x					.50
25672	Mounting Bracket—Side				x	x	x						.50
25682	Motor Support Tube Casing—Front and Rear				x	x	x						9.40
25683	Screw Plug—Flushing Kit	x	x	x	x	x	x		x				.50
25684	Fiber Washer—Flushing Kit	x	x	x	x	x	x	x	x	x			.02
25685	Coupling—Flushing Kit	x	x	x	x	x	x	x	x	x			.25
25686A	Nozzle—Flushing Kit—Metal	x	x	x	x	x	x		x				.72
25686B	Flushing Plug Kit							x		x			.84
25688	Piston Ring—.030 Oversize				x	x	x	x					1.40
25691A	Stainless Steel Water Inlet Tube (C-3 and C-4)	x	x	x	x	x	x						1.50
25691B	Stainless Steel Water Inlet Tube—Extension				x	x	x						2.00
25695	Gearcase Seal	x	x	x	x	x	x						.10
25698	Carburetor—Carter N-753S						x	x					10.80
25699	Tank Seal (Refer to 25909)	x	x	x	x	x	x	x					
25700	Propeller Nut—Brass	x	x	x	x	x	x						.90
25741A	Stainless Steel Water Tube (C-1 and C-2)				x								1.50
25741B	Stainless Steel Water Tube—Extension (C-1 and C-2)				x								2.00
25742	Carter Carburetor—Linkage and Choke Control (N-753S)						x	x					12.80
25743	Elbow Fitting			x			x	x					.55
25744	Shut Off Cock			x			x	x					1.55
25745	Choke Control Assembly			x			x	x					.90
25746	Bracket—Choke Control			x			x	x					.20
25747	Choke Pin and Stem Assembly			x			x	x					.30
25749	Decal—Operating Instructions						x	x					.10
25750	Shroud Assembly—Front						x						4.40
25751	Decal—Carburetor Control			x			x	x					.10
25752	Gas Line Assembly						x	x					.75
25755	O'Ring Valve ('49 Model and Later)				x	x	x	x					1.10
25759	Bevel Gear (13-19 Ratio)				x								3.85
25760	Pinion Gear (13-19 Ratio)				x								2.75
25762	Cam Follower Pin Insert Bushing				x	x	x	x					.35
25765	Propeller Shaft and Gear Assembly				x								6.60
25767	"66" Gas Tank Assembly						x						21.00
25768	Decal—Martin "66"						x						.10
25778	Tank Mounting Bracket—Intake Side						x	x					.70
25787	Decal Set "66"						x						.30
25790	Gear Set (13-19 Ratio)				x								6.60
25794	Gas Tank and Decal Assembly "75" Twist Grip						x						21.00
25796	Decal—Martin "75"						x	x					.10
25797	Cam—Carburetor Control			x									.20
25799	Decal—Rear			x			x						.10
25807	Lever—Throttle Control							x		x			.10
25810	Guide Screw—Steering Handle							x		x			.04
25814	Bracket—Steering Handle							x					4.50
25815	Handle—Steering							x		x			4.20
25827	Decal—Rear							x					.10
25828	Shroud Assembly—Front							x					4.30
25836	Bracket—Cable Support							x					.20
25838	Spring—Clutch Lever							x		x			.10

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY										Price	
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS		200 SL
25840	Plug—Steering Handle								x		x		.45
25841	Locknut Cable Adjusting Screw								x		x		.02
25842	Tube Assembly—Clutch Control								x		x		5.30
25843	Cover Plate—Steering Handle								x		x		.60
25845	Button and Rod Assembly								x		x		1.20
25846	Collar Assembly								x		x		.30
25848	Spring—Throttle Control								x		x		.02
25849	Eccentric Assembly								x		x		.50
25852	Orifice Plate—Carburetor							x	x				.06
25854	Spacer Tank Seal (Refer to 25931)	x	x	x	x	x	x	x	x				
25856	Upper Drive Shaft								x				4.50
25857	Tube—Drive Shaft Enclosure								x				1.20
25859	Reversing Lock								x				.10
25860	Thrust Socket				x	x	x	x					1.20
25861	Tube Neutral Cable (Refer to 25878)								x				
25862	Bracket—Tube Support								x				.50
25863	Water Inlet Tube (Refer to 25949)								x				
25867	Motor Support Tube Assembly (Refer to 26032)								x				
25869	Neutral Clutch Lever								x				.50
25870	Seal Assembly—Lower Main Bearing								x				2.38
25871	Upper Cable Assembly (Refer to 25907)								x				
25874	Gasket—Motor Support Tube								x				.20
25875	Propeller								x				3.50
25876	Decal—Speed Control								x				.10
25877	Gas Tank and Decal Assembly								x				21.00
25878	Control Cable, Boot and Tube								x				3.50
25880	Filler Cap								x				1.30
25885	Torque Tube Assembly								x		x		8.40
25886	Gear and Shaft Pin				x	x	x						.25
25887	O'Ring—Enclosure Tube								x		x		.24
25888	Bracket—Throttle Control								x				.20
25889	Cable Clamp—No Longer Used								x				
25890	Clamp—Cable Nut—No Longer Used								x				
25893	Cylinder Block and Crankcase Assembly								x				33.00
25896	Cap—Grommet Retainer								x				.06
25897	Throttle Control Cable								x				1.90
25898	Spring—Neutral Lever Return								x				.15
25903	Gasket—Lower Main Bearing Seal	x	x	x	x	x	x	x					.05
25904	Seal—Lower Main Bearing	x	x	x	x	x	x						1.55
25905	Seal Assembly—Lower Main Bearing	x	x	x	x	x	x						2.50
25906	Grommet—Water Tube	x	x	x	x	x	x						.03
25907	Upper Cable Assembly								x				2.75
25908	Cylinder Block and Crankcase Assembly				x	x							33.00
25909	Tank Seal	x	x	x	x	x	x	x					.30
25910	Filler Cap Assembly	x	x	x	x	x	x						2.50
25919	Intake Manifold Assembly							x	x				1.25
25920	Carburetor Control—Cam								x				.20
25921	Cam—Carburetor Control						x	x					.20
25924	Sleeve—Starting Housing			x				x	x				.04
25925	Spring Washer	x	x	x	x	x	x	x					.10
25926	Adjusting Screw—Clutch Lever (Refer to 25878)								x		x		
25927	Motor Support Tube Casing Assembly								x				9.80
25930	Locknut—Cable Adjusting Screw								x				.03
25931	Spacer—Tank Seal	x	x	x	x	x	x	x					.02
25936	Water Pump Gasket								x		x		.03
25945	Snap Ring				x	x	x						.03
25946	Screw—Rear Tank Bracket Locating				x	x	x	x					.05
25948	Swivel Retaining Screw	x		x					x				.14
25949	Water Inlet Tube								x				1.00
25952	Magneto (FW-2141)				x	x	x	x					40.25

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL	
25955	Carter Carburetor (N-2022S)						x	x					10.80
25956	Carter Carburetor Linkage and Choke Control Assembly (N-2022S)						x	x					12.80
26000	Decal Set—Syncro Twist						x						.30
26002	Lower Unit Assembly							x					98.00
26003	Gear Case Assembly							x		x			42.00
26004	Gear Case Housing Assembly							x		x			13.25
26006	Intermediate Housing—Lower							x		x			12.50
26007	Bearing Plate (Refer to 55710)							x		x			
26008	Motor Support Tube Assembly (Refer to 26032)								x				
26009	Steering Handle Assembly								x				18.00
26010	Powerhead Assembly Complete								x				138.00
26011	Powerhead—Less Carburetor and Magneto								x				91.50
26012	Starter and Cover Assembly								x				19.80
26013	Filler Cap Assembly								x				2.50
26014	Stern Bracket Assembly				x	x	x	x					24.00
26016	Powerhead "75" Syncro Twist						x						138.00
26017	Powerhead—Less Carburetor and Magneto "75" Syncro Twist						x						91.50
26018A	Gasket Set								x				1.25
26018B	Powerhead Gasket Set						x	x					.80
26019	Decal Set								x				.30
26020	Cylinder Block and Crankcase						x						33.00
26021	Steering Handle Sub Assembly								x		x		9.90
26032	Motor Support Tube Assembly								x				11.50
55000	Cylinder Block and Crankcase Assembly (Refer to 55608)									x			
55001	Cam Follower—Lower								x	x			.62
55002	Cam Follower—Upper								x	x			.62
55003	Cylinder Head								x	x			8.00
55004	Cylinder Head Gasket								x	x			.20
55011	Piston Ring								x	x			.40
55013	Piston and Wristpin Assembly								x	x			4.90
55015	Connecting Rod and Cap Assembly (Includes Needles)								x	x			10.20
55016	Spring—Magneto Cam (Refer to 55185)								x	x			
55018	Crankshaft								x	x			30.00
55019	Magneto (FW-1927)								x	x			43.15
55020	Upper Main Bearing—Orange								x	x			6.80
55021	Lower Main Bearing—Torrington								x				2.75
55022	Pin—Bearing Locating								x	x			.08
55024	Gasket—Intake Manifold								x	x			.04
55025	Intake Manifold								x	x			1.75
55026	Spacer—Cam Follower								x	x			.01
55027	Spark Plug Insulator								x				.75
55028	Spark Plug and Washer (Refer to 100-s-4)	x		x					x	x			
55029	Main Bearing Seal								x	x			.60
55030	Reed Seal								x	x			.03
55031	Cam Follower Pin								x	x			.25
55032	Gasket—Exhaust Port Cover								x	x			.15
55033	Exhaust Port Cover Plate								x	x			.35
55034	Taper Dowel Screw								x	x			.10
55035	Exhaust Port Cover								x	x			1.25
55036	Gasket—Intake Port Cover								x	x			.04
55037	Intake Port Cover								x	x			1.10
55038	Gasket—Lower Main Cap								x	x			.04
55039	Cap—Lower Main								x				.20
55040	Stern Bracket—Right								x	x			4.00
55041	Stern Bracket—Left								x	x			4.00
55043	Upper Seal—Water Tube								x	x			.10

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price	
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL		
55045	Gasket—Motor Support Tube								x	x				.15
55046	Stabilizer Friction Ring								x					.60
55047	Motor Support Tube Casing (Refer to 55295)								x					
55049	Stern Adjusting Screw and Handle								x	x				1.50
55050	Carter Carburetor (N 754SA)								x	x				10.80
55051	Pin—Stern Adjusting Anchor								x	x				.80
55052	Adapter—Safety Chain								x	x				.06
55053	Bolt—Stern Bracket								x	x				.45
55054	Bolt—Thrust Socket								x	x				.30
55055	Tilt Adjusting Lever								x	x				.45
55056	Thrust Socket								x	x				1.50
55057	Intermediate Housing								x					11.40
55058	Motor Support Tube Assembly (Refer to 55639)								x					
55060	Reversing Lock								x	x				.12
55061	Bearing Ball—Propeller Shaft								x	x	x			3.00
55062	Water Inlet Tube								x					.80
55063	Pin—Gear and Propeller Shaft								x					.06
55064	Water Pump Housing Assembly								x					2.00
55067	Lower Unit Long Stud								x					.45
55068	Short Stud—Lower Unit								x					.24
55069	Pump Rotor (Refer to 55476)								x					
55071	Pin—Pump Rotor								x					.05
55072	Propeller Shaft								x					6.70
55073	Zerol Bevel Gear								x					4.80
55074	Zerol Bevel Pinion								x	x				4.40
55076	Tube—Drive Shaft Enclosure								x					1.10
55078	Drive Shaft								x					3.50
55080	Bearing—Drive Shaft								x	x	x			.90
55081	Lower Seal—Water Tube								x					.02
55082	Needle Bearing—Drive Shaft								x	x	x			.80
55089	Instruction Plate								x	x				.50
55090	Bolt—Bracket Mounting								x	x				.18
55091	Bolt—Rear Tank Mounting (Refer to 55090)								x					
55105	Gas Line Fitting								x	x				.98
55106	Gas Line and Fitting Assembly								x	x				2.05
55108	Cable—Vent Seal Control								x					1.30
55109	Collar—Flexible Vent Cable								x					.20
55110	Speed Control Lever								x	x				.40
55111	Link—Speed Control								x	x				.15
55112	Stator Lever								x	x				.20
55113	Pivot—Speed Control Lever								x	x	x			.15
55114	Hinge Pin—Speed Control Lever								x	x				.10
55115	Wave Washer—Speed Control Lever								x	x				.01
55116	Speed Control Knob								x	x				2.20
55118	Vent Tube—Upper—No Longer Used								x					
55121	Sleeve—Speed Control Lever								x	x				.06
55122	Spring—Choke Control								x	x				.04
55123	Spring Air Vent—No Longer Used								x					
55125	Bracket—Steering Handle (Refer to 55361)								x					
55126	Handle—Steering								x					4.60
55127	Bushing—Steering Handle								x	x	x			.18
55128	Grip—Steering Handle								x					.24
55129	Button Throttle Control								x					.42
55130	Rod Throttle Control								x					.35
55131	Spring—Throttle Control								x					.06
55132	Throttle Control Lever Assembly								x					.34
55134	Ring—Steering Handle Retaining (Refer to 55182)								x					
55135	Inner Washer—Steering Handle								x	x	x			.10
55136	Outer Washer—Steering Handle								x	x	x			.15
55137	Screw—Throttle Control Lever								x	x	x			.06

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL	
55138	Cable—Throttle Control							x	x			1.85	
55139	Clip—Throttle Control			x				x	x	x		.05	
55141	Shoe Spring—Throttle Control							x	x	x		.05	
55142	Pin—Throttle Control Bracket								x	x		.15	
55143	Disc—Throttle Control Grommet							x	x	x		.02	
55144	Ring—Throttle Control Button							x	x	x		.22	
55145	Screw—Friction Shoe							x	x	x		.03	
55146	Cover Plate—Steering Handle								x			.30	
55147	Grommet Cap								x	x		.04	
55148	Clamp—Flexible Vent Tube								x			.05	
55149	Grommet—Throttle Control								x	x		.05	
55151	Tab—Pawl Friction								x	x		.12	
55152	Spring—Starter Pawl								x	x		.04	
55153	Pawl Starter								x	x		.45	
55154	Starter Pulley								x	x		5.50	
55156	Spring—Starter Rewind								x	x		1.75	
55157	Starter Pulley Liner—No Longer Used								x	x			
55158	Starter Rope Assembly								x	x		1.60	
55161	Plate—Pawl Friction								x	x		.88	
55162	Bearing—Starter Pivot								x	x		1.30	
55163	Plate—Rewind Spring Anchor								x	x		.35	
55164	Spring—Access Cover								x	x		.10	
55165	Spring—Anchor Plate								x	x		.16	
55166	Pivot Pin—Access Cover								x	x		.05	
55167	Retaining Ring								x	x		.06	
55174	Pulley—Emergency Starter								x	x		.60	
55175	Ratchet—Starter								x	x		2.50	
55176	Starter Housing (Refer to 55612)								x				
55179	Decal—Maintenance Instructions								x	x		.10	
55180	Access Cover Sub Assembly								x	x		3.00	
55181	Carburetor Control Knob	x		x				x	x	x		.65	
55182	Ring—Steering Handle Retainer							x	x	x		.10	
55183	Grommet—Shut Off Cock								x	x		.08	
55185	Spring—Magneto Cam								x	x		.06	
55186	Water Pump Seal (Refer to 55483)								x				
55187	Oil Seal—Propeller Shaft							x	x	x		.95	
55188	Pump Plate								x			.26	
55189	Gasket—Propeller Shaft Bearing Housing								x			.05	
55190	Washer—Drive Shaft Enclosure Tube Seal								x			.06	
55193	Bolt—Pinion to Drive Shaft							x	x	x		.20	
55195	Stud—Crankcase to Block								x	x		.10	
55196	Stud—Cylinder Head								x	x		.10	
55197	Stud—Manifold to Case								x	x		.10	
55198	Stud—Carburetor								x	x		.10	
55199	Gasket—Carburetor			x			x	x	x	x		.01	
55200	Valve and O'Ring Assembly								x	x		1.50	
55204	O'Ring Valve								x	x		.25	
55205	Valve Spring								x	x		.15	
55206	Pad—Reed Mounting								x	x		.45	
55207	Reed—Bleed System								x	x		.08	
55208	Stop—Bleed System—Reed								x	x		.06	
55209	Gasket—Reed Mounting Pad								x	x		.02	
55210	Nut—Bleed System								x	x		.05	
55211	Tube—Upper Cylinder Bleed								x	x		.24	
55212	Tube—Lower Cylinder Bleed								x	x		.15	
55213	Compression Sleeve								x	x		.01	
55214	Cam—Carburetor								x	x		.20	
55215	Key—Magneto								x	x		.10	
55216	Marker Lead Wire (Refer to 5925F)		x	x	x	x	x	x	x	x			
55217	Flap—Rear Shroud								x	x		.40	

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL	
55218	Main Spring—Shroud Fastener								x	x			.10
55219	Choke Control Rod Assembly								x	x			.40
55221	Hair Pin Cotter—Choke Control Rod								x	x			.01
55222	Lever—Choke Rod								x	x			.05
55223	Choke Bracket Assembly								x	x			.10
55224	Carburetor Bracket								x	x			.15
55225	Intermediate Lever								x	x			.03
55227	Carburetor Link								x	x			.03
55228	Link—Control Rod								x	x			.10
55231	Seal—Vent Tube—No Longer Used								x				
55232	Adapter Fitting—Shut Off Cock								x	x			.30
55233	Gasket—Cap Seal Clutch Shaft								x	x	x		.01
55234	Fuel Tank Assembly								x				26.00
55235	Decal—Rear								x				.10
55236	Fuel Gauge (Refer to 55290)								x				
55237	Screw—Fuel Gauge								x	x			.15
55238	Gasket—Fuel Gauge—Rear								x	x			.02
55239	Gasket—Fuel Gauge—Rear (Refer to 55238)								x	x			
55241	Clip—Wrench								x				.10
55242	Fuel Cap Assembly								x				2.00
55246	Gasket—Fuel Cap (Part of Assembly 55242)								x				.05
55248	Chain—Fuel Cap (Refer to 55359)								x				
55249	Stop—Fuel Cap								x	x			.10
55250	Front Shroud Sub-Assembly								x	x			4.50
55251	Stud—Shroud Fastener								x	x			.18
55252	Cross Pin—Shroud Fastener								x	x			.04
55253	Rear Shroud Sub Assembly								x	x			7.00
55254	Centering Disc								x				2.40
55255	Clutch Plate								x				.10
55256	Clutch Disc								x				.10
55257	Clutch Spring								x				.15
55258	Propeller Spring Shield								x	x			.25
55259	Propeller Nut								x	x	x		.56
55260	Propeller								x				4.60
55261	Shut Off Cock								x	x			1.66
55262	Clutch Plate and Disc Assembly								x				3.20
55263	Pinion Thrust Washer								x	x	x		.30
55264	Wrench								x				.25
55265	Shim—Gear Bearing								x	x	x		.05
55266	Seal—Upper Drive Shaft Enclosure Tube								x				.72
55267	Lower Seal—Drive Shaft Enclosure Tube								x				.05
55272	Seal Ring—Fuel Cap								x	x			.15
55273	Fuel Cap								x				2.30
55275	Pin—Fuel Cap Chain								x				.04
55276	Fuel Cap Assembly (Refer to 55431)								x				
55287	Washer and O'Ring—Fuel Gauge								x				.25
55290	Gas Gauge—Metal								x	x			3.30
55294	Bleed Valve Assembly								x	x			1.00
55295	Motor Support Tube Casing								x	x			7.10
55296	Stabilizer Friction Ring								x	x			1.30
55300	Upper Intermediate Housing								x	x			10.20
55301	Water Pump Housing (Refer to 55711)								x	x			
55306	Bracket—Clutch Lever								x	x	x		2.00
55307	Pin—Clutch Lever								x	x			.15
55308	Clutching Lever								x	x			.25
55309	Clutch Spring								x	x			1.80
55310	Rotor—Water Pump				x				x	x			1.20
55312	Clutch Bushing								x	x			2.10
55313	Pin—Pump Rotor								x	x			.03
55314	Drive Shaft—Lower								x	x			3.50

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price		
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL			
55316	Key Drive Shaft							x		x					.01
55319	Upper Drive Shaft									x					4.10
55320	O'Ring—Water Tube							x		x					.18
55321	Fitting—Clutch Shaft							x		x					.12
55322	Shaft—Clutch Lever Actuating							x		x					.50
55323	Cover Plate—Water Pump (Refer to 55713)							x		x					
55324	Stud—Lower Unit							x		x					.30
55325	Snap Ring							x		x					.05
55327	Access Cover							x		x					.16
55328	Drive Shaft Enclosure Tube									x					.96
55329	Boot for Clutch Mechanism							x		x					.10
55330	Gasket—Gear Case							x		x					.06
55332	Gasket—Bearing Plate							x		x					.10
55333	Gasket—Propeller Shaft Bearing Housing Assembly							x		x					.05
55339	Cap Seal—Clutch Shaft							x		x					.20
55341	O'Ring							x	x	x					.15
55344	Neutral Clutch Lever Assembly									x					.75
55347	Bracket Cable Support									x					.35
55348	Bracket—Tube Support									x					.30
55352	Water Inlet Tube (Refer to 55729)									x					
55354	Spring—Declutching							x		x					.04
55358	Upper Cable Assembly—Clutch Control									x					1.25
55359	Chain—Fuel Cap									x	x				.08
55361	Steering Handle Bracket									x	x				4.10
55362	Propeller (Standard)									x					4.20
55366	Rear Decal									x					.10
55367	Propeller Shaft Bearing Housing and Seal Assembly							x		x					3.90
55368	Water Pump Housing Assembly (Refer to 55712)							x		x					
55369	Control Cable, Boot and Tube Assembly									x					4.20
55371	Clutch Spring and Bushing Assembly							x		x					6.60
55380	Thrust Collar							x		x					.60
55381	Pin—Thrust Collar							x		x					.05
55382	Snap Ring—Thrust Collar Pin							x		x					.02
55388	Gasket—Access Cover							x		x					.03
55389	Thrust Washer—Clutch Bushing							x		x					.24
55390	Spring—Clutch							x		x					.08
55391	Decal—Start and Shift									x					.10
55392	Clutch Plate							x		x					.05
55393	Pin—Clutch Plate Driver							x		x					.08
55394	Clutch Plate and Disc Assembly							x		x					2.00
55395	Clutch Disc							x		x					.06
55399	Driver—Clutch Plate							x		x					2.75
55400	Snap Ring—Clutch Driver							x		x					.03
55401	Seal Neutral Cable Tube							x		x					.02
55405	Zerol Bevel Gear Assembly							x		x					5.50
55408	Bushing							x		x					.12
55411	Cylinder Block and Case Assembly (Refer to 55678)									x					
55412	Gasket—Clutch Lever Bracket							x		x					.02
55414	Carburetor Cam Assembly									x					1.00
55415	Washer—Pivot Screw							x		x					.01
55418	Neutral Lever Return Spring									x					.10
55419	Propeller Shaft							x		x					4.50
55420	Air Vent Screw (Refer to 55487)									x	x				
55421	Washer—Air Vent Seal									x	x				.05
55422	Chain Retainer—Fuel Cap									x	x				.05
55423	Friction Spring—Air Vent									x	x				.03
55424	Drive Pin							x		x					.03

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY												Price
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL		
55431	Filler Cap Assembly								x	x				3.10
55433	Access Cover Sub Assembly (Refer to 55180)								x	x				
55435	Bracket Assembly									x				13.50
55440	Fuel Tank Assembly (Refer to 55738)									x				
55441	Washer Bearing									x				.01
55442	Stud—Lower Unit (Short)							x		x				.30
55443	Bearing Plate and Bracket (Refer to 55709)							x		x				
55445	Upper cable assembly									x				2.40
55446	Dowel—Block and Case								x	x				.10
55447	Cap—Sealing Nut							x		x				.05
55448	Sealing Nut Assembly							x		x				.25
55450	Washer Clutch Spring							x		x				.04
55453	Decal—Neutral							x		x				.10
55456	Cap—Lower Main Bearing								x	x				.75
55461	Starter Housing								x	x				11.10
55474	Spring—Clutch Control Detent							x		x				.02
55475	Gasket—Exhaust Port Cover (Refer to 55032)								x	x				
55476	Rotor—Water Pump								x					.90
55479	Grommet—Clutch Cable (Refer to 55445)									x				
55482	Plate—Clutch Driver							x		x				.10
55483	Water Pump Seal							x	x	x				.03
55487	Air Vent Screw								x	x				.50
55489	Clip—Drive Pin									x				.04
55493	Rivet—Speed Control Lever								x	x				.05
55504	Stern Bracket Assembly								x					24.00
55505	Powerhead—Less Carburetor and Magneto (Refer to 55611)									x				
55506	Starter and Cover Assembly								x					23.00
55507	Throttle Control Assembly								x					12.40
55509	Carter Carburetor and Linkage Control								x	x				12.80
55510	Steering Handle and Bracket Assembly									x				23.75
55512	Stern Bracket Assembly								x	x				24.00
55517	Powerhead (Refer to 55636)									x				
55521	Starter and Cover Assembly								x	x				23.00
55600	Decal Set								x					.30
55602A	Gasket Set								x					1.00
55602B	Powerhead Gasket Set								x	x				.69
55603	Flushing Kit								x					3.00
55604	Flushing Kit—Pump Housing								x					2.10
55605	Gearcase Assembly								x					35.00
55606	Tank Bracket								x					13.50
55607	Gearcase Housing								x					9.90
55608	Cylinder Block and Crankcase Assembly								x					40.00
55609	Starter Cord and Handle Assembly								x					2.40
55610	Propeller Shaft Bearing Housing								x					3.30
55611	Powerhead—Less Carburetor and Magneto								x					132.50
55612	Starter Housing and Accessory Cover								x					13.70
55613	Propeller Shaft Bearing and Gear								x					19.80
55614	Propeller Shaft Assembly								x					15.40
55615	Rod and Button Assembly								x					1.10
55616	Stern Bracket—Right								x	x				5.50
55617	Stern Bracket—Left								x	x				5.50
55632	Gear Set (Ring and Pinion)							x		x				9.90
55635A	Gasket Set									x				1.52
55635B	Powerhead Gasket Set (Refer to 55602B)								x	x				
55636	Powerhead Assembly—Complete									x				186.40
55637	Powerhead—Less Carburetor and Magneto									x				132.50
55638	Steering Handle Assembly									x				18.00
55639	Motor Support Tube Assembly								x	x				13.70
55640	Starter Cord and Handle Assembly								x	x				2.50

WHEN ORDERING PARTS ALWAYS INDICATE MOTOR SERIAL NO. — MOTOR SERIES — MODEL

Part No.	DESCRIPTION	INTERCHANGEABILITY											Price
		20	40	45	60	66	75 TG	75 TS	100 Std	100 TS	200 SS	200 SL	
55641	Lower Unit Assembly									x			114.00
55642	Adapter								x		x		1.00
55643	Flushing Kit								x		x		1.40
55668	Washer								x		x		.05
55665	Decal Set										x		.30
55675	Motor Support Tube Assembly									x	x		13.70
55678	Cylinder Block and Crankcase Assembly										x		40.00
55709	Bearing Plate and Bracket Assembly								x		x		11.25
55710	Drive Shaft Bearing Plate								x		x		5.50
55711	Water Pump Housing								x		x		3.40
55712	Water Pump Housing Assembly								x		x		5.10
55713	Cover Plate—Water Pump								x		x		.30
55714	Gasket—Water Pump Bearing Plate								x		x		.03
55715	Gasket—Water Pump								x		x		.03
55729	Water Inlet Tube Assembly										x		1.20
55731	Propeller (Heavy Load)										x		4.20
55738	Fuel Tank Assembly										x		26.00
55739	Magneto (Refer to 55019)										x		
65158	Starter Handle	x	x	x	x	x	x	x	x	x	x		.44
65432	Plug Flushing System								x	x	x		.15

WATERCRAFTMANUALS.COM

Martin Motors SERVICE BULLETIN

EAU CLAIRE, WISCONSIN, U. S. A.

DATE May 15, 1950

NO. 29 Cont.

19. Replacing driveshaft seals	2.50
20. Replacing propeller shaft seal	1.50
21. Complete overhaul ("40" or "60")	15.00
22. Complete overhaul ("20")	10.00

HD:vw

H. Dickerson
Service Manager

WATERCRAFTMANUALS.COM